

HyPerformance[®] Plasma HPR260XD[®]

Manual gas

Instruction manual

806340 – Revision 3

Hypertherm[®]

Register your new Hypertherm system

Register your product on-line at www.hypertherm.com/registration for easier technical and warranty support. You can also receive updates on new Hypertherm products and a free gift as a token of our appreciation.

For your records

Serial number: _____

Purchase date: _____

Distributor: _____

Maintenance notes:

HyPerformance Plasma HPR260XD Manual Gas

Instruction Manual

(P/N 806340)

Revision 3 – June, 2015

**Hypertherm Inc.
Hanover, NH USA
www.hypertherm.com**

© 2015 Hypertherm Inc.
All Rights Reserved

Hypertherm, HyPerformance, HyDefinition, LongLife and CommandTHC are trademarks of Hypertherm Inc.
and may be registered in the United States and/or other countries.

Hypertherm Inc.

Etna Road, P.O. Box 5010
Hanover, NH 03755 USA
603-643-3441 Tel (Main Office)
603-643-5352 Fax (All Departments)
info@hypertherm.com (Main Office Email)

800-643-9878 Tel (Technical Service)

technical.service@hypertherm.com (Technical Service Email)

800-737-2978 Tel (Customer Service)

customer.service@hypertherm.com (Customer Service Email)

866-643-7711 Tel (Return Materials Authorization)**877-371-2876 Fax (Return Materials Authorization)**

return.materials@hypertherm.com (RMA email)

Hypertherm Plasmatechnik GmbH

Technologiepark Hanau
Rodenbacher Chaussee 6
D-63457 Hanau-Wolfgang, Deutschland
49 6181 58 2100 Tel
49 6181 58 2134 Fax
49 6181 58 2123 (Technical Service)

Hypertherm (S) Pte Ltd.

82 Genting Lane
Media Centre
Annexe Block #A01-01
Singapore 349567, Republic of Singapore
65 6841 2489 Tel
65 6841 2490 Fax
65 6841 2489 (Technical Service)

Hypertherm (Shanghai) Trading Co., Ltd.

Unit 301, South Building
495 ShangZhong Road
Shanghai, 200231
PR China
86-21-60740003 Tel
86-21-60740393 Fax

Hypertherm Europe B.V.

Vaartveld 9
4704 SE
Roosendaal, Nederland
31 165 596907 Tel
31 165 596901 Fax
31 165 596908 Tel (Marketing)
31 165 596900 Tel (Technical Service)
00 800 4973 7843 Tel (Technical Service)

Hypertherm Japan Ltd.

Level 9, Edobori Center Building
2-1-1 Edobori, Nishi-ku
Osaka 550-0002 Japan
81 6 6225 1183 Tel
81 6 6225 1184 Fax

Hypertherm Brasil Ltda.

Rua Bras Cubas, 231 – Jardim Maia
Guarulhos, SP - Brasil
CEP 07115-030
55 11 2409 2636 Tel
55 11 2408 0462 Fax

Hypertherm México, S.A. de C.V.

Avenida Toluca No. 444, Anexo 1,
Colonia Olivar de los Padres
Delegación Álvaro Obregón
México, D.F. C.P. 01780
52 55 5681 8109 Tel
52 55 5683 2127 Fax

Hypertherm Korea Branch

#3904 Centum Leaders Mark B/D,
1514 Woo-dong, Haeundae-gu, Busan
Korea, 612-889
82 51 747 0358 Tel
82 51 701 0358 Fax

ELECTROMAGNETIC COMPATIBILITY (EMC)

Introduction

Hypertherm's CE-marked equipment is built in compliance with standard EN60974-10. The equipment should be installed and used in accordance with the information below to achieve electromagnetic compatibility.

The limits required by EN60974-10 may not be adequate to completely eliminate interference when the affected equipment is in close proximity or has a high degree of sensitivity. In such cases it may be necessary to use other measures to further reduce interference.

This cutting equipment is designed for use only in an industrial environment.

Installation and use

The user is responsible for installing and using the plasma equipment according to the manufacturer's instructions.

If electromagnetic disturbances are detected then it shall be the responsibility of the user to resolve the situation with the technical assistance of the manufacturer. In some cases this remedial action may be as simple as earthing the cutting circuit, see *Earthing of the workpiece*. In other cases, it could involve constructing an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases, electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Assessment of area

Before installing the equipment, the user shall make an assessment of potential electromagnetic problems in the surrounding area. The following shall be taken into account:

- a. Other supply cables, control cables, signaling and telephone cables; above, below and adjacent to the cutting equipment.
- b. Radio and television transmitters and receivers.
- c. Computer and other control equipment.
- d. Safety critical equipment, for example guarding of industrial equipment.
- e. Health of the people around, for example the use of pacemakers and hearing aids.
- f. Equipment used for calibration or measurement.
- g. Immunity of other equipment in the environment. User shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures.
- h. Time of day that cutting or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

Methods of reducing emissions

Mains supply

Cutting equipment must be connected to the mains supply according to the manufacturer's recommendations. If interference occurs, it may be necessary to take additional precautions such as filtering of the mains supply.

Consideration should be given to shielding the supply cable of permanently installed cutting equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the cutting mains supply so that good electrical contact is maintained between the conduit and the cutting power source enclosure.

Maintenance of cutting equipment

The cutting equipment must be routinely maintained according to the manufacturer's recommendations. All access and service doors and covers should be closed and properly fastened when the cutting equipment is in operation. The cutting equipment should not be modified in any way, except as set forth in and in accordance with the manufacturer's written instructions. For example, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturer's recommendations.

Cutting cables

The cutting cables should be kept as short as possible and should be positioned close together, running at or close to the floor level.

Equipotential bonding

Bonding of all metallic components in the cutting installation and adjacent to it should be considered.

However, metallic components bonded to the workpiece will increase the risk that the operator could receive a shock by touching these metallic components and the electrode (nozzle for laser heads) at the same time.

The operator should be insulated from all such bonded metallic components.

Earthing of the workpiece

Where the workpiece is not bonded to earth for electrical safety, nor connected to earth because of its size and position, for example, ship's hull or building steel work, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances. Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment. Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitances selected according to national regulations.

Note: The cutting circuit may or may not be earthed for safety reasons. Changing the earthing arrangements should only be authorized by a person who is competent to assess whether the changes will increase the risk of injury, for example, by allowing parallel cutting current return paths which may damage the earth circuits of other equipment. Further guidance is provided in IEC 60974-9, Arc Welding Equipment, Part 9: Installation and Use.

Screening and shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire plasma cutting installation may be considered for special applications.

Attention

Genuine Hypertherm parts are the factory-recommended replacement parts for your Hypertherm system. Any damage or injury caused by the use of other than genuine Hypertherm parts may not be covered by the Hypertherm warranty, and will constitute misuse of the Hypertherm Product.

You are solely responsible for the safe use of the Product. Hypertherm does not and cannot make any guarantee or warranty regarding the safe use of the product in your environment.

General

Hypertherm Inc. warrants that its Products shall be free from defects in materials and workmanship for the specific periods of time set forth herein and as follows: if Hypertherm is notified of a defect (i) with respect to the plasma power supply within a period of two (2) years from the date of its delivery to you, with the exception of Powermax brand power supplies, which shall be within a period of three (3) years from the date of delivery to you, and (ii) with respect to the torch and leads within a period of one (1) year from its date of delivery to you, with the exception of the HPRXD short torch with integrated lead, which shall be within a period of six (6) months from the date of delivery to you, and with respect to torch lifter assemblies within a period of one (1) year from its date of delivery to you, and with respect to Automation products one (1) year from its date of delivery to you, with the exception of the EDGE Pro CNC, EDGE Pro Ti CNC, MicroEDGE Pro CNC, and ArcGlide THC, which shall be within a period of two (2) years from the date of delivery to you, and (iii) with respect to HyIntensity fiber laser components within a period of two (2) years from the date of its delivery to you, with the exception of laser heads and beam delivery cables, which shall be within a period of one (1) year from its date of delivery to you.

This warranty shall not apply to any Powermax brand power supplies that have been used with phase converters. In addition, Hypertherm does not warranty systems that have been damaged as a result of poor power quality, whether from phase converters or incoming line power. This warranty shall not apply to any product which has been incorrectly installed, modified, or otherwise damaged.

Hypertherm provides repair, replacement or adjustment of the Product as the sole and exclusive remedy, if and only if the warranty set forth herein properly is invoked and applies. Hypertherm, at its sole option, shall repair, replace, or adjust, free of charge, any defective Products covered by this warranty which shall be returned with Hypertherm's prior authorization (which shall not be unreasonably withheld), properly packed, to Hypertherm's place of business in Hanover, New Hampshire, or to an authorized Hypertherm repair facility, all costs, insurance and freight pre paid by the customer. Hypertherm shall not be liable for any repairs, replacement, or adjustments of Products covered by this warranty, except those made pursuant to this paragraph and with Hypertherm's prior written consent.

The warranty set forth above is exclusive and is in lieu of all other warranties, express, implied, statutory, or otherwise with respect to the Products or as to the results which may be obtained therefrom, and all implied warranties or conditions of quality or of merchantability or fitness for a particular purpose or against infringement. The foregoing shall constitute the sole and exclusive remedy for any breach by Hypertherm of its warranty.

Distributors/OEMs may offer different or additional warranties, but Distributors/OEMs are not authorized to give any additional warranty protection to you or make any representation to you purporting to be binding upon Hypertherm.

Patent indemnity

Except only in cases of products not manufactured by Hypertherm or manufactured by a person other than Hypertherm not in strict conformity with Hypertherm's specifications and in cases of designs, processes, formulae, or combinations not developed or purported to be developed by Hypertherm, Hypertherm will have the right to defend or settle, at its own expense, any suit or proceeding brought against you alleging that the use of the Hypertherm product, alone and not in combination with any other product not supplied by Hypertherm, infringes any patent of any third party. You shall notify Hypertherm promptly upon learning of any action or threatened action in connection with any such alleged infringement (and in any event no longer than fourteen (14) days after learning of any action or threat of action), and Hypertherm's obligation to defend shall be conditioned upon Hypertherm's sole control of, and the indemnified party's cooperation and assistance in, the defense of the claim.

Limitation of liability

In no event shall Hypertherm be liable to any person or entity for any incidental, consequential direct, indirect, punitive or exemplary damages (including but not limited to lost profits) regardless of whether such liability is based on breach of contract, tort, strict liability, breach of warranty, failure of essential purpose, or otherwise, and even if advised of the possibility of such damages.

National and local codes

National and local codes governing plumbing and electrical installation shall take precedence over any instructions contained in this manual. In no event shall Hypertherm be liable for injury to persons or property damage by reason of any code violation or poor work practices.

WARRANTY

Liability cap

In no event shall Hypertherm's liability, if any, whether such liability is based on breach of contract, tort, strict liability, breach of warranties, failure of essential purpose or otherwise, for any claim, action, suit or proceeding (whether in court, arbitration, regulatory proceeding or otherwise) arising out of or relating to the use of the Products exceed in the aggregate the amount paid for the Products that gave rise to such claim.

Insurance

At all times you will have and maintain insurance in such quantities and types, and with coverage sufficient and appropriate to defend and to hold Hypertherm harmless in the event of any cause of action arising from the use of the products.

Transfer of rights

You may transfer any remaining rights you may have hereunder only in connection with the sale of all or substantially all of your assets or capital stock to a successor in interest who agrees to be bound by all of the terms and conditions of this Warranty. Within thirty (30) days before any such transfer occurs, you agree to notify in writing Hypertherm, which reserves the right of approval. Should you fail timely to notify Hypertherm and seek its approval as set forth herein, the Warranty set forth herein shall be null and void and you will have no further recourse against Hypertherm under the Warranty or otherwise.

ELECTROMAGNETIC COMPATIBILITY (EMC)	EMC-1
WARRANTY	W-1

Section 1

SAFETY	SC-1
Recognize safety information	SC-2
Follow safety instructions.....	SC-2
Inspect equipment before using.....	SC-2
Responsibility for safety.....	SC-2
A plasma arc can damage frozen pipes	SC-2
Static electricity can damage printed circuit boards	SC-2
Grounding safety.....	SC-3
Electrical hazards.....	SC-3
Electric shock can kill.....	SC-3
Cutting can cause fire or explosion	SC-4
Machine motion can cause injury	SC-4
Compressed gas equipment safety.....	SC-5
Gas cylinders can explode if damaged.....	SC-5
Toxic fumes can cause injury or death.....	SC-5
A plasma arc can cause injury and burns.....	SC-6
Arc rays can burn eyes and skin.....	SC-6
Pacemaker and hearing aid operation	SC-6
Noise can damage hearing	SC-7
Dry dust collection information	SC-7
Laser radiation	SC-8
Additional safety information	SC-8

Section 2

SPECIFICATIONS	2-1
System description.....	2-3
General	2-3
Power supply.....	2-3
Ignition console.....	2-3
Gas console	2-3
Off-valve	2-3
Torch	2-3
Specifications	2-4
System gas requirements.....	2-4
Power supply.....	2-5
Ignition console – 078172.....	2-6
Torch lead junction box (Optional) – 078619.....	2-8
Gas console – 078532	2-9
Off-valve – 078534	2-10
Torch – 228521	2-11
IEC symbols	2-12
Symbols and Marks	2-13

TABLE OF CONTENTS

Section 3

INSTALLATION	3-1
Upon receipt	3-3
Claims.....	3-3
Installation requirements.....	3-3
Noise levels	3-3
Placement of system components.....	3-3
Torque specifications	3-3
Installation requirements.....	3-4
System components.....	3-5
Cables and hoses	3-5
Supply gas hoses.....	3-5
Customer-supplied power cable	3-5
Recommended grounding and shielding practices	3-6
Introduction	3-6
Types of grounding	3-6
Grounding practices.....	3-6
Grounding diagram	3-9
Placement of the power supply	3-11
Install the ignition console.....	3-12
Install the off-valve	3-14
Placement of the gas console.....	3-15
Power supply to ignition console leads	3-16
Pilot arc lead.....	3-16
Negative lead.....	3-16
Ignition console power cable.....	3-18
Ignition console coolant hoses.....	3-19
Power supply to gas console cables	3-20
Control cable.....	3-20
Power cable.....	3-20
Gas console to off-valve connections.....	3-22
Cable and gas hose assembly	3-22
Power supply to CNC interface cable	3-24
Optional multi-system CNC interface cable	3-24
Notes to CNC interface cable run list	3-25
Examples of output circuits	3-26
Examples of input circuits.....	3-27
Remote ON/OFF switch (provided by customer)	3-28
Torch lead assembly	3-29
Torch lead junction box (Optional).....	3-30
Install the junction box.....	3-31
Connect the leads	3-32
Work lead	3-36
Torch connections	3-37
Connect the torch to the torch lead assembly	3-37
Connect the torch to the quick-disconnect	3-41

Torch mounting and alignment	3-42
Torch lifter requirement	3-43
Hypernet.....	3-43
Power requirements	3-44
General	3-44
Line disconnect switch	3-45
Main power cable.....	3-45
Connect the power.....	3-46
Torch coolant requirements.....	3-47
Premixed coolant for standard operating temperatures	3-47
Custom Coolant mix for cold operating temperatures.....	3-48
Custom Coolant mix for hot operating temperatures.....	3-49
Water purity requirements	3-49
Fill the power supply with coolant.....	3-50
Gas requirements	3-51
Setting the supply regulators.....	3-51
Gas regulators.....	3-52
Supply gas plumbing	3-53
Connect the supply gases	3-54
Supply gas hoses	3-55

Section 4

OPERATION4-1

Daily start-up.....	4-3
Check torch	4-3
Controls and indicators	4-4
General	4-4
Main power switch	4-4
Power indicators.....	4-4
Manual gas console operation.....	4-5
Consumable selection	4-6
Standard cutting (0°).....	4-6
Bevel cutting (0° to 45°)	4-6
Marking	4-6
Consumables for mirror-image cutting.....	4-6
SilverPlus electrodes	4-6
Mild steel	4-7
Stainless steel	4-8
Aluminum	4-8
Mild steel bevel cutting	4-9
Mild steel, thick piercing, bevel cutting	4-9
Stainless steel bevel cutting	4-9
Install and Inspect consumables	4-10
Install consumables.....	4-10
Inspect consumables.....	4-11
Torch maintenance	4-13

TABLE OF CONTENTS

Routine maintenance	4-13
Quick-disconnect maintenance	4-13
Maintenance kit.....	4-13
Torch connections	4-14
Replace torch water tube.....	4-14
Common cutting faults	4-15
How to optimize cut quality	4-16
Tips for table and torch.....	4-16
Plasma set-up tips.....	4-16
Maximize the life of consumable parts.....	4-16
Additional factors of cut quality.....	4-17
Additional improvements	4-19
Cut charts.....	4-20
Thin stainless steel with HDi technology.....	4-20
Overview.....	4-20
Cut charts.....	4-20
Bevel cutting	4-21
Cut charts.....	4-21
Consumables	4-21
Bevel compensation tables	4-21
Bevel cutting definitions.....	4-22
Underwater cut charts	4-23
Overview.....	4-23
Cut charts.....	4-24
Estimated kerf-width compensation	4-25

Section 5

MAINTENANCE.....	5-1
Introduction	5-3
Routine maintenance.....	5-3
System description.....	5-4
Power and signal cables.....	5-4
Sequence of operation	5-5
Gas system purge cycle.....	5-6
Gas system valve usage.....	5-6
Marking process	5-8
PCB block diagram	5-9
Error codes.....	5-10
HyPerformance plasma system error codes.....	5-10
Error code troubleshooting – error codes 000 to 018	5-11
Error code troubleshooting – error codes 020 to 028, 224 to 228.....	5-12
Error code troubleshooting – error codes 030 to 042, 231 to 234.....	5-13
Error code troubleshooting – error codes 044 to 046	5-14
Error code troubleshooting – error codes 047 to 053, 248 to 250.....	5-15
Error code troubleshooting – error codes 054 to 061	5-16
Error code troubleshooting – error codes 062 to 067, 265 to 267	5-17

Error code troubleshooting – error codes 071 to 075, 273 to 275	5-18
Error code troubleshooting – error codes 076 to 101, 276 to 301	5-19
Error code troubleshooting – error codes 102 to 111, 302 to 308	5-20
Error code troubleshooting – error codes 116 to 133, 316	5-21
Error code troubleshooting – error codes 134 to 140, 334 and 338	5-22
Error code troubleshooting – error codes 141 to 152, 346 to 351	5-23
Error code troubleshooting – error codes 153 to 156, 354 to 356	5-24
Error code troubleshooting – error codes 157 to 159, 357 to 359	5-25
Error code troubleshooting – error codes 160 to 180	5-26
Error code troubleshooting – error code 181, 182, 298, and 383	5-27
Power supply states	5-28
Plasma system operation with pump timeout	5-29
CNC operation with pump timeout	5-30
Initial checks	5-31
Power measurement	5-32
Air filter element replacement	5-33
Power supply coolant system servicing	5-34
Draining the coolant system	5-34
Coolant system filter	5-35
Filter replacement	5-35
Coolant flow troubleshooting chart	5-36
Coolant flow tests	5-37
Before testing	5-37
Using the Hypertherm flow meter (128933)	5-37
Manual pump operation	5-38
Test 1 – return line	5-39
Test 2 – supply line at ignition console	5-39
Test 3 – change the torch	5-40
Test 4 – supply line to the torch receptacle	5-40
Test 5 – return line from the torch receptacle (remove at the ignition console)	5-40
Test 6 – bucket test at the pump	5-41
Test 7 – bypass the check valve	5-41
Pump and motor troubleshooting	5-42
Testing the flow sensor	5-43
Gas leak tests	5-44
Leak test 1	5-44
Leak test 2	5-44
Power supply control board PCB3	5-45
Power supply power distribution board PCB2	5-46
Start-circuit PCB1	5-47
Operation	5-47
Start circuit functional schematic	5-47
Start circuit troubleshooting	5-47
Pilot arc current levels	5-49
Gas console control board PCB2	5-50
Gas console power distribution board PCB1	5-51

TABLE OF CONTENTS

Gas console, AC valve-driver board PCB3.....	5-52
Chopper tests.....	5-53
Phase-loss detection test	5-55
Torch lead test.....	5-56
Preventive maintenance.....	5-57

Section 6

PARTS LIST	6-1
Power supply	6-2
Ignition console	6-7
Ignition console to junction box leads	6-8
Torch lead junction box (Optional).....	6-9
Gas console	6-10
Off-valve.....	6-11
HyPerformance torch	6-12
Torch assembly	6-12
Torch leads	6-13
Ohmic contact wire.....	6-13
Consumable parts kits	6-14
Consumables for mirror-image cutting	6-16
Straight cutting	6-16
Bevel cutting.....	6-18
Recommended spare parts	6-19
Warning Label – 110647.....	6-20

Section 7

WIRING DIAGRAMS.....	7-1
Introduction	7-1
Wiring Diagram Symbols	7-1
Discrete output functionality.....	7-4

Appendix A

HYPERTHERM TORCH COOLANT SAFETY DATA	A-1
1 – Identification of the substance/mixture and of the company undertaking.....	a-2
2 – Hazards identification	a-2
3 – Composition/information on ingredients.....	a-3
4 – First aid measures	a-3
5 – Fire-fighting measures.....	a-3
6 – Accidental release measures.....	a-3
7 – Handling and storage	a-4
8 – Exposure controls/personal protection	a-4
9 – Physical and chemical properties.....	a-4
10 – Stability and reactivity	a-5
11 – Toxicological information.....	a-5
12 – Ecological information.....	a-5
13 – Disposal considerations.....	a-6
14 – Transport information	a-6

15 – Regulatory information.....	a-6
16 – Other information	a-7
Freezing Point of Propylene Glycol Solution	a-8

Appendix B

FUNCTIONAL DESCRIPTION OF SOFTWARE	B-1
---	------------

Appendix C

ROBOTIC APPLICATIONS.....	C-1
----------------------------------	------------

Components for robotic applications.....	c-2
Torch leads	c-2
Ohmic contact extension.....	c-2
Rotational mounting sleeve (optional) – 220864	c-3
Leather overwrap – 024866.....	c-3
Robotic teaching torch (laser pointer) – 228394.....	c-3
Torch and rotational mounting sleeve dimensions.....	c-3
Rotational mounting sleeve clamp dimensions.....	c-4
HPR260XD MANUAL GAS REVISION CHANGES (806340).....	1

Section 1

SAFETY

In this section:

Recognize safety information	SC-2
Follow safety instructions.....	SC-2
Inspect equipment before using.....	SC-2
Responsibility for safety.....	SC-2
A plasma arc can damage frozen pipes	SC-2
Static electricity can damage printed circuit boards	SC-2
Grounding safety	SC-3
Electrical hazards.....	SC-3
Electric shock can kill.....	SC-3
Cutting can cause fire or explosion.....	SC-4
Machine motion can cause injury	SC-4
Compressed gas equipment safety.....	SC-5
Gas cylinders can explode if damaged.....	SC-5
Toxic fumes can cause injury or death	SC-5
A plasma arc can cause injury and burns.....	SC-6
Arc rays can burn eyes and skin.....	SC-6
Pacemaker and hearing aid operation	SC-6
Noise can damage hearing.....	SC-7
Dry dust collection information	SC-7
Laser radiation	SC-8
Additional safety information	SC-8



RECOGNIZE SAFETY INFORMATION

The symbols shown in this section are used to identify potential hazards. When you see a safety symbol in this manual or on your machine, understand the potential for personal injury, and follow the related instructions to avoid the hazard.



FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and safety labels on your machine.

- Keep the safety labels on your machine in good condition. Replace missing or damaged labels immediately.
- Learn how to operate the machine and how to use the controls properly. Do not let anyone operate it without instruction.
- Keep your machine in proper working condition. Unauthorized modifications to the machine may affect safety and machine service life.

DANGER WARNING CAUTION

American National Standards Institute (ANSI) guidelines are used for safety signal words and symbols. The signal word **DANGER** or **WARNING** is used with a safety symbol. **DANGER** identifies the most serious hazards.

- **DANGER** and **WARNING** safety labels are located on your machine near specific hazards.
- **DANGER** safety messages precede related instructions in the manual that will result in serious injury or death if not followed correctly.
- **WARNING** safety messages precede related instructions in this manual that may result in injury or death if not followed correctly.
- **CAUTION** safety messages precede related instructions in this manual that may result in minor injury or damage to equipment if not followed correctly.

INSPECT EQUIPMENT BEFORE USING

All cutting equipment must be inspected as required to make sure it is in safe operating condition. When found to be incapable of reliable and safe operation, the equipment must be repaired by qualified personnel prior to its next use or withdrawn from service.

RESPONSIBILITY FOR SAFETY

The person or entity responsible for the safety of the workplace must:

- Make sure that operators and their supervisors are trained in the safe use of their equipment, the safe use of the process, and emergency procedures.
- Make sure that all hazards and safety precautions identified herein are communicated to and understood by workers before the start of work.
- Designate approved cutting areas and establish procedures for safe cutting.
- Be responsible for authorizing cutting operations in areas not specifically designed or approved for such processes.
- Make sure that only approved equipment, such as torches and personal protective equipment, are used.
- Select contractors who provide trained and qualified personnel, and who have awareness of the risks involved, to do cutting.
- Tell contractors about flammable materials or hazardous conditions that are specific to the site, or hazardous conditions that they may not be aware of.
- Make sure that the quality and quantity of air for ventilation is such that personnel exposures to hazardous contaminants are below the allowable limits.
- Make sure that ventilation in confined spaces is sufficient to allow adequate oxygen for life support, to prevent accumulation of asphyxiants or flammable explosive mixtures, to prevent oxygen-enriched atmospheres, and to keep airborne contaminants in breathing atmospheres below allowable limits.



A PLASMA ARC CAN DAMAGE FROZEN PIPES

Frozen pipes may be damaged or can burst if you attempt to thaw them with a plasma torch.



STATIC ELECTRICITY CAN DAMAGE PRINTED CIRCUIT BOARDS

Use proper precautions when handling printed circuit boards:

- Store printed circuit boards in anti-static containers.
- Wear a grounded wrist strap when handling printed circuit boards.



GROUNDING SAFETY

Work lead Attach the work lead securely to the workpiece or the cutting table with good metal-to-metal contact. Do not connect it to the piece that will fall away when the cut is complete.

Cutting table Connect the cutting table to an earth ground, in accordance with appropriate national and local electrical regulations.

Input power

- Make sure to connect the power cord ground wire to the ground in the disconnect box.
- If installation of the plasma system involves connecting the power cord to the power supply, make sure to connect the power cord ground wire properly.
- Place the power cord's ground wire on the stud first, then place any other ground wires on top of the power cord ground. Tighten the retaining nut.
- Tighten all electrical connections to avoid excessive heating.

ELECTRICAL HAZARDS

- Only trained and authorized personnel may open this equipment.
- If the equipment is permanently connected, turn it off, and lock out/tag out power before the enclosure is opened.
- If power is supplied to the equipment with a cord, unplug the unit before the enclosure is opened.
- Lockable disconnects or lockable plug covers must be provided by others.
- Wait 5 minutes after removal of power before entering the enclosure to allow stored energy to discharge.
- If the equipment must have power when the enclosure is open for servicing, arc flash explosion hazards may exist. Follow **all** local requirements (NFPA 70E in the USA) for safe work practices and for personal protective equipment when servicing energized equipment.
- Prior to operating the equipment after moving, opening, or servicing, make sure to close the enclosure and make sure that there is proper earth ground continuity to the enclosure.
- Always follow these instructions for disconnecting power before inspecting or changing torch consumable parts.



ELECTRIC SHOCK CAN KILL

Touching live electrical parts can cause a fatal shock or severe burn.

- Operating the plasma system completes an electrical circuit between the torch and the workpiece. The workpiece and anything touching the workpiece are part of the electrical circuit.
- In machine torch applications, never touch the torch body, workpiece, or water in a water table when the plasma system is operating.

Electric shock prevention

All plasma systems use high voltage in the cutting process (200 to 400 VDC are common). Take the following precautions when operating this system:

- Wear insulated gloves and boots, and keep your body and clothing dry.
- Do not stand, sit, or lie on – or touch – any wet surface when using the plasma system.
- Insulate yourself from the work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground. If you must cut in or near a damp area, use extreme caution.
- Provide a disconnect switch close to the power supply with properly sized fuses. This switch allows the operator to turn off the power supply quickly in an emergency situation.
- When using a water table, make sure that it is correctly connected to an earth ground.
- Install and ground this equipment according to the instruction manual and in accordance with national and local regulations.
- Inspect the input power cord frequently for damage or cracking of the cover. Replace a damaged power cord immediately. **Bare wiring can kill.**
- Inspect and replace any worn or damaged torch leads.
- Do not pick up the workpiece, including the waste cutoff, while you cut. Leave the workpiece in place or on the workbench with the work lead attached during the cutting process.
- Before checking, cleaning, or changing torch parts, disconnect the main power or unplug the power supply.
- Never bypass or shortcut the safety interlocks.
- Before removing any power supply or system enclosure cover, disconnect electrical input power. Wait 5 minutes after disconnecting the main power to allow capacitors to discharge.
- Never operate the plasma system unless the power supply covers are in place. Exposed power supply connections present a severe electrical hazard.
- When making input connections, attach a proper grounding conductor first.
- Each plasma system is designed to be used only with specific torches. Do not substitute other torches, which could overheat and present a safety hazard.



CUTTING CAN CAUSE FIRE OR EXPLOSION

Fire prevention

- Make sure the cutting area is safe before doing any cutting. Keep a fire extinguisher nearby.
- Remove all flammables within 35 feet (10 m) of the cutting area.
- Quench hot metal or allow it to cool before handling or before letting it touch combustible materials.
- Never cut containers with potentially flammable materials inside – they must be emptied and properly cleaned first.
- Ventilate potentially flammable atmospheres before cutting.
- When cutting with oxygen as the plasma gas, an exhaust ventilation system is required.

Explosion prevention

- Do not use the plasma system if explosive dust or vapors may be present.
- Do not cut pressurized cylinders, pipes, or any closed containers.
- Do not cut containers that have held combustible materials.



WARNING
Explosion Hazard
Argon-Hydrogen and Methane

Hydrogen and methane are flammable gases that present an explosion hazard. Keep flames away from cylinders and hoses that contain methane or hydrogen mixtures. Keep flames and sparks away from the torch when using methane or argon-hydrogen plasma.



WARNING
Explosion Hazard
Underwater Cutting with Fuel Gases
Containing Hydrogen

- Do not cut underwater with fuel gases containing hydrogen.
- Cutting underwater with fuel gases containing hydrogen can result in an explosive condition that can detonate during plasma cutting operations.



WARNING
Explosion Hazard
Hydrogen Detonation with Aluminum Cutting

When you use a plasma torch to cut aluminum alloys under water or on a water table, a chemical reaction between the water and the workpiece, parts, fine particles, or molten aluminum droplets generates significantly more hydrogen gas than occurs with other metals. This hydrogen gas may get trapped under the workpiece. If exposed to oxygen or air, the plasma arc or a spark from any source can ignite this trapped hydrogen gas, causing an explosion that may result in death, personal injury, loss of property, or equipment damage.

Consult with the table manufacturer and other experts prior to cutting aluminum to implement a risk assessment and mitigation plan that eliminates the risk of detonation by preventing hydrogen accumulation.

Also, make sure that the water table, fume extraction (ventilation), and other parts of the cutting system have been designed with aluminum cutting in mind.

Do not cut aluminum alloys underwater or on a water table unless you can prevent the accumulation of hydrogen gas.

Note: With proper mitigation, most aluminum alloys can be plasma cut on a water table. An exception is aluminum-lithium alloys. **Never cut aluminum-lithium alloys in the presence of water.** Contact your aluminum supplier for additional safety information regarding hazards associated with aluminum-lithium alloys.




MACHINE MOTION CAN CAUSE INJURY

When an original equipment manufacturer (OEM) makes a cutting system by combining Hypertherm equipment with other equipment, the end-use customer and the OEM are responsible for providing protection against the hazardous moving parts of this cutting system. However, we advise the following to prevent operator injury and equipment damage:

- Read and follow the instruction manual provided by the OEM.
- Maintain a restricted-access area larger than the maximum movement range of the cutting system's moving parts.
- Where there is a risk of collision, do not allow personnel or equipment near the cutting system's moving parts.
- Avoid accidental contact with the CNC touchscreen or joystick. Accidental contact can activate commands and result in unintended motion.
- Do not service or clean the machinery during operation.
- If servicing is required, enable the safety interlock or disconnect and lock out/tag out power to disable the motors and prevent motion.
- Allow only qualified personnel to operate, maintain, and service the machinery.

COMPRESSED GAS EQUIPMENT SAFETY

- Never lubricate cylinder valves or regulators with oil or grease.
- Use only correct gas cylinders, regulators, hoses, and fittings designed for the specific application.
- Maintain all compressed gas equipment and associated parts in good condition.
- Label and color-code all gas hoses to identify the type of gas in each hose. Consult applicable national and local regulations.



GAS CYLINDERS CAN EXPLODE IF DAMAGED

Gas cylinders contain gas under high pressure. If damaged, a cylinder can explode.

- Handle and use compressed gas cylinders in accordance with applicable national and local regulations.
- Never use a cylinder that is not upright and secured in place.
- Keep the protective cap in place over the valve except when the cylinder is in use or connected for use.
- Never allow electrical contact between the plasma arc and a cylinder.
- Never expose cylinders to excessive heat, sparks, slag, or open flame.
- Never use a hammer, wrench, or other tool to open a stuck cylinder valve.



TOXIC FUMES CAN CAUSE INJURY OR DEATH

The plasma arc by itself is the heat source used for cutting. Accordingly, although the plasma arc has not been identified as a source of toxic fumes, the material being cut can be a source of toxic fumes or gases that deplete oxygen.

The fumes produced vary depending on the metal that is cut. Metals that may release toxic fumes include, but are not limited to, stainless steel, carbon steel, zinc (galvanized), and copper.

In some cases, the metal may be coated with a substance that could release toxic fumes. Toxic coatings include, but are not limited to, lead (in some paints), cadmium (in some paints and fillers), and beryllium.

The gases produced by plasma cutting vary based on the material to be cut and the method of cutting, but may include ozone, oxides of nitrogen, hexavalent chromium, hydrogen, and other substances if such are contained in or released by the material being cut.

Caution should be taken to minimize exposure to fumes produced by any industrial process. Depending on the chemical composition and concentration of the fumes (as well as other factors, such as ventilation), there may be a risk of physical illness, such as birth defects or cancer.

It is the responsibility of the equipment and site owner to test the air quality in the cutting area and to make sure that the air quality in the workplace meets all local and national standards and regulations.

The air quality level in any relevant workplace depends on site-specific variables such as:

- Table design (wet, dry, underwater).
- Material composition, surface finish, and composition of coatings.
- Volume of material removed.
- Duration of cutting or gouging.
- Size, air volume, ventilation, and filtration of the workplace.
- Personal protective equipment.
- Number of welding and cutting systems in operation.
- Other workplace processes that may produce fumes.

If the workplace must conform to national or local regulations, only monitoring or testing done at the site can determine whether the workplace is above or below allowable levels.

To reduce the risk of exposure to fumes:

- Remove all coatings and solvents from the metal before cutting.
- Use local exhaust ventilation to remove fumes from the air.
- Do not inhale fumes. Wear an air-supplied respirator when cutting any metal coated with, containing, or suspected to contain toxic elements.
- Make sure that those using welding or cutting equipment, as well as air-supplied respiration devices, are qualified and trained in the proper use of such equipment.
- Never cut containers with potentially toxic materials inside. Empty and properly clean the container first.
- Monitor or test the air quality at the site as needed.
- Consult with a local expert to implement a site plan to make sure air quality is safe.



A PLASMA ARC CAN CAUSE INJURY AND BURNS

Instant-on torches

- A plasma arc ignites immediately when the torch switch is activated.

The plasma arc will cut quickly through gloves and skin.

- Keep away from the torch tip.
- Do not hold metal near the cutting path.
- Never point the torch toward yourself or others.



ARC RAYS CAN BURN EYES AND SKIN

Eye protection Plasma arc rays produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin.

- Use eye protection in accordance with applicable national and local regulations.
- Wear eye protection (safety glasses or goggles with side shields, and a welding helmet) with appropriate lens shading to protect your eyes from the arc's ultraviolet and infrared rays.

Skin protection Wear protective clothing to protect against burns caused by ultraviolet light, sparks, and hot metal.

- Wear gauntlet gloves, safety shoes, and hat.

- Wear flame-retardant clothing to cover all exposed areas.
- Wear cuffless trousers to prevent entry of sparks and slag.

Also, remove any combustibles, such as a butane lighter or matches, from your pockets before cutting.

Cutting area Prepare the cutting area to reduce reflection and transmission of ultraviolet light:

- Paint walls and other surfaces with dark colors to reduce reflection.
- Use protective screens or barriers to protect others from flash and glare.
- Warn others not to watch the arc. Use placards or signs.

Arc current	Minimum protective shade number (ANSI Z49.1:2012)	Suggested shade number for comfort (ANSI Z49.1:2012)	OSHA 29CFR 1910.133(a)(5)	Europe EN168:2002
Less than 40 A	5	5	8	9
41 A to 60 A	6	6	8	9
61 A to 80 A	8	8	8	9
81 A to 125 A	8	9	8	9
126 A to 150 A	8	9	8	10
151 A to 175 A	8	9	8	11
176 A to 250 A	8	9	8	12
251 A to 300 A	8	9	8	13
301 A to 400 A	9	12	9	13
401 A to 800 A	10	14	10	N/A



PACEMAKER AND HEARING AID OPERATION

Pacemaker and hearing aid operation can be affected by magnetic fields from high currents.

Pacemaker and hearing aid wearers should consult a doctor before going near any plasma arc cutting and gouging operations.

To reduce magnetic field hazards:

- Keep both the work lead and the torch lead to one side, away from your body.
- Route the torch leads as close as possible to the work lead.
- Do not wrap or drape the torch lead or work lead around your body.
- Keep as far away from the power supply as possible.



NOISE CAN DAMAGE HEARING

Cutting with a plasma arc can exceed acceptable noise levels as defined by local regulations in many applications. Prolonged exposure to excessive noise can damage hearing. Always wear proper ear protection when cutting or gouging, unless sound pressure level measurements taken at the site have verified personal hearing protection is not necessary per relevant international, regional, and local regulations.

Significant noise reduction can be obtained by adding simple engineering controls to cutting tables such as barriers or curtains positioned between the plasma arc and the workstation, and/or locating the workstation away from the plasma arc. Implement administrative controls in the workplace to restrict access and limit operator exposure time, and screen off noisy areas and/or take measures to reduce reverberation in cutting areas by putting up noise absorbers.

Use ear protectors if the noise is disruptive or if there is a risk of hearing damage after all other engineering and administrative controls have been implemented. If hearing protection is required, wear only approved personal protective equipment such as ear muffs or ear plugs with a noise reduction rating appropriate for the situation. Warn others near the cutting area of possible noise hazards. In addition, ear protection can prevent hot splatter from entering the ear.

DRY DUST COLLECTION INFORMATION

In some workplaces, dry dust can represent a potential explosion hazard.

The U.S. National Fire Protection Association's NFPA standard 68, "Explosion Protection by Deflagration Venting," provides requirements for the design, location, installation, maintenance, and use of devices and systems to vent combustion gases and pressures after any deflagration event. Consult with the manufacturer or installer of any dry dust collection system for applicable requirements before you install a new dry dust collection system or make significant changes in the process or materials used with an existing dry dust collection system.

Consult your local "Authority Having Jurisdiction" (AHJ) to determine whether any edition of NFPA standard 68 has been "adopted by reference" in your local building codes.

Refer to NFPA standard 68 for definitions and explanations of regulatory terms such as deflagration, AHJ, adopted by reference, the Kst value, deflagration index, and other terms.

Note 1 – Unless a site-specific evaluation has been completed that determines that none of the dust generated is combustible, then NFPA standard 68 requires the use of explosion vents. Design the explosion vent size and type to conform to the worst-case Kst value as described in Annex F of NFPA standard 68. NFPA standard 68 does not specifically identify plasma cutting or other thermal cutting processes as requiring deflagration venting systems, but it does apply these new requirements to all dry dust collection systems.

Note 2 – Users should consult and comply with all applicable national, state, and local regulations. Publications do not intend to urge action that is not in compliance with all applicable regulations and standards, and this manual may never be construed as doing so.

LASER RADIATION

Exposure to the laser beam from a laser pointer can result in serious eye injury. Avoid direct eye exposure.

On products that use a laser pointer for alignment, one of the following laser radiation labels has been applied on the product near where the laser beam exits the enclosure. The maximum output (mV), wavelength emitted (nm), and, if appropriate, pulse duration are also provided.



Additional laser safety instructions:

- Consult with an expert on local laser regulations. Laser safety training may be required.
- Do not allow untrained persons to operate the laser. Lasers can be dangerous in the hands of untrained users.
- Do not look into the laser aperture or beam at any time.
- Position the laser as instructed to avoid unintentional eye contact.
- Do not use the laser on reflective workpieces.
- Do not use optical tools to view or reflect the laser beam.
- Do not disassemble or remove the laser or aperture cover.
- Modifying the laser or product in any way can increase the risk of laser radiation.
- Use of adjustments or performance of procedures other than those specified in this manual may result in hazardous laser radiation exposure.
- Do not operate in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Use only laser parts and accessories that are recommended or provided by the manufacturer for your model.
- Repairs and servicing **must** be performed by qualified personnel.
- Do not remove or deface the laser safety label.

ADDITIONAL SAFETY INFORMATION


1. ANSI Standard Z49.1, Safety in Welding and Cutting, American Welding Society, 550 LeJeune Road, P.O. Box 351020, Miami, FL 33135
2. ANSI Standard Z49.2, Fire Prevention in the Use of Cutting and Welding Processes, American National Standards Institute, 1430 Broadway, New York, NY 10018
3. ANSI Standard Z87.1, Safe Practices for Occupation and Educational Eye and Face Protection, American National Standards Institute, 1430 Broadway, New York, NY 10018
4. AWS F4.1, Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances, American Welding Society, 550 LeJeune Road, P.O. Box 351040, Miami, FL 33135
5. AWS F5.2, Recommended Safe Practices for Plasma Arc Cutting, American Welding Society, 550 LeJeune Road, P.O. Box 351040, Miami, FL 33135
6. CGA Pamphlet P-1, Safe Handling of Compressed Gases in Cylinders, Compressed Gas Association, 1235 Jefferson Davis Highway, Arlington, VA 22202
7. CSA Standard W117.2, Code for Safety in Welding and Cutting, Canadian Standards Association Standard Sales, 178 Rexdale Boulevard, Rexdale, Ontario M9W 1R3, Canada
8. NFPA Standard 51B, Cutting and Welding Processes, National Fire Protection Association, 1 Batterymarch Park, Quincy, MA 02169-7471
9. NFPA Standard 70, National Electrical Code, National Fire Protection Association, 1 Batterymarch Park, Quincy, MA 02169-7471
10. OSHA, Safety and Health Standards, 29FR 1910 U.S. Government Printing Office, Washington, D.C. 20402
11. AWS Safety and Health Fact Sheets, American Welding Society, 550 LeJeune Road, P.O. Box 351040, Miami, FL 33135, www.aws.org/technical/facts/

Section 2

SPECIFICATIONS

In this section:

System description.....	2-3
General	2-3
Power supply.....	2-3
Ignition console.....	2-3
Gas console	2-3
Off-valve	2-3
Torch	2-3
Specifications	2-4
System gas requirements.....	2-4
Power supply.....	2-5
Ignition console – 078172.....	2-6
Torch lead junction box (Optional) – 078619.....	2-8
Gas console – 078532	2-9
Off-valve – 078534	2-10
Torch – 228521	2-11
IEC symbols	2-12
Symbols and Marks.....	2-13



System description

General

HyPerformance plasma systems are designed to cut a wide range of thicknesses of mild steel, stainless steel and aluminum.

Power supply

The power supply is a 260-amp, 150-VDC constant-current supply. It contains the circuitry to ignite a torch, a heat exchanger and pump to cool the torch. The power supply has a serial interface to provide communication with a CNC controller.

Ignition console

The ignition console uses a spark-gap assembly. The ignition console converts 120 VAC control voltage from the power supply into high-frequency and high-voltage pulses (9-10 kV) to break over the torch electrode-nozzle gap. The high-voltage, high-frequency signal is coupled to the cathode lead and pilot arc lead.

Gas console

The power switch located on the gas console is the main power switch for the system. Power may be present at all other components when it is in the ON (I) position. The gas console manages the selection and flow rate of all incoming gases. The gas console includes motor valves, solenoid valves, check valves and pressure transducers. The gas console also houses a relay PC board and a control PC board.

Off-valve

The off-valve consists of 5 solenoid valves, a manifold block and a wiring harness with connector. The assembly interfaces with the machine torch, the ignition console and the gas console.

Torch

The virtually dross-free cutting capacity of the torch is 38 mm (1.5 in) for HyDefinition cutting. The production pierce capacity is 38 mm (1.5 in) for mild steel, 32 mm (1.25 in) stainless steel and 25 mm (1 in) for aluminum. The maximum cutting capability (edge start) is 64 mm (2.5 in) for mild steel and stainless steel and 50 mm (2 in) for aluminum.

SPECIFICATIONS







Specifications

System gas requirements

Gas quality and pressure requirements			
Gas type	Quality	Pressure +/- 10%	Flow rate
O ₂ oxygen	99.5% pure Clean, dry, oil-free	793 kPa / 8 bar 115 psi	4250 l/h 150 scfh
N ₂ nitrogen	99.99% pure Clean, dry, oil-free	793 kPa / 8 bar 115 psi	11610 l/h 410 scfh
Air	* Clean, dry, oil-free per ISO 8573-1 Class 1.4.2	793 kPa / 8 bar 115 psi	11330 l/h 400 scfh
H35 argon-hydrogen	99.995% pure (H35 = 65% Argon, 35% Hydrogen)	793 kPa / 8 bar 115 psi	4250 l/h 150 scfh
F5 nitrogen-hydrogen	99.98% pure (F5 = 95% Nitrogen, 5% Hydrogen)	793 kPa / 8 bar 115 psi	4250 l/h 150 scfh
Ar argon	99.99% pure Clean, dry, oil-free	793 kPa / 8 bar 115 psi	4250 l/h 150 scfh

* ISO standard 8573-1 Class 1.4.2 requirements are:


- Particulates – no more than 100 particles per cubic meter of air at a Size of 0.1 to 0.5 microns in the largest dimension and 1 particle per cubic meter of air at a Size of 0.5 to 5.0 microns in the largest dimension.
- Water – the pressure dewpoint of the humidity must be less than or equal to 3° C (37.4° F).
- Oil – the concentration of oil can be no more than 0.1 mg per cubic meter of air.

	Mild steel		Stainless steel		Aluminum	
						
Gas types	Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas
Cutting 30 to 50 A	O ₂	O ₂	N ₂ & F5	N ₂	Air	Air
Cutting 80 A	O ₂	Air	F5	N ₂	–	–
Cutting 130 A	O ₂	Air	N ₂ & H35	N ₂	H35 & Air	N ₂ & Air
Cutting 200 A	O ₂	Air	N ₂ & H35	N ₂	N ₂ & H35	N ₂
Cutting 260 A	O ₂	Air	N ₂ & H35	N ₂ & Air	N ₂ & H35	N ₂ & Air

Power supply

General							
Maximum OCV (U_0)				311 VDC			
Maximum output current (I_2)				260 Amps			
Output voltage (U_2)				50 – 175 VDC			
Duty cycle rating (X)				100% @ 45.5 kw, 40° C (104° F)			
Ambient temperature/Duty cycle				Power supplies will operate between -10° C and +40° C (+14° and 104° F)			
Power factor (cosφ)				0.98 @ 260 ADC output			
Cooling				Forced air (Class F)			
Insulation				Class H			
Power supply part numbers		AC Voltage (U_1)	Phase	Frequency (Hz)	Amperage (I_1)	Regulatory approval	Power kVA (+/- 10%) ($U_1 \times I_1 \times 1.73$)
Without Hypernet	With Hypernet						
078554	078562	200/208	3	50/60	149/144	CSA	51.6
078555	078563	220	3	50/60	136	CSA	51.6
078556	078564	240	3	60	124	CSA	51.6
078557	078565	380*	3	50/60	79	CCC	51.6
078558	078566	400	3	50/60	75	CE/GOST-R	51.6
078605	078606	415	3	50/60	75	CE/GOST-R	51.6
078559	078567	440	3	50/60	68	CSA	51.6
078560	078568	480	3	60	62	CSA	51.6
078561	078569	600	3	60	50	CSA	51.6




* The 380 volt CCC regulatory approval only applies to 50 Hz operation




SPECIFICATIONS

Ignition console – 078172


- The ignition console may be mounted locally on the power supply (LHF) or remotely on the cutting table's bridge (RHF). See *Installation* section for details.
- Maximum cable length from the ignition console to the torch lifter station is 20 m (65 ft). Allow room to remove the top for servicing.
- The ignition console may be mounted horizontally or vertically.




LHF mounting (local)




RHF mounting (remote)



Horizontal mounting







Vertical mounting



SPECIFICATIONS


Torch lead junction box (Optional) – 078619

- The junction box provides increased installation flexibility by creating a break point in the leads between the ignition console and torch to facilitate easier replacement of torch leads in certain applications.
- Maximum combined lead length from the ignition console to the torch must be less than or equal to:
 - 20 m (65 feet) for HPR130XD / HPR260XD
 - 15 m (50 feet) for HPR400XD / HPR800XD



Gas console – 078532




- Maximum cable length from the power supply to the gas console is 75 m (250 ft).
- Maximum cable length from the gas console to the off-valve assembly is 20 m (65 ft).
- Mount the gas console on top of the power supply or near the CNC on the cutting table. Allow room to open the top for servicing.



SPECIFICATIONS

Off-valve – 078534




- Maximum cable length from the off-valve to the torch lifter station is 1.8 m (6 ft).
- Mount the off-valve assembly to the torch carriage on larger tables. On smaller tables it can be mounted to a bracket just above the bridge.
- The vent hole on the manifold must be kept clear at all times.



A - A


















Torch – 228521

- The outside diameter of the torch mounting sleeve is 50.8 mm (2.0 in).
- The minimum bend radius for the torch leads is 152.4 mm (6.0 in).



IEC symbols

The following symbols may appear on the power supply data plate, control labels, switches, LEDs, and LCD screen.

	Direct current (DC)		Power is ON
	Alternating current (AC)		Power is OFF
	Plasma torch cutting		An inverter-based power source, either 1-phase or 3-phase
	Plate metal cutting		Volt/amp curve, “drooping” characteristic
	Expanded metal cutting		Power is ON (LED)
	Gouging		System fault (LED)
	AC input power connection		Inlet gas pressure fault (LCD)
	The terminal for the external protective (earth) conductor		Missing or loose consumables (LCD)
			Power supply is out of temperature range (LCD)

Symbols and Marks

Your product may have one or more of the following markings on or near the data plate. Due to differences and conflicts in national regulations, not all marks are applied to every version of a product.



S mark

The S mark indicates that the power supply and torch are suitable for operations carried out in environments with increased hazard of electrical shock according to IEC 60974-1.



CSA mark

Products with a CSA mark meet the United States and Canadian regulations for product safety. The products were evaluated, tested, and certified by CSA-International. Alternatively, the product may have a mark by one of the other Nationally Recognized Testing Laboratories (NRTL) accredited in both the United States and Canada, such as Underwriters Laboratories, Incorporated (UL) or TÜV.



CE mark

The CE marking signifies the manufacturer's declaration of conformity to applicable European directives and standards. Only those versions of products with a CE marking located on or near the data plate have been tested for compliance with the European Low Voltage Directive and the European Electromagnetic Compatibility (EMC) Directive. EMC filters needed to comply with the European EMC Directive are incorporated within versions of the product with a CE marking.



Eurasian Customs Union (CU) mark

CE versions of products that include an EAC mark of conformity meet the product safety and EMC requirements for export to Russia, Belarus, and Kazakhstan.



GOST-TR mark

CE versions of products that include a GOST-TR mark of conformity meet the product safety and EMC requirements for export to the Russian Federation.



C-Tick mark

CE versions of products with a C-Tick mark comply with the EMC regulations required for sale in Australia and New Zealand.



CCC mark

The China Compulsory Certification (CCC) mark indicates that the product has been tested and found compliant with product safety regulations required for sale in China.



UkrSEPRO mark

The CE versions of products that include a UkrSEPRO mark of conformity meet the product safety and EMC requirements for export to the Ukraine.



Serbian AAA mark

CE versions of products that include a AAA Serbian mark meet the product safety and EMC requirements for export to Serbia.

Section 3

INSTALLATION

In this section:

Upon receipt	3-3
Claims.....	3-3
Installation requirements.....	3-3
Noise levels	3-3
Placement of system components.....	3-3
Torque specifications	3-3
Installation requirements.....	3-4
System components.....	3-5
Cables and hoses	3-5
Supply gas hoses.....	3-5
Customer-supplied power cable	3-5
Recommended grounding and shielding practices	3-6
Introduction	3-6
Types of grounding	3-6
Grounding practices.....	3-6
Grounding diagram	3-9
Placement of the power supply	3-11
Install the ignition console.....	3-12
Install the off-valve	3-14
Placement of the gas console.....	3-15
Power supply to ignition console leads	3-16
Pilot arc lead.....	3-16
Negative lead.....	3-16
Ignition console power cable.....	3-18
Ignition console coolant hoses.....	3-19
Power supply to gas console cables	3-20
Control cable.....	3-20
Power cable.....	3-20
Gas console to off-valve connections.....	3-22
Cable and gas hose assembly	3-22
Power supply to CNC interface cable	3-24
Optional multi-system CNC interface cable	3-24

INSTALLATION

Notes to CNC interface cable run list	3-25
Examples of output circuits	3-26
Examples of input circuits.....	3-27
Remote ON/OFF switch (provided by customer)	3-28
Torch lead assembly	3-29
Torch lead junction box (Optional).....	3-30
Install the junction box.....	3-31
Connect the leads	3-32
Work lead	3-36
Torch connections	3-37
Connect the torch to the torch lead assembly	3-37
Connect the torch to the quick-disconnect	3-41
Torch mounting and alignment	3-42
Torch lifter requirement	3-43
Hypernet.....	3-43
Power requirements	3-44
General	3-44
Line disconnect switch	3-45
Main power cable.....	3-45
Connect the power.....	3-46
Torch coolant requirements.....	3-47
Premixed coolant for standard operating temperatures	3-47
Custom Coolant mix for cold operating temperatures.....	3-48
Custom Coolant mix for hot operating temperatures.....	3-49
Water purity requirements	3-49
Fill the power supply with coolant.....	3-50
Gas requirements	3-51
Setting the supply regulators.....	3-51
Gas regulators.....	3-52
Supply gas plumbing	3-53
Connect the supply gases	3-54
Supply gas hoses	3-55

Upon receipt

- Verify that all system components on your order have been received. Contact your supplier if any items are missing.
- Inspect the system components for any physical damage that may have occurred during shipping. If there is evidence of damage, refer to *Claims*. All communications regarding claims must include the model number and serial number located on the rear of the power supply.

Claims

Claims for damage during shipment – If your unit was damaged during shipment, you must file a claim with the carrier. Hypertherm will furnish you with a copy of the bill of lading upon request. If you need additional assistance, call Customer Service listed in the front of this manual, or your authorized Hypertherm distributor.

Claims for defective or missing merchandise – If any of the merchandise is defective or missing, contact your supplier. If you need additional assistance, call Customer Service listed in the front of this manual, or your authorized Hypertherm distributor.

Installation requirements

All installation and service of the electrical and plumbing systems must conform to national and local electrical and plumbing codes. This work should be performed only by qualified, licensed personnel.

Direct any technical questions to the nearest Hypertherm Technical Service Department listed in the front of this manual, or your authorized Hypertherm distributor.

Noise levels


Acceptable noise levels as defined by national and local codes may be exceeded by this plasma system. Always wear proper ear protection when cutting or gouging. Any noise measurements taken are dependant on the specific environment in which the system is used. See also *Noise can damage hearing* in the *Safety* section of this manual. Specific information by product can be found in the Hypertherm downloads library at:

<https://www.hypertherm.com/Xnet/library/DocumentLibrary.jsp>

Select the product you are looking for from the Product Type drop down menu, choose “Regulatory” from the Category drop down menu, and choose “Acoustical Noise Data Sheets” from the Sub Category drop down menu. Hit Submit.


Placement of system components

- Place all system components in position prior to making electrical, gas, and interface connections. Use the diagram in this section for component-placement guidelines.
- Ground all system components to earth. See *Recommended grounding and shielding practices* in this section for details.
- To prevent leaks in the system, tighten all gas and water connections as shown below:



Torque specifications			
Gas or water hose size	kgf-cm	lbf-in	lbf-ft
Up to 10 mm (3/8 in)	8.6-9.8	75-85	6.25-7
12 mm (1/2 in)	41.5-55	360-480	30-40

Installation requirements



System components

- A** Power supply
- B** Ignition console
- C** Off-valve assembly
- D** Gas console
- E** Torch

Cables and hoses

- 1** Pilot arc lead
- 2** Negative lead
- 3** Ignition console power cable
- 4** Ignition console coolant hoses
- 5** Gas control cable
- 6** Gas power cable
- 7** Gas console to off-valve hose and lead assembly
- 8** CNC interface cable
- 9** Optional CNC interface cable for systems with multiple power supplies
- 10** Torch lead assembly
- 11** Work lead




Supply gas hoses

- 12** Oxygen
- 13** Nitrogen or argon
- 14** Air
- 15** Argon-hydrogen (H35) or nitrogen-hydrogen (F5)

Customer-supplied power cable

- 16** Main power cable

Recommended grounding and shielding practices

		<p>WARNING! ELECTRIC SHOCK CAN KILL</p>
	<p>Disconnect electrical power before performing any maintenance.</p> <p>All work requiring the removal of the plasma system cover must be performed by a qualified technician.</p> <p>See the <i>Safety</i> section of your manual for more safety precautions.</p>	

Introduction

This section describes practices for grounding and shielding to protect a plasma cutting system against radio frequency interference (RFI) and electromagnetic interference (EMI) (also called *noise*). It also describes the DC power ground and the service ground. The diagram at the end of this section shows these types of grounds in a plasma cutting system.

Note: The grounding practices in this section have been used on many installations with excellent results, and Hypertherm recommends that these practices be a routine part of the installation process. The actual methods used to implement these practices may vary from system to system, but should remain as consistent as possible. However, due to the variation in equipment and installations, these grounding practices may not succeed in every case to eliminate RFI/EMI noise issues.

Types of grounding

Service ground (also called safety ground or potential earth (PE) ground) is the grounding system that applies to the incoming line voltage. It prevents a shock hazard to any personnel from any of the equipment or the cutting table. It includes the service ground coming into the plasma system and other systems such as the CNC and the motor drives, as well as the supplemental ground rod connected to the cutting table. In the plasma circuits, the ground is carried from the plasma system chassis to the chassis of each separate console through the interconnecting cables.

DC power ground (also called cutting current ground) is the grounding system that completes the path of the cutting current from the torch back to the plasma system. It requires that the positive lead from the plasma system be firmly connected to the cutting table ground bus with a properly sized cable. It also requires that the slats, on which the workpiece rests, make firm contact with the table and the workpiece.

RFI and EMI grounding and shielding is the grounding system that limits the amount of electrical noise emitted by the plasma and motor drive systems. It also limits the amount of noise that is received by the CNC and other control and measurement circuits. The grounding practices described in this section mainly target RFI and EMI grounding and shielding.

Grounding Practices


1. Unless noted, use only 13.3 mm² (6 AWG) welding cables (047040) for the EMI ground cables shown on the diagram at the end of this section.
2. The cutting table is used for the common, or star, EMI ground point and should have threaded studs welded to the table with a copper bus bar mounted on them. A separate bus bar should be mounted on the gantry as close to each motor as possible. If there are motors at each end of the gantry, run a separate EMI ground

cable from the far motor to the gantry bus bar. The gantry bus bar should have a separate, heavy EMI ground cable 21.2 mm² (4 AWG; 047031) to the table bus bar. The EMI ground cables for the torch lifter and the RHF console must each run separately to the table ground bus.


3. A ground rod that meets all applicable local and national electrical codes must be installed within 6 m (20 ft) of the cutting table. This is a PE ground and should be connected to the cutting table ground bus bar using 13.3 mm² (6 AWG) green and yellow grounding cable (047121) or equivalent.
4. For the most effective shielding, use the Hypertherm CNC interface cables for I/O signals, serial communication signals, between plasma systems in multi-drop connections, and for interconnections between all parts of the Hypertherm system.
5. All hardware used in the ground system must be brass or copper. While you can use steel studs welded to the cutting table for mounting the ground bus, no other aluminum or steel hardware can be used in the ground system.
6. AC power, PE, and service grounds must be connected to all equipment according to local and national codes.
7. For a system with a remote high frequency console (RHF), the positive, negative, and pilot arc leads should be bundled together for as long a distance as possible. The torch lead, work lead, and the pilot arc (nozzle) leads may be run parallel to other wires or cables only if they are separated by at least 150 mm (6 inches). If possible, run power and signal cables in separate cable tracks.
8. For a system with an RHF console, the ignition console should be mounted as closely as possible to the torch, and must have a separate ground cable that connects directly to the cutting table ground bus bar.
9. Each Hypertherm component, as well as any other CNC or motor drive cabinet or enclosure, must have a separate ground cable to the common (star) ground on the table. This includes the ignition console, whether it is bolted to the plasma system or to the cutting table.
10. The metal braided shield on the torch lead must be connected firmly to the ignition console and to the torch. It must be electrically insulated from any metal and from any contact with the floor or building. The torch lead can be run in a plastic cable tray or track, or covered with a plastic or leather sheath.
11. The torch holder and the torch breakaway mechanism – the part mounted to the lifter, not the part mounted to the torch – must be connected to the stationary part of the lifter with copper braid at least 12.7 mm (0.5 inches) wide. A separate cable must run from the lifter to the gantry ground bus bar. The valve assembly should also have a separate ground connection to the gantry ground bus bar.
12. If the gantry runs on rails that are not welded to the table, then each rail must be connected with a ground cable from the end of the rail to the table. The rail ground cables connect directly to the table and do not need to connect to the table ground bus bar.
13. If you are installing a voltage divider board, mount it as closely as possible to where the arc voltage is sampled. One recommended location is inside the plasma system enclosure. If a Hypertherm voltage divider board is used, the output signal is isolated from all other circuits. The processed signal should be run in twisted shielded cable (Belden 1800F or equivalent). Use a cable with a braided shield, not a foil shield. Connect the shield to the chassis of the plasma system and leave it unconnected at the other end.
14. All other signals (analog, digital, serial, and encoder) should run in twisted pairs inside a shielded cable. Connectors on these cables should have a metal housing. The shield, not the drain, should be connected to the metal housing of the connector at each end of the cable. Never run the shield or the drain through the connector on any of the pins.

INSTALLATION

The following picture shows an example of a cutting table ground bus. The components shown here may differ from your system.




The following picture shows an example of a gantry ground bus. It is bolted to the gantry, close to the motor. All of the individual ground cables from the components mounted on the gantry connect to the bus. A single heavy cable then connects the gantry ground bus to the table ground bus.



Grounding diagram

The following diagram shows an example of grounding the components in a plasma cutting system.



- 1** Cutting table
- 2** Gantry
- 3** Plasma system
- 4** Table ground bus bar
- 5** Gantry ground bus bar
- 6** Torch height control lifter (ArcGlide®, Sensor™ THC, Sensor PHC, or other)
- 7** RHF console (not on all systems). Connect to table ground bus bar.


- 8, 9** System-specific component such as metering console, gas console, or selection console
- 10** CNC chassis
- 11** Torch height control module (ArcGlide, Command® THC)
- 12** System-specific component such as a cooler or chiller
- 13** DC power ground

A Placement of the power supply

		<p style="text-align: center;">DANGER ELECTRIC SHOCK CAN KILL</p>
<p>Remove all electrical connections to the power supply before moving or positioning. Transporting the unit can cause personal injury and equipment damage.</p>		




The power supply can be moved by forklift but the forks must be long enough to extend the entire length of the base. Take care when lifting so that the underside of the power supply is not damaged. The forks must also be centered front to back and side to side to prevent tipping while moving. Fork lift speeds should be kept to a minimum, especially when making a turn or going around a corner.

- Place the power supply in an area that is free of excessive moisture, has proper ventilation and is relatively clean. Allow 1 m (3 ft) of space on all sides of the power supply for ventilation and service.
- Cooling air is drawn in through the front panel and is exhausted through the rear of the unit by a cooling fan. Do not place any filter device over the air intake locations, which reduces cooling efficiency and **VOIDS THE WARRANTY**.
- Do not place the power supply on an incline greater than 10° to prevent it from toppling.








B Install the ignition console

- Mount the ignition console on the gantry (bridge) for the RHF configuration.
- Mount the ignition console on the power supply for the LHF configuration.
- Allow room to remove the top for servicing.





Ignition console grounding



**Horizontal RHF mounting****Vertical RHF mounting****LHF mounting**

C Install the off-valve

- Mount the off-valve assembly near the torch lifter station. The maximum length of the gas hoses between the off-valve assembly and the torch is 1.8 m (6 ft).




Off-valve grounding





D Placement of the gas console


- Mount the gas console near the cutting table. Allow room to remove the top and right side cover for servicing. Preferred orientation is shown in the figure below. The maximum length of cables between the power supply and gas console is 75 m (250 ft). The maximum length of cables and hoses between the gas console and the off-valve assembly is 20 m (65 ft).



Preferred gas console orientation




Gas console grounding




Power supply to ignition console leads

1 Pilot arc lead




Part no.	Length	Part no.	Length
123683*	1.5 m (5 ft)	123823	20 m (65 ft)
123820	3 m (10 ft)	123735	25 m (82 ft)
123821	4.5 m (15 ft)	123668	35 m (115 ft)
123666	7.5 m (25 ft)	123669	45 m (150 ft)
123822	10 m (35 ft)	123824	60 m (200 ft)
123667	15 m (50 ft)	123825	75 m (250 ft)




2 Negative lead




Part no.	Length	Part no.	Length
123829*	1.5 m (5 ft)	123819	20 m (65 ft)
123816	3 m (10 ft)	123775	25 m (82 ft)
123817	4.5 m (15 ft)	123776	35 m (115 ft)
123773	7.5 m (25 ft)	123777	45 m (150 ft)
123818	10 m (35 ft)	123778	60 m (200 ft)
123774	15 m (50 ft)	123779	75 m (250 ft)

* Cable numbers 123683 and 123829 are for use with systems that have the ignition console mounted on the power supply






3 Ignition console power cable



Part no.	Length	Part no.	Length
123865*	2.1 m (7 ft)	123836	20 m (65 ft)
123419	3 m (10 ft)	123425	22.5 m (75 ft)
123834	4.5 m (15 ft)	123736	25 m (82 ft)
123420	6 m (20 ft)	123426	30 m (100 ft)
123670	7.5 m (25 ft)	123672	35 m (115 ft)
123422	9 m (30 ft)	123938	37.5 m (125 ft)
123835	10 m (35 ft)	123673	45 m (150 ft)
123423	12 m (40 ft)	123837	60 m (200 ft)
123671	15 m (50 ft)	123838	75 m (250 ft)



Cable signal list – power supply to ignition console		
Power supply end		Ignition console end
Pin No.	Description	Pin No.
1	120 Vac-hot	1
2	120 Vac-return	2
3	Ground	3
4	Not used	4

* Cable number 123865 is for use with systems that have the ignition console mounted on the power supply




4 Ignition console coolant hoses

Caution: Never use PTFE tape on any joint preparation.




Part no.	Length	Part no.	Length
228031*	0.7 m (2.5 ft)	128984	20 m (65 ft)
028652	3 m (10 ft)	128078	25 m (85 ft)
028440	4.5 m (15 ft)	028896	35 m (115 ft)
028441	7.5 m (25 ft)	028445	45 m (150 ft)
128173	10 m (35 ft)	028637	60 m (200 ft)
028442	15 m (50 ft)	128985	75 m (250 ft)

* Hose set number 228031 is for use with systems that have the ignition console mounted on the power supply



Power supply to gas console cables

5 Control cable



Part no.	Length	Part no.	Length
123784*	3 m (10 ft)	123841	20 m (65 ft)
123839	4.5 m (15 ft)	123737	25 m (82 ft)
123963	6 m (20 ft)	123738	35 m (115 ft)
123691	7.5 m (25 ft)	123739	45 m (150 ft)
123840	10 m (35 ft)	123842	60 m (200 ft)
123711	15 m (50 ft)	123843	75 m (250 ft)

Cable signal list – power supply to gas console					
Power supply end			Gas console end		
Pin No.	Input/Output	Description	Pin No.	Input/Output	Function
1		Not used	1		Not used
6		Not used	6		Not used
2	Input/Output	CAN L	2	Input/Output	CAN serial communication
7	Input/Output	CAN H	7	Input/Output	CAN serial communication
3		CAN ground	3		CAN ground reference
9		Not used	9		Not used
8		Not used	8		Not used
4		Not used	4		Not used
5		Not used	5		Not used





6 Power cable



Part no.	Length	Part no.	Length
123785*	3 m (10 ft)	123848	20 m (65 ft)
123846	4.5 m (15 ft)	123740	25 m (82 ft)
123964	6 m (20 ft)	123676	35 m (115 ft)
123674	7.5 m (25 ft)	123677	45 m (150 ft)
123847	10 m (35 ft)	123849	60 m (200 ft)
123675	15 m (50 ft)	123850	75 m (250 ft)

Cable signal list – power supply to gas console		
Power supply end		Gas console end
Pin No.	Description	Pin No.
1	120 Vac-hot	1
2	120 Vac-return	2
3	Ground	3
4	Not used	4
5	Not used	5
6	24 Vac-hot	6
7	24 Vac-return	7

* Cable numbers 123784 and 123785 are for use with systems that have the gas console mounted on the power supply




Gas console to off-valve connections

7 Cable and gas hose assembly

Part no.	Length	Part no.	Length
128989	3 m (10 ft)	128967	10 m (35 ft)
128990	4.5 m (15 ft)	128786	15 m (50 ft)
228339	6 m (20 ft)	128991	20 m (65 ft)
128782	7.5 m (25 ft)	228864	25 m (82 ft)

Female end at off-valve


Male end at gas console



Gas console to off-valve cable


Cable signal list – gas console to off-valve cable		
Gas console end		Off-valve end
Pin No.	Description	Pin No.
1	120 Vac Hot – Shield preflow	1
2	120 Vac Return – Shield preflow	2
3	120 Vac Hot – Shield cutflow	3
4	120 Vac Return – Shield cutflow	4
5	120 Vac Hot – Plasma preflow	5
6	120 Vac Return – Plasma preflow	6
7	120 Vac Hot – Plasma cutflow	7
8	120 Vac Return – Plasma cutflow	8
9	120 Vac Hot – Plasma vent	9
10	120 Vac Return – Plasma vent	10
11	Ground	11

Off-valve cable



Cable signal list – off-valve cable			
Description	End B	Color	End A
Shield	S	Red/black	1
Preflow	P	Red	2
Shield	S	Red/black	3
Cutflow	C	Red	4
Plasma	P	Red/black	5
Preflow	P	Red	6
Plasma	P	Red/black	7
cutflow	C	Red	8
Vent	V	Red/black	9
	V	Red	10
Ground	Gnd	Green/Yellow	11
	Gnd		12
	Gnd		13
	Gnd		14

Caution: Never use PTFE tape on any joint preparation.




INSTALLATION

8 Power supply to CNC interface cable

Part no.	Length	Part no.	Length	Part no.	Length
123210	3 m (10 ft)	123216	13.5 m (45 ft)	123742	35 m (115 ft)
123211	4.5 m (15 ft)	123023	15 m (50 ft)	123219	37.5 m (125 ft)
123212	6 m (20 ft)	123494	16.5 m (55 ft)	123220	45 m (150 ft)
123022	7.5 m (25 ft)	123851	20 m (65 ft)	123852	60 m (200 ft)
123213	9 m (30 ft)	123217	22.5 m (75 ft)	123853	75 m (250 ft)
123214	10 m (35 ft)	123741	25 m (82 ft)		
123215	12 m (40 ft)	123218	30 m (100 ft)		

9 Optional multi-system CNC interface cable (see schematics for installation information)

Power supply end					CNC end	
Wire color	Pin #	Input/Output	Signal name	Function	Input/Output	Notes
Black	1	Input	Rx –	RS-422 serial receiver	Output	
Red	20	Input	Rx +	RS-422 serial receiver	Output	
Black	2	Output	Tx –	RS-422 serial transmitter	Input	
Green	21	Output	Tx +	RS-422 serial transmitter	Input	
Black	3		RS-422 ground	RS-422 serial ground		
Blue	22		None	Not used		
Black	4	Output	Motion 1 E (–)	Notifies the CNC that an arc transfer has occurred and to begin machine motion once the CNC's pierce delay has timed out.	Input	2 & 3
Yellow	23	Output	Motion 1 C (+)		Input	
Black	5	Output	Error E (–)	Notifies the CNC that an error has occurred	Input	2
Brown	24	Output	Error C (+)		Input	
Black	6	Output	Rampdown error E (–)	Notifies the CNC that a rampdown error has occurred	Input	2
Orange	25	Output	Rampdown error C (+)			
Red	7	Output	Not ready E (–)	Notifies the CNC that the plasma system is not ready to fire an arc	Input	2
White	26	Output	Not ready C (+)			
Red	8	Output	Motion 2 E (–)	Notifies the CNC that an arc transfer has occurred and to begin machine motion once the CNC's pierce delay has timed out	Input	2 & 3
Green	27	Output	Motion 2 C (+)		Input	
Red	9	Output	Motion 3 E (–)	Notifies the CNC that an arc transfer has occurred and to begin machine motion once the CNC's pierce delay has timed out	Input	2 & 3
Blue	28	Output	Motion 3 C (+)		Input	
Red	10	Output	Motion 4 E (–)	Notifies the CNC that an arc transfer has occurred and to begin machine motion once the CNC's pierce delay has timed out	Input	2 & 3
Yellow	29	Output	Motion 4 C (+)		Input	
Red	11		None	Not used		
Brown	30		None	Not used		
Red	12	Input	Corner (–)	The CNC Notifies the plasma system that a corner is approaching and to reduce cut current (Cut current is CNC selectable or defaults to 50% of cut current)	Output	1
Orange	31	Input	Corner (+)		Output	
Green	13	Input	Pierce (–)	The CNC Notifies the plasma system to maintain the shield preflow until the CNC releases the signal	Output	1
White	32	Input	Pierce (+)			
Green	14	Input	Hold (–)	Not required without CommandTHC. CommandTHC requires signal to preflow gases during IHS	Output	1
Blue	33	Input	Hold (+)			
Green	15	Input	Start (–)	The CNC initiates the plasma arc	Output	1
Yellow	34	Input	Start (+)		Output	
Green	16		None	Not used		
Brown	35		None	Not used		
Green	17		None	Not used		
Orange	36		Power ground	Ground		
White	18		Power ground	Ground		4
Black	37		CNC +24 VDC	Available 24 VDC (200 milliamps maximum) see notes		
	19		CNC +24 VDC	Not connected		



Notes to CNC interface cable run list


- Note 1. Inputs are optically isolated. They require 24 VDC at 7.3 mA, or dry-contact closure. The external relay's life may be improved by adding a metallized-polyester capacitor ($0.022\mu\text{F}$ 100 V or higher) in parallel with the relay contacts.
- Note 2. Outputs are optically isolated, open collector, transistors. The maximum rating is 24 VDC at 10 mA.
- Note 3. Machine motion is selectable and is used for configurations with multiple plasma systems.
- Note 4.* CNC +24 VDC provides 24 VDC at 200 mA maximum. A jumper is required on J301 to use 24 V power.

Caution: The CNC cable must be constructed using cable with 360 degree shielding and metal housing connectors at each end. The shielding must be terminated to the metal housings at each end to ensure proper grounding and to provide the best shielding.


* See example 1 on page 3-27

Examples of output circuits


1. Logic interface, active-high




2. Logic interface, active-low



3. Relay interface




4. Do not use this configuration. Warranty will be void.




Examples of input circuits


1. Relay interface





2. Optocoupler interface




3. Amplified-output interface



Remote ON/OFF switch (provided by customer)


		<p>DANGER ELECTRIC SHOCK CAN KILL</p>
<p>Disconnect electrical power before performing any maintenance. See the <i>Safety Section</i> in this Manual for more safety precautions.</p>		

1. Locate terminal block 2 (TB2) in the power supply.




TB2 location

2. Remove wire 1 as shown and connect it to terminal 2.



3. Connect switch to terminals 1 and 2 as shown.




Note: Use a switch, relay or solid-state relay that is compatible with 24 VAC @ 100 mA. It must be a maintained-contact switch, not a momentary-contact switch.

Note: The main power switch on the gas console must be in the ON position for the remote switch to function.

10 Torch lead assembly


Part no.	Length
228291	2 m (6 ft)
228292	3 m (10 ft)
228293	4.5 m (15 ft)
228294	6 m (20 ft)
228295	7.5 m (25 ft)
228296	10 m (35 ft)
228297	15 m (50 ft)
228547	20 m (65 ft)



Torch lead junction box (Optional)

See the *Parts list* for part numbers


Caution: Total lead length from the ignition console to the torch must be less than or equal to:
20 m (65 feet) for HPR130XD / HPR260XD
15 m (50 feet) for HPR400XD / HPR800XD



1. Off-valve assembly
2. Ignition console
3. Junction box lead
4. Junction box
5. Junction box to torch lead

Install the junction box


1. Remove the cover from the junction box



2. Mount the junction box near the cutting location. (See *Specification* – for Junction box mounting dimensions)

Allow space to install and remove the cover of the box for servicing.

3. Ground the junction box to the bus bar on the cutting table or equivalent. See *Recommended grounding and shielding* in the *Installation* section in your system's instruction manual for more information.




Connect the leads

Do not overtighten the connections

Junction box to the ignition console

1. Connect one end of the junction box lead to the junction box.

The lead can go in either end of the junction box.




1 Coolant supply hose (green)

2 Coolant return hose (red)

3 Pilot arc lead (yellow)

2. Connect the other end of the junction box lead to the ignition console.



1 Coolant supply hose (green)


2 Coolant return hose (red)

3 Pilot arc lead (yellow)

INSTALLATION

Lead from the torch to the junction box

1. Connect the lead from the torch to the junction box.




1 Coolant supply hose (green)


2 Coolant return hose (red)

3 Pilot arc lead (yellow)

2. Install the junction box cover.




3. Connect the torch hoses to the off-valve assembly.








- 1 Off-valve assembly
- 2 Junction box
- 3 Plasma gas vent hose (white)
- 4 Plasma gas hose (black)
- 5 Shield hose (blue)

11 Work lead




Part no.	Length	Part no.	Length
123816	3 m (10 ft)	123775	25 m (82 ft)
123817	4.5 m (15 ft)	123776	35 m (115 ft)
123773	7.5 m (25 ft)	123777	45 m (150 ft)
123818	10 m (35 ft)	123778	60 m (200 ft)
123774	15 m (50 ft)	123779	75 m (250 ft)
123819	20 m (65 ft)		




E Torch connections

Connect the torch to the torch lead assembly


1. Uncoil the first 2 meters (6.5 ft) of the leads on a flat surface.





2. Hold the torch assembly in place with the spanner wrench (104269) and remove the mounting sleeve from the torch assembly.



3. Push back the braided cover and slide the sleeve over the leads. Align the torch with the hoses in the lead assembly. The hoses must not be twisted. They are taped together to help prevent twisting.




4. Connect the coolant return hose (red).



Caution: Never use PTFE tape on any joint preparation.


INSTALLATION

5. Connect the pilot arc lead (yellow). Insert the connector into the torch receptacle and turn it by hand until it is tight.




6. Connect the optional ohmic contact wire.

6a. Route the ohmic contact wire through the opening in the braided cover and the torch sleeve.




6b. Insert the connector into the torch receptacle and turn it by hand until it is tight.




Ohmic contact wire part numbers (Not part of the HPR260XD system. Shown for reference only)


Part no.	Length
123983	3 m (10 ft)
123984	6 m (20 ft)
123985	7.5 m (25 ft)
123986	9 m (30 ft)
123987	12 m (40 ft)
123988	15 m (50 ft)
123989	23 m (75 ft)
123990	30 m (100 ft)
123991	45 m (150 ft)




7. Connect the plasma-gas vent hose (white).




8. Connect the coolant supply hose (green).



9. Connect the plasma gas hose (black).




10. Connect the shield gas hose (blue).



Note: The connectors in steps 7–10 are push-to-connect fittings.

To make a connection, push the hose fitting into the appropriate connector until it stops, 13 mm (0.5 in.).




To disconnect a fitting, push the connector-collar toward the torch, and pull the hose away from the torch.




INSTALLATION


11. Slide the torch sleeve over the connections and screw it onto the torch assembly.



12. Slide the braided cover up to the torch sleeve. Make sure that the plasma, shield and vent hoses are routed through the hole in the braided cover. Loosen the hose clamp on the braided cover, slide the braided cover and clamp over the sleeve and tighten the clamp.




Connect the torch to the quick-disconnect




Installation note

Align the torch body to the torch leads and secure by screwing completely together. Be certain that there is no space between the torch body and the o-ring on the torch leads. See also *Torch connections* earlier in this section for torch lead connections to ignition console.



Torch mounting and alignment

Mounting the torch



Installation

1. Install the torch (with torch leads attached) in the torch mounting bracket.
2. Position the torch below the mounting bracket, so that the bracket is around the lower portion of the torch sleeve but not touching the torch quick-disconnect.
3. Tighten the securing screws.

Note: The bracket should be as low on the torch sleeve as possible to minimize vibration at the tip of the torch.

Torch alignment

To align the torch at right angles to the workpiece, use a square. See figure above.


Torch lifter requirement

The system requires a high-quality, motorized torch lifter with sufficient travel to cover all cutting thickness requirements. The lifter must provide 203 mm (8 in) of vertical travel. The unit should have the capability of maintaining a constant speed of up to 5080 mm/min (200 ipm) with positive braking. A unit which drifts through the stop point is not acceptable.

Hypernet

Hypernet is only used to connect certain Hypertherm components to each other. An HPRXD system can be connected to the ArcGlide® torch height control, and an EDGE® Pro or MicroEDGE® Pro CNC using an ethernet hub and cable. The Hypernet PCB provides communication between components and is the source for the arc voltage needed for the torch height control. See the ArcGlide instruction manual (806450), the EDGE Pro instruction manual (806360) or the MicroEDGE Pro CNC instruction manual (807290) for more information.

Note: The HPR130XD power supply is shown below, but the Hypernet interface board is in the same location in the HPR260XD power supply.



Power requirements

General

All switches, slow-blow fuses and power cables are customer-supplied and must be chosen as outlined by applicable national and local electrical codes. Installation must be performed by a licensed electrician. Use a separate, primary, line disconnect switch for the power supply. Recommendations on fuse and circuit breaker sizing are listed below, however actual sizes required will vary based on individual site electrical line conditions (including but not limited to source impedance, line impedance, and line voltage fluctuation), product inrush characteristics, and regulatory requirements.

The main feed protection device (Circuit Breaker or Fuse) must be sized to handle all branch-feed loads for both inrush and steady-state current. The power supply must be wired into one of the branch-feed circuits. The power supply has a steady-state current listed in the table below.

Use a motor-start circuit breaker or equivalent if time delay high inrush fuses are not permitted by local and national codes. Time delay fuses and circuit breakers must be capable of withstanding inrush current that is up to 30 times the rated input current (FLA) for 0.01 seconds and up to 12 times the rated input current (FLA) for 0.1 seconds.

Input voltage	Phase	Rated input current (FLA) @ 45.5 kW output	Recommended time delay, high inrush fuse size	Recommended Cable size for 15 m (50 ft) maximum length	
				Rated for 60° C (140° F)	Rated for 90° C (194° F)
200/208 VAC	3	149/144 amps	175 amps	N/A	67.5 mm ² (2/0 AWG)
220 VAC	3	136 amps	175 amps	N/A	67.5 mm ² (2/0 AWG)
240 VAC	3	124 amps	150 amps	107.2 mm ² (4/0 AWG)	53.5 mm ² (1/0 AWG)
380 VAC	3	79 amps	95 amps	42.4 mm ² (1 AWG)	26.7 mm ² (3 AWG)
400 VAC	3	75 amps	90 amps	42.4 mm ² (1 AWG)	26.7 mm ² (3 AWG)
415 VAC	3	75 amps	90 amps	42.4 mm ² (1 AWG)	26.7 mm ² (3 AWG)
440 VAC	3	68 amps	80 amps	42.4 mm ² (1 AWG)	21.2 mm ² (4 AWG)
480 VAC	3	62 amps	75 amps	33.6 mm ² (2 AWG)	21.2 mm ² (4 AWG)
600 VAC	3	50 amps	60 amps	26.7 mm ² (3 AWG)	13.3 mm ² (6 AWG)

Note: Cable AWG recommendations taken from table 310-16 of the National Electric Code handbook (USA).

Line disconnect switch

The line disconnect switch serves as the supply-voltage disconnecting (isolating) device. Install this switch near the power supply for easy access by the operator.

Installation must be performed by a licensed electrician and according to applicable national and local codes.



The switch should:


- Isolate the electrical equipment and disconnect all live conductors from the supply voltage when in the “OFF” position
- Have one “OFF” and one “ON” position clearly marked with “O” (OFF) and “I” (ON)
- Have an external operating handle capable of being locked in the “OFF” position
- Contain a power-operated mechanism that serves as an emergency stop
- Have slow-blow fuses installed for the proper breaking capacity (see table above).

16 Main power cable

Wire sizes vary based on the distance of the receptacle from the main box. The wire sizes listed in the table above were taken from the National Electric Code 1990 handbook, table 310.16 (USA). Use a 4-conductor Type SO input power cable with a conductor temperature rating of 60° C (140° F). Installation must be performed by a licensed electrician.

Connect the power

		<p>DANGER ELECTRIC SHOCK CAN KILL</p>
<p>The line disconnect switch must be in the OFF position before making the power cable connections. In the U.S., use a “lock-out/tag-out” procedure until installation is complete. In other countries, follow appropriate national and local safety procedures.</p>		

1. Insert the power cable through the strain relief at the rear of the power supply.
2. Connect the ground lead (PE) to the GROUND terminal () of TB1 as shown below.
3. Connect the power leads to the terminals of TB1 as shown below.
4. **Verify that the line disconnect switch is in the OFF position and remains in the OFF position for the remainder of the installation of the system.**
5. Connect the power cord leads to the line disconnect switch following national and local electrical codes.

North American wire colors

U = Black

V = White

W = Red

(PE) Earth ground = Green/Yellow


European wire colors

U = Black

V = Blue

W = Brown



(PE) Earth ground = Green/Yellow




Torch coolant requirements

The system is shipped without any coolant in the tank. Before filling the coolant system, determine what coolant mix is correct for your operating conditions.

Observe the warning and cautions below. Refer to the *Material Safety Data Sheets* appendix for data on safety, handling, and storage of propylene glycol and benzotriazole.

		<p style="text-align: center;">DANGER</p> <p style="text-align: center;">COOLANT CAN BE IRRITATING TO SKIN AND EYES AND HARMFUL OR FATAL IF SWALLOWED</p>
<p>Propylene glycol and benzotriazole are irritating to skin and eyes, and harmful or fatal if swallowed. Upon contact, flush skin or eyes with water. If swallowed, seek immediate medical attention.</p>		

	<p style="text-align: center;">CAUTION</p>
<p>Never use automotive anti-freeze in place of propylene glycol. Antifreeze contains corrosion inhibitors that will damage the torch coolant system.</p> <p>Always use purified water in the coolant mixture in order to prevent damage to the pump and corrosion in the torch coolant system.</p>	

Definitions


Ambient temperature – The temperature of the room in which the chiller is being used.

Premixed coolant for standard operating temperatures

Use Hypertherm premixed coolant (028872) when operating in an ambient temperature range of -12° C to 40° C (10° F to 104° F). Refer to the custom coolant mix recommendations, if temperatures during operation are ever outside of this range.

Hypertherm premixed coolant consists of 69.8% water, 30% propylene glycol, and 0.2% benzotriazole.

Custom Coolant mix for cold operating temperatures (below -12° C / 10° F)




CAUTION

For operating temperatures colder than the temperature stated above, the percentage of propylene glycol must be increased. Failure to do so could result in a cracked torch head, hoses, or other damage to the torch coolant system due to freezing.

Use the chart below to determine what percentage of propylene glycol to use in the mixture.

Mix 100% glycol (028873) with the premixed Hypertherm coolant (028872) to increase the percentage of glycol. The 100% glycol solution can also be mixed with purified water (see next page for water purity requirements) to achieve the required protection from freezing.

Note: The maximum percentage of glycol should never exceed 50%.



Freezing Point of Propylene Glycol Solution

Custom Coolant mix for hot operating temperatures (above 38° C / 100° F)

Treated water (with no propylene glycol) can only be used as coolant when ambient temperatures are **never** below 0° C (32° F). For operations in very warm temperatures, treated water will provide the best cooling properties.

Treated water refers to a mixture of purified water, that meets the specifications below, and 1 part benzotriazole (BZT) to 300 parts of water. BZT (128020) acts as a corrosion inhibitor for the copper based coolant system contained in the plasma system.

Water purity requirements

It is critical to maintain a low level of calcium carbonate in the coolant to avoid reduced performance of the torch or cooling system.

Always use water that meets the minimum and maximum specifications in the table below when using a custom coolant mix.

Water that does not meet the minimum purity specifications below can cause excessive deposits on the nozzle that will alter the water flow and produce an unstable arc.

Water that does not meet the maximum purity specifications below can also cause problems. Deionized water that is too pure will cause leaching problems with the coolant system plumbing.

Use water purified by any method (deionization, reverse osmosis, sand filters, water softeners, etc.) as long as the water purity meets the specifications in the table below. Contact a water specialist for advice in choosing a water filtration system.

	Water purity measurement method			
Water purity	Conductivity μS/cm at 25° C (77° F)	Resistivity mΩ-cm at 25° C (77° F)	Dissolved solids (ppm of NaCl)	Grains per gallon (gpg of CaCO ₂)
Pure water (for reference only)	0.055	18.3	0	0
Maximum purity	0.5	2	0.206	0.010
Minimum purity	18	0.054	8.5	0.43
Maximum potable water (for reference only)	1000	0.001	495	25

Fill the power supply with coolant

The system will take 11.4 – 15.1 liters (3 to 4 gallons) of coolant depending on the length of the torch leads and if the system has a local or remote ignition console.


Caution:




Using the wrong coolant can cause damage to the system. Refer to *torch coolant requirements* in this section for more information.

Do not over fill the coolant tank.


1. Add coolant to the power supply until the tank is full.




2. Press and hold the current selection knob (8) and press power switch on the gas console. The pump will run continuously while (8) is pressed.



3. The current display shows the flow rate. When the flow rate is constant and greater than 22.7 lpm (0.6 gpm), release the knob. The display will show the current again. The pump will continue to run.



4. Add coolant to the power supply until the tank is full and replace the filler cap.



Gas requirements

The customer must furnish all gases and gas-supply regulators for the system. Use a high-quality, 2-stage pressure regulator located within 3 m (10 ft) of the gas console. See *gas regulators* in this section for recommendations. See the *Specification* section for gas and flow specifications. See *Supply gas hoses* at the end of this section for recommendations.

Caution:




Gas supply pressures not within the specifications in Section 2 can cause poor cut quality, poor consumable life and operational problems.

If the purity level of the gas is too low or if there are leaks in the supply hoses or connections,


- Cut speeds can decrease
- Cut quality can deteriorate
- Cutting thickness capability can decrease
- Parts life can shorten

Setting the supply regulators


1. Turn OFF the power to the system. Set all gas regulator pressures to 8 bar (115 psi).



2. Turn ON the power to the system.



3. After the purge cycle stops, move switch (7) on the gas console to SET PREFLOW.




4. While gas is flowing adjust the supply regulator for the shield gas pressure to 8 bar (115 psi).

5. Move switch (7) back to the RUN position (center).



6. Move switch (7) to the CUTFLOW position (right position).



7. While gas is flowing adjust the supply regulator for the plasma gas to 8 bar (115 psi).

8. Move switch (7) to the RUN position.



INSTALLATION

Gas regulators

Low-quality gas regulators do not provide consistent supply pressures and can result in poor cut quality and system operation problems. Use a high-quality, 1-stage, gas regulator to maintain consistent gas supply pressure, if using liquid cryogenic or bulk storage. Use a high-quality, 2-stage, gas regulator to maintain consistent gas supply pressure from high pressure gas cylinders.

The high-quality gas regulators listed below are available from Hypertherm and meet U.S. Compressed Gas Association (CGA) specifications. In other countries, select gas regulators that conform to national or local codes.

2-stage regulator



Single stage regulator



Part Number	Description	Qty.
128544	Kit: Oxygen, 2-stage *	1
128545	Kit: Inert Gas, 2-stage	1
128546	Kit: Hydrogen (H5, H35 and methane) 2-stage	1
128547	Kit: Air, 2-stage	1
128548	Kit: 1-stage (for use with cryogenic liquid nitrogen or oxygen)	1
022037	Oxygen, 2-stage	1
022038	Inert gas, 2-stage	1
022039	Hydrogen/methane, 2-stage	3
022040	Air, 2-stage	1
022041	Line regulator, 1-stage	1

* Kits include appropriate fittings

Supply gas plumbing

Rigid copper plumbing or suitable flexible hose may be used for all gas supplies. Do not use steel or aluminum pipe. After installation, pressurize the entire system and check for leaks.

Recommended hose diameters are 9.5 mm (3/8 in) for lengths < 23 m (75 ft) and 12.5 mm (1/2 in) for lengths > 23 m (75 ft).

For flexible-hose systems, use a hose designed for inert gas to carry air, nitrogen or argon-hydrogen. See the last page of this section for hose part numbers.

Caution: Never use PTFE tape on any joint preparation.



Caution: When connecting the selection console to the supply gases, make sure that all hoses, hose connections and fittings are acceptable for use with oxygen and argon-hydrogen. Installation must be made in accordance with national and local codes.



Note: When cutting with oxygen as the plasma gas, air must also be connected to the selection console to achieve the proper mixtures in the preflow and cutflow modes.



WARNING

CUTTING WITH OXYGEN CAN CAUSE FIRE OR EXPLOSION

Cutting with oxygen as the plasma gas can cause a potential fire hazard due to the oxygen-enriched atmosphere that it creates. As a precaution, Hypertherm recommends that an exhaust ventilation system be installed when cutting with oxygen.

Flashback arrestors are required (unless not available for specific gases or required pressures) to prevent fire from propagating back to supply gas.

INSTALLATION


Connect the supply gases

Connect the supply gases to the gas console. Torch leads must be purged between gas changes.



Caution: Synthetic lubricants containing esters that are used in some air compressors will damage polycarbonates used in the air regulator bowl.

Fitting	Size
N ₂ / Ar	5/8 – 18, RH, internal (inert gas) “B”
Air	9/16 – 18, JIC, no. 6
H35 / F5	9/16 – 18, LH, (fuel gas) “B”
O ₂	9/16 – 18, RH, (oxygen) “B”





Caution: Replacing the fittings on the selection console may cause the internal valves to malfunction, because particulates can migrate into the valves.

Supply gas hoses

12 Oxygen hose



Caution: Never use PTFE tape on any joint preparation.




Part no.	Length	Part no.	Length
024607	3 m (10 ft)	024738	25 m (82 ft)
024204	4.5 m (15 ft)	024450	35 m (115 ft)
024205	7.5 m (25 ft)	024159	45 m (150 ft)
024760	10 m (35 ft)	024333	60 m (200 ft)
024155	15 m (50 ft)	024762	75 m (250 ft)
024761	20 m (65 ft)		

13 Nitrogen or argon hose




Part no.	Length	Part no.	Length
024210	3 m (10 ft)	024739	25 m (82 ft)
024203	4.5 m (15 ft)	024451	35 m (115 ft)
024134	7.5 m (25 ft)	024120	45 m (150 ft)
024211	10 m (35 ft)	024124	60 m (200 ft)
024112	15 m (50 ft)	024764	75 m (250 ft)
024763	20 m (65 ft)		

14 Air hose



Part no.	Length	Part no.	Length
024671	3 m (10 ft)	024740	25 m (82 ft)
024658	4.5 m (15 ft)	024744	35 m (115 ft)
024659	7.5 m (25 ft)	024678	45 m (150 ft)
024765	10 m (35 ft)	024680	60 m (200 ft)
024660	15 m (50 ft)	024767	75 m (250 ft)
024766	20 m (65 ft)		

15 Argon-hydrogen (H35) or nitrogen-hydrogen (F5)



Part no.	Length	Part no.	Length
024768	3 m (10 ft)	024741	25 m (82 ft)
024655	4.5 m (15 ft)	024742	35 m (115 ft)
024384	7.5 m (25 ft)	024743	45 m (150 ft)
024769	10 m (35 ft)	024771	60 m (200 ft)
024656	15 m (50 ft)	024772	75 m (250 ft)
024770	20 m (65 ft)		

Section 4

OPERATION

In this section:

Daily start-up.....	4-3
Check torch	4-3
Controls and indicators	4-4
General	4-4
Main power switch	4-4
Power indicators	4-4
Manual gas console operation.....	4-5
Consumable selection	4-6
Standard cutting (0°)	4-6
Bevel cutting (0° to 45°)	4-6
Marking	4-6
Consumables for mirror-image cutting.....	4-6
SilverPlus electrodes	4-6
Mild steel	4-7
Stainless steel	4-8
Aluminum	4-8
Mild steel bevel cutting	4-9
Mild steel, thick piercing, bevel cutting	4-9
Stainless steel bevel cutting	4-9
Install and inspect consumables	4-10
Install consumables.....	4-10
Inspect consumables.....	4-11
Torch maintenance	4-13
Routine maintenance	4-13
Quick-disconnect maintenance	4-13
Maintenance kit	4-13
Torch connections	4-14
Replace torch water tube.....	4-14
Common cutting faults	4-15
How to optimize cut quality	4-16
Tips for table and torch.....	4-16
Plasma set-up tips.....	4-16

Maximize the life of consumable parts..... 4-16

Additional factors of cut quality..... 4-17

Additional improvements 4-19

Cut charts..... 4-20

Thin stainless steel with HDi technology..... 4-20

 Overview..... 4-20

 Cut charts..... 4-20

Bevel cutting 4-21

 Cut charts..... 4-21

 Consumables 4-21

 Bevel compensation tables 4-21

 Bevel cutting definitions..... 4-22

Underwater cut charts 4-23

 Overview..... 4-23

 Cut charts..... 4-24

Estimated kerf-width compensation 4-25


Daily start-up

Prior to start-up, ensure that your cutting environment and that your clothing meet the safety requirements outlined in the *Safety* section of this manual.

Check torch

		DANGER ELECTRIC SHOCK CAN KILL
<p>Before operating this system, you must read the <i>Safety</i> section thoroughly. Turn OFF the power supply's main disconnect switch before proceeding with the following steps.</p>		


1. Turn main disconnect switch to the power supply OFF.
2. Remove the consumables from the torch and check for worn or damaged parts. **Always place the consumables on a clean, dry, oil-free surface after removing. Dirty consumables can cause the torch to malfunction.**
 - Refer to *Install and inspect consumables* later in this section for details and for parts inspection tables.
 - Refer to the *Cut charts* to choose the correct consumables for your cutting needs.
3. Replace consumable parts. Refer to *Install and inspect consumables parts* later in this section for details.
4. Ensure that the torch is perpendicular to the workpiece.




Controls and indicators

General

The main power switch for the HyPerformance plasma system is located on the gas console. There is no power switch on the power supply. The gas console controls all systems functions. Error codes are shown in the LED display over the current select knob.



Main power switch




On Position (I)

AC power is sent to the control transformer, to turn on the power supply.

Off Position (O)

AC power is cut off to the control transformer, to turn off the power supply.

Power indicators




AC Green Indicator:

Illuminates when the power switch is in the on position.

Manual gas console operation

The term “position number” refers to the numbers on the front panel of the gas console.



1. Turn ON the power.
2. Follow instructions below using the settings provided in the *Cut charts*.

Position #	Instruction
1	Select PLASMA GAS.
2	Select SHIELD GAS.
3, 4 & 7	Position switch (7) to SET PREFLOW (3-4). Set plasma preflow (3). Set shield preflow (4)
5, 6 & 7	Position switch (7) to SET CUTFLOW (5-6). Set plasma cutflow (5). Set shield cutflow (6).
7	Position switch (7) to RUN.
8	Position switch (8) to SET AMPS. Set amperage using knob above switch (8). Switch 8 can be in any position while operating.
	System is ready to cut.

* The 3-digit display is for reference. The current shown during cutting may vary by +/- 2 amps from the current shown when the amperage is set.

Consumable selection

Standard cutting (0°)

Most of the consumables on the following pages are designed for standard (straight) cutting, when the torch is perpendicular to the workpiece.

Bevel cutting (0° to 45°)

Consumables for 130 amp and 260 amp bevel cutting are specifically designed for bevel cutting. 400 amp consumables can be used for standard cutting and bevel cutting, but bevel-specific, 400 amp cut charts are provided for convenience.

Marking

Any of the consumable sets can also be used for marking with argon or nitrogen. Marking parameters are shown at the bottom of each cut chart. The quality of the marks will vary depending on the marking process, cut process, material type, material thickness, and material surface finish. For best mark quality, use the argon marking process settings. For all marking processes the depth of the mark can be increased by reducing the marking speed, or the depth can be decreased by increasing the marking speed. Argon marking currents can be increased by up to 30% to increase the depth of the mark. When marking with an argon process at 25 amps or greater, the process will start with air before changing to argon, and a thicker, darker mark will be seen at the start of the mark. When using the argon marking processes, mark and cut individual parts. Marking the entire nest prior to cutting may lead to reduced consumable life. For better results intersperse cuts and marks. Poor quality marking or burn-through may occur with material less than 1.5 mm (0.06 in. or 16 gauge).


Consumables for mirror-image cutting

See the *Parts List* section in this manual for part numbers.

SilverPlus electrodes

SilverPlus electrodes provide increased life when the average cut duration is short (< 60 seconds), and cut quality is not the most critical requirement. SilverPlus electrodes are available for 130 amp, 200 amp, and 260 amp mild steel O₂ / Air cutting. Part numbers can be found on the following page.

Mild steel



* SilverPlus electrodes are available for these processes.


Mild steel, 130 amp, O₂ / Air – 220665

Mild steel, 200 amp, O₂ / Air – 220666


Mild steel, 260 amp, O₂ / Air – 220668

OPERATION






















Stainless steel










Aluminum

















Mild steel bevel cutting

	Shield cap	Shield	Nozzle retaining cap	Nozzle	Swirl ring	Electrode	Water tube
80 A							
	220637	220742	220845	220806	220179	220802	220700
130 A							
	220637	220742	220740	220646	220179	220649	220700
260 A							
	220637	220741	220740	220542	220436	220541	220571



Mild steel, thick piercing, bevel cutting

260 A							
	220637	220897	220896	220898	220436	220899	220571

Stainless steel bevel cutting

	Shield cap	Shield	Nozzle retaining cap	Nozzle	Swirl ring	Electrode	Water tube
130 A							
	220637	220738	220739	220656	220179	220606	220571
260 A							
	220637	220738	220739	220607	220405	220606	220571


Install and Inspect consumables

		<h3>WARNING</h3>
<p>The system is designed to go into an idle mode if the retaining cap is removed. However, DO NOT CHANGE CONSUMABLE PARTS WHILE IN THE IDLE MODE. <u>Always</u> disconnect power to the power supply before inspecting or changing torch consumable parts. Use gloves when removing consumables. The torch might be hot.</p>		


Install consumables

Check the consumable parts daily for wear before cutting. Before removing consumables, bring the torch to the edge of the cutting table, with the torch lifter raised to its highest point to prevent the consumables from dropping into the water of the water table.

Note: Do not overtighten parts! Only tighten until mating parts are seated.




Apply a thin film of silicone lubricant on each o-ring. The o-ring should look shiny, but there should not be any excess or built-up grease.



Wipe the internal and external surfaces of the torch with a clean cloth or paper towel.


Tool: 104119




1. Install the electrode




2. Install the swirl ring




3. Install the nozzle and swirl ring



4. Install the nozzle retaining cap







5. Install the shield






6. Install the shield cap

Inspect consumables

Inspect	Look for	Action
Shield cap 	Erosion, missing material Cracks Burned surface	Replace shield cap Replace shield cap Replace shield cap
Shield 	General: Erosion or missing material Molten material attached Blocked gas holes Center hole: Must be round O-rings: Damage Lubricant	Replace shield Replace shield Replace shield Replace the shield when the hole is no longer round Replace shield Apply a thin film of silicone lubricant if the o-rings are dry
Nozzle retaining cap  <p>Insulating ring</p>	General: Damage to insulating ring Poor cut quality after replacing other consumables	Replace nozzle retaining cap Replace nozzle retaining cap
Nozzle Always replace the nozzle and electrode as a set. 	General: Erosion or missing material Blocked gas holes Center hole: Must be round Signs of arcing O-rings: Damage Lubricant	Replace nozzle Replace nozzle Replace the nozzle when the hole is no longer round Replace nozzle Replace nozzle Apply a thin film of silicone lubricant if the o-rings are dry

OPERATION

Inspect	Look for	Action
Swirl ring 	General: Chips or cracks Blocked gas holes Dirt or debris O-rings: Damage Lubricant	Replace swirl ring Replace swirl ring Clean and check for damage; replace when damaged Replace swirl ring Apply a thin film of silicone lubricant if the o-rings are dry
Electrode Always replace the nozzle and electrode as a set. 	Center surface: Emitter wear – a pit forms as the emitter wears. O-rings: Damage Lubricant	In general, replace the electrode when the pit depth is 1 mm (0.04 in.) or greater. For the 400 amp mild steel electrode and all SilverPlus electrodes, replace the electrode when the pit depth is 1.5 mm (0.06 in.) or greater. See Electrode pit depth gage below. Replace electrode Apply a thin film of silicone lubricant if the o-rings are dry



Electrode pit depth gage (004147)

Torch maintenance

Poor cut quality and premature failure may occur if the HPR torch is not maintained properly.


The torch is manufactured to very tight tolerances to maximize cut quality. The torch should not be subjected to hard impacts that can cause critical features to become misaligned.

The torch should be stored in a clean location when not in use, to avoid contamination of critical surfaces and passages.

Routine maintenance

The following steps should be completed each time consumables are changed:

1. Use a clean cloth to wipe off the torch inside and outside. A cotton swab can be used to access hard-to-reach internal surfaces.
2. Use compressed air to blow away any remaining dirt and debris from internal and external surfaces.
3. Apply a thin film of silicone lubricant on each external o-ring. The o-rings should look shiny, but there should not be any excess or built-up grease.
4. If consumables will be reused, use a clean cloth to wipe them off, and use compressed air to blow them off before they are installed again. This is especially critical for the nozzle retaining cap.





Front view of the torch

Quick-disconnect maintenance

The following steps should be completed every 5-10 times consumables are changed:

1. Remove the torch from the quick-disconnect assembly.
2. Use compressed air to blow off all internal surfaces and the external threads.
3. Use compressed air to blow off all internal surfaces at the rear of the torch.
4. Inspect each of the 5 o-rings at the rear of the torch for nicks or cuts. Replace any damaged o-rings. If they are not damaged, apply a thin film of silicone lubricant on each o-ring. The o-rings should look shiny, but there should not be any excess or built-up grease.




Rear view of the torch


Maintenance kit

Even with proper care, the o-rings at the rear of the torch will need to be replaced periodically. Hypertherm provides a kit (128879) of replacement parts. Kits should be kept in stock and be used as part of your routine maintenance schedule.

Torch connections



Torch



Torch quick-disconnect receptacle

Note: The coolant in and the coolant return lines in the quick-disconnect are in opposite positions from the torch coolant lines. This helps reduce the coolant temperature.

Replace torch water tube



WARNING

The system is designed to go into an idle mode if the retaining cap is removed. However, **DO NOT CHANGE CONSUMABLE PARTS WHILE IN THE IDLE MODE.** Always disconnect power to the power supply before inspecting or changing torch consumable parts. Use gloves when removing consumables. The torch might be hot.

Note: The water tube may seem loose when correctly inserted, but any side-to-side looseness will disappear after the electrode is installed.

1. Turn OFF all power to the system.
2. Remove consumables from torch. See *Install and inspect consumables* in this section.
3. Remove the old water tube.
4. Apply a thin film of silicone lubricant on the o-ring, and install a new water tube. The o-ring should look shiny, but there should not be any excess or built-up grease.
5. Replace consumables. See *Install and inspect consumables* in this section.



Common cutting faults


- Torch pilot arc will initiate, but will not transfer. Causes can be:
 1. Work cable connection on the cutting table is not making good contact.
 2. Malfunction in the system. See Section 5.
 3. Torch-to-work distance is too high.
- The workpiece is not totally penetrated, and there is excessive sparking on top of the workpiece. Causes can be:
 1. Current is set too low (check *Cut chart* information).
 2. Cut speed is too high (check *Cut chart* information).
 3. Torch parts are worn (see *Install and inspect consumables*).
 4. Metal being cut is too thick.
- Dross forms on the bottom of the cut. Causes can be:
 1. Cutting speed is not correct (check *Cut chart* information).
 2. Arc current is set too low (check *Cut chart* information).
 3. Torch parts are worn (see *Install and inspect consumables*).
- Cut angle is not square. Causes can be:
 1. Wrong direction of machine travel.
High-quality side is on the right with respect to the forward motion of the torch.
 2. Torch-to-work distance is not correct (check *Cut chart* information).
 3. Cutting speed is not correct (check *Cut chart* information).
 4. Arc current is not correct (check *Cut chart* information).
 5. Damaged consumable parts (see *Install and inspect consumables*).
- Short consumable life. Causes can be:
 1. Arc current, arc voltage, travel speed, motion delay, gas flow rates, or initial torch height not set as specified in the *Cut charts*.
 2. Attempting to cut highly magnetic metal plate, such as armor plate with a high nickel content, will shorten consumable life. Long consumable life is difficult to achieve when cutting plate that is magnetized or becomes magnetized easily.
 3. Beginning or ending the cut off the plate surface. **To achieve consumable long life, all cuts must begin and end on the plate surface.**

How to optimize cut quality

The following tips and procedures will help produce square, straight, smooth and dross-free cuts.

Tips for table and torch

- Use a square to align the torch at right angles to the workpiece.
- The torch may travel more smoothly if you clean, check and “tune” the rails and drive system on the cutting table. Unsteady machine motion can cause a regular, wavy pattern on the cut surface.
- The torch must not touch the workpiece during cutting. Contact can damage the shield and nozzle, and affect the cut surface.



Plasma set-up tips

Follow carefully each step in the *Daily start-up* procedure described earlier in this section.

Purge the gas lines before cutting.

Maximize the life of consumable parts

Hypertherm's LongLife® process automatically “ramps up” the gas and current flows at the start and ramps them down at the end of each cut, to minimize erosion of the electrode's center surface. The LongLife process also requires that cuts start and stop on the workpiece.

- The torch should never fire into the air.
 - Starting the cut at the edge of the workpiece is acceptable, as long as the arc is not fired in the air.
 - To start with a pierce, use a pierce height that is 1.5 to 2 times the torch-to-work distance. See *Cut charts*.
- Each cut should end with the arc still attached to the workpiece, to avoid arc blow-outs (ramp-down errors).
 - When cutting drop parts (small parts that drop down after being cut from the workpiece), check that the arc stays attached to the edge of the workpiece, for proper ramp-down.
- If arc blow-outs occur, try one or more of the following:
 - Reduce the cutting speed during the final part of the cut.
 - Stop the arc before the part is completely cut, to allow completion of the cut during the ramp-down.
 - Program the path of the torch into the scrap area for ramp-down.

Note: Use a “chain cut” if possible, so the path of the torch can lead directly from one cut part into the next, without stopping and starting the arc. However, do not allow the path to lead off the workpiece and back on, and remember that a chain cut of long duration will cause electrode wear.

Note: It may be difficult to achieve the full benefits of the LongLife process in some conditions.

Additional factors of cut quality


Cut angle

Note: The squarest cut angle will be on the right side with respect to the forward motion of the torch.

Note: To determine whether a cut-angle problem is being caused by the plasma system or the drive system, make a test cut and measure the angle of each side. Next, rotate the torch 90° in its holder and repeat the process. If the angles are the same in both tests, the problem is in the drive system.

If a cut-angle problem persists after “mechanical causes” have been eliminated (see *Tips for table and torch*, previous page), check the torch-to-work distance, especially if cut angles are all positive or all negative.

- A positive cut angle results when more material is removed from the top of the cut than from the bottom.
- A negative cut angle results when more material is removed from the bottom of the cut than from the top.



Dross

Low-speed dross forms when the torch's cutting speed is too slow and the arc shoots ahead. It forms as a heavy, bubbly deposit at the bottom of the cut and can be removed easily. Increase the speed to reduce the dross.

High-speed dross forms when the cutting speed is too fast and the arc lags behind. It forms as a thin, linear bead of solid metal attached very close to the cut. It is welded to the bottom of the cut and is difficult to remove. To reduce high-speed dross:

- Decrease the cutting speed.
- Decrease arc voltage, to decrease the torch-to-work distance.

Notes: Dross is more likely to form on warm or hot metal than on cool metal. For example, the first cut in a series of cuts will likely produce the least dross. As the workpiece heats up, more dross may form on subsequent cuts.

Dross is more likely to form on mild steel than on stainless steel or aluminum.

Worn or damaged consumables may produce intermittent dross.

Straightness of the cut surface



A typical plasma cut surface is slightly concave.

The cut surface may become more concave, or convex. Correct torch height is required to keep the cut surface acceptably close to straight.



A strongly concave cut surface occurs when the torch-to-work distance is too low. Increase the arc voltage to increase the torch-to-work distance and straighten the cut surface.



A convex cut surface occurs when the torch-to-work distance is too great or the cutting current is too high. First, reduce the arc voltage, then reduce the cutting current. If there is overlap between different cutting currents for that thickness, try the consumables designed for the lower current.

Additional improvements

Some of these improvements involve trade-offs, as described.

Piercing

The pierce delay should allow sufficient time to penetrate the full thickness of the material, but not so long that it allows the arc to “wander” while trying to find the edge of a large pierce hole. As consumables wear, this delay time may need to be increased. Pierce delay times given in the cut charts are based on average delay times throughout the life of the consumables.

Using the “pierce complete” signal during piercing maintains the shield-gas pressure at the higher preflow pressure, which provides additional protection for the consumables (for example: 30 amp O_2/O_2 and 50 amp O_2/O_2 processes). The pierce complete signal must be turned off for processes with shield gas preflow pressures that are lower than the cutflow pressures (for example: 600 amp and 800 amp processes).

When piercing materials close to the maximum thickness for a specific process, there are several important factors to consider:

- Allow a lead-in distance that is about the same as the thickness of the material being pierced. 50 mm (2 in) material requires a 50 mm lead-in.
- To avoid damage to the shield from the build up of molten material created by the pierce, do not allow the torch to descend to cut height until it has cleared the puddle of molten material.
- Different material chemistries can have an adverse effect on the pierce capability of the system. In particular, high-strength steel and steel with a high manganese or silicon content can reduce the maximum pierce capability. Hypertherm calculates mild steel pierce parameters with certified A-36 plate.
- If the system has difficulty piercing a specific material or thickness, increasing the shield preflow pressure can help in some cases.
Trade-off: This may reduce starting reliability.
- Using a “moving pierce” or “flying pierce” (starting torch motion immediately after transfer and during the pierce process) can extend the piercing capability of the system in some cases. Because this can be a complex process that can damage the torch, lifter, or other components, an edge start is recommended unless the operator is experienced with this technique.

How to increase cutting speed

- Decrease the torch-to-work distance.
Trade-off: This will increase the negative cut angle.

Note: The torch must not touch the workpiece while piercing or cutting.

Cut charts

The following *Cut charts* show the consumable parts, cutting speeds and the gas and torch settings required for each process.

The numbers shown in the *Cut charts* are recommended to provide high-quality cuts with minimal dross. Because of differences between installations and material composition, adjustments may be required to obtain desired results.

Thin stainless steel with HDi technology

Overview

The HPRXD family of plasma cutting systems offers a HyDefinition inox (HDi) 60 A cutting process for thin stainless steel that produces high quality cuts with minimal dross. Specifically, it enables operators to achieve:

- A sharp, top edge of the cut
- A shiny surface finish
- Good cut-edge angularity

You can use these 60 A stainless steel settings with your existing HPRXD system along with the following three new consumables:

- 220814 (nozzle retaining cap)
- 220815 (shield)
- 220847 (nozzle)

The cut charts and consumables for the 60 A stainless steel process can be used with both automatic and manual gas consoles.

Recommendations

Hypertherm develops stainless steel processes using SAE grade 304L. When cutting other grades of stainless steel, you may need to adjust the cut chart parameters to obtain optimal cut quality. In order to reduce the amount of dross, the first recommended adjustment is to adjust the cut speed. Dross can also be reduced by increasing the shield cut flow setting. Both of these adjustments may change the angle of the cut edge.

Cut charts

The HDi charts are listed by amperage with the other stainless steel cut charts.

Bevel cutting

Cut charts

The bevel cut charts are slightly different from the standard cut charts. The torch-to-work distance is a range rather than a single value, material thickness is given as an equivalent value, a column for minimum clearance has been added, and there is no column for arc voltage.

Equivalent thicknesses and the arc voltages will vary depending on the angle of the cut. The angle for bevel cutting can range from 0° to 45°.

Consumables

Bevel cutting processes use separate sets of consumables that are specially designed for bevel applications. These consumables have been optimized for PowerPierce™, which uses the tapered design to increase pierce capabilities.

See the *parts list* for mirror-image consumable part numbers.

Bevel compensation tables


Customers using bevel heads with an HPRXD plasma-cutting system are now able to use dynamic cut charts (or compensation tables) with compatible CNC and nesting software to achieve more accurate bevel cutting results with mild steel. These specialized cut charts enable operators to retrieve bevel cut settings that are specially tailored for making V cuts, A cuts, and Y Top cuts.

The bevel compensation tables require an HPRXD plasma-cutting system and are intended to be used for cutting mild steel. While these tables are built into Hypertherm's CNC software and nesting software, the information is available to all HPRXD customers and can be used with other compatible CNCs and nesting software programs. For technical details on how to use these compensation tables for mild steel bevel cutting, refer to the HPRXD *Bevel Compensation Cut Charts* white paper (part number 807830), which can be found in the "Downloads library" on the Hypertherm website at www.hypertherm.com.

See *Bevel cutting definitions* on the next page for more detailed information.

Bevel cutting definitions

Bevel angle	The angle between the center line of the torch and a line that is perpendicular to the workpiece. If the torch is perpendicular to the workpiece, the bevel angle is zero. The maximum bevel angle is 45°.
Nominal thickness	The vertical thickness of the workpiece.
Equivalent thickness	The length of the cut edge, or the distance the arc travels through the material while cutting. Equivalent thickness is equal to the nominal thickness divided by the cosine of the bevel angle. Equivalent thicknesses are listed in the cut chart.
Clearance	The vertical distance from the lowest point of the torch to the surface of the workpiece.
Torch-to-work distance	The linear distance from the center of the torch outlet to the workpiece surface along the torch center-line. A range of torch-to-work distances are listed in the cut chart. The smallest number is for a straight cut (bevel angle = 0°). The largest number is for a 45° bevel cut with a clearance of 3 mm (0.120 in).
Arc voltage	The arc voltage setting is dependent on the bevel angle and the setup of the cutting system. The arc voltage setting on one system may be different from a second system even if the workpiece is the same thickness. The arc voltages for bevel cutting are not supplied in the bevel cut charts.



Underwater cut charts

Overview

Hypertherm has developed underwater cut charts for 80 A, 130 A, 200 A, 260 A, and 400 A mild steel processes. These underwater cut charts are designed to produce optimal results for cutting mild steel up to 75 mm (3 inches) below the surface of the water.

Benefits and trade-offs

Underwater cutting can significantly reduce the level of noise and smoke generated by normal plasma cutting, as well as the glare of the plasma arc. Underwater operation provides the maximum possible noise suppression over the widest possible range of current levels. For example, you can expect noise levels to stay below 70 decibels for many processes when cutting up to 75 mm (3 inches) below the surface of the water. Operators can expect exact noise levels to vary depending on the table design and the cutting application being used.

However, underwater cutting can limit the visual and auditory signals that experienced operators may use while cutting to ensure they are getting a high quality cut and the cutting process is proceeding as it should. Underwater cutting can also affect the cut edge quality, resulting in a rougher surface finish with increased dross levels.

		<p style="text-align: center;">WARNING!</p> <p style="text-align: center;">Explosion hazard – underwater cutting with fuel gases or aluminum</p>
<p>Do not cut under water with fuel gases containing hydrogen. Do not cut aluminum alloys underwater or on a water table unless you can prevent the accumulation of hydrogen gas.</p> <p>Doing so can result in an explosive condition that can detonate during plasma cutting operations.</p>		

All underwater processes (80–400 A) use consumables that are designed for standard (straight) cutting, when the torch is perpendicular to the workpiece.

Requirements and restrictions

- These processes are specifically designed for cutting mild steel up to 75 mm (3 inches) below the surface of the water. Do not attempt to cut in water if the surface of the workpiece is deeper than 75 mm (3 inches).
- The True Hole™ process is not compatible with underwater cutting. If you are using a water table with the True Hole process, the water level should be at least 25 mm (1 inch) below the bottom surface of the workpiece.
- Preflow must be on during initial height sense (IHS) for all underwater cutting.
- Ohmic contact cannot be used for underwater cutting.

Operators should disable ohmic contact from the CNC. For example, if you are using a Hypertherm CNC and torch height control (THC) system, you can disable ohmic contact sensing by switching the Nozzle Contact IHS setting to OFF. The system then defaults to stall force sensing as a backup for torch height control.

The use of stall force sensing is not as accurate as ohmic contact sensing, so operators may need to optimize the stall force setting and/or the cut height setting (or torch-to-work distance) to compensate for possible workpiece deflection. That is, the stall force value should be set high enough to avoid false stall detection but not so high that the excess force causes a deflection of the workpiece and inaccurate IHS operation. In this example, the cut height value can be adjusted from the cut chart, while the stall force value can be adjusted from the THC setup parameters.

Refer to the instruction manuals for your Hypertherm CNC and THC systems for more details on setting the stall force threshold or on disabling ohmic contact. Alternative CNCs and THC systems can also be set up for underwater cutting.

Cut charts

The underwater cut charts are listed by amperage with the other mild steel cut charts.

Estimated kerf-width compensation

The widths in the chart below are for reference. Differences between installations and material composition may cause actual results to vary from those shown in the table.

Note: N/A = not available

Metric

Process	Thickness (mm)												
	1.5	3	5	6	8	10	12	15	20	25	32	38	50
Mild steel													
260A O ₂ / Air	N/A	N/A	N/A	2.54	2.54	2.54	2.79	3.43	3.56	3.91	4.32	4.45	5.72
200A O ₂ / Air	N/A	N/A	1.93	1.98	2.09	2.20	2.26	2.61	2.95	3.16	4.19	4.87	5.45
130A O ₂ / Air	N/A	1.64	1.77	1.81	1.92	2.04	2.11	2.22	2.65	3.43	4.26	4.59	N/A
80A O ₂ / Air	N/A	1.37	1.53	1.73	1.79	1.91	2.00	2.11	2.72	N/A	N/A	N/A	N/A
50A O ₂ / O ₂	1.52	1.74	1.86	1.86	2.09	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
30A O ₂ / O ₂	1.35	1.45	1.54	1.56	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Stainless steel													
260A N ₂ / Air	N/A	N/A	N/A	2.31	2.39	2.46	2.54	2.76	3.08	3.30	3.64	4.43	4.16
260A H35 / N ₂	N/A	N/A	N/A	N/A	3.84	3.83	3.81	3.81	4.06	4.32	4.53	4.70	7.46
200A N ₂ / N ₂	N/A	N/A	N/A	N/A	2.10	2.16	2.29	2.47	2.92	N/A	N/A	N/A	N/A
200A H35 / N ₂	N/A	N/A	N/A	N/A	3.66	3.68	3.81	3.68	3.94	N/A	N/A	N/A	N/A
130A H35 / N ₂	N/A	N/A	N/A	N/A	2.69	2.72	2.77	3.03	2.90	3.25	N/A	N/A	N/A
130A N ₂ / N ₂	N/A	N/A	N/A	1.83	1.89	1.88	2.42	2.51	3.00	N/A	N/A	N/A	N/A
80A F5 / N ₂	N/A	N/A	1.02	1.20	1.05	0.96	N/A	N/A	N/A	N/A	N/A	N/A	N/A
45A F5 / N ₂	0.59	0.38	0.52	0.54	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
45A N ₂ / N ₂	0.49	0.23	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Aluminum													
260A N ₂ / Air	N/A	N/A	N/A	2.49	2.73	2.97	3.05	2.91	3.05	3.30	2.87	3.99	5.66
260A H35 / N ₂	N/A	N/A	N/A	2.64	2.64	2.62	2.79	3.09	3.30	3.56	3.29	3.60	5.37
200A N ₂ / N ₂	N/A	N/A	N/A	N/A	1.78	2.03	2.58	2.54	3.01	N/A	N/A	N/A	N/A
200A H35 / N ₂	N/A	N/A	N/A	N/A	2.44	2.67	2.92	3.18	3.30	N/A	N/A	N/A	N/A
130A H35 / N ₂	N/A	N/A	N/A	N/A	2.70	2.72	2.77	2.36	2.90	1.72	N/A	N/A	N/A
130A Air / Air	N/A	N/A	N/A	2.09	2.09	2.10	2.19	1.91	1.87	2.23	N/A	N/A	N/A
45A Air / Air	1.07	1.10	1.25	1.25	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

Estimated kerf-width compensation – continued

English

Process	Thickness (in)														
	0.060	0.135	1/4	5/16	3/8	1/2	5/8	3/4	1.0	1-1/4	1-1/2	1-3/4	2.0	2-1/4	2-1/2
Mild steel															
260A O ₂ / Air	N/A	N/A	0.100	0.100	0.100	0.110	0.115	0.135	0.150	0.170	0.175	0.220	0.225	0.240	0.260
200A O ₂ / Air	N/A	N/A	0.078	0.082	0.086	0.089	0.108	0.116	0.125	0.164	0.192	N/A	0.216	N/A	N/A
130A O ₂ / Air	N/A	0.066	0.071	0.076	0.080	0.083	0.089	0.104	0.135	0.167	0.181	N/A	N/A	N/A	N/A
80A O ₂ / Air	N/A	0.054	0.068	0.070	0.075	0.080	0.084	0.102	N/A	N/A	N/A	N/A	N/A	N/A	N/A
50A O ₂ / O ₂	0.060	0.063	0.073	0.082	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
30A O ₂ / O ₂	0.053	0.057	0.067	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Stainless steel															
260A N ₂ / Air	N/A	N/A	0.091	0.094	0.100	0.100	0.120	0.120	0.130	0.142	0.175	0.223	0.155	N/A	N/A
260A H35 / N ₂	N/A	N/A	N/A	0.150	0.151	0.165	0.170	0.177	0.182	0.184	0.185	0.202	0.307	N/A	N/A
200A N ₂ / N ₂	N/A	N/A	N/A	0.083	0.085	0.090	0.100	0.115	N/A	N/A	N/A	N/A	N/A	N/A	N/A
200A H35 / N ₂	N/A	N/A	N/A	0.144	0.145	0.150	0.152	0.155	N/A	N/A	N/A	N/A	N/A	N/A	N/A
130A H35 / N ₂	N/A	N/A	N/A	0.115	0.121	0.123	0.124	0.125	0.129	N/A	N/A	N/A	N/A	N/A	N/A
130A N ₂ / N ₂	N/A	N/A	0.072	0.074	0.083	0.095	0.100	0.118	N/A	N/A	N/A	N/A	N/A	N/A	N/A
80A F5 / N ₂	N/A	0.032	0.047	0.050	0.052	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
45A F5 / N ₂	0.023	0.015	0.021	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
45A N ₂ / N ₂	0.019	0.009	0.006	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Aluminum															
260A N ₂ / Air	N/A	N/A	0.098	0.107	0.120	0.120	0.120	0.120	0.130	0.145	0.158	0.193	0.227	N/A	N/A
260A H35 / N ₂	N/A	N/A	0.104	0.104	0.105	0.110	0.126	0.130	0.140	0.141	0.142	0.222	0.210	N/A	N/A
200A N ₂ / N ₂	N/A	N/A	N/A	0.070	0.080	0.090	0.100	0.105	N/A	N/A	N/A	N/A	N/A	N/A	N/A
200A H35 / N ₂	N/A	N/A	N/A	0.096	0.105	0.115	0.125	0.130	N/A	N/A	N/A	N/A	N/A	N/A	N/A
130A H35 / N ₂	N/A	N/A	N/A	0.106	0.107	0.109	0.112	0.114	0.120	N/A	N/A	N/A	N/A	N/A	N/A
130A Air / Air	N/A	N/A	0.082	0.082	0.082	0.086	0.071	0.071	0.089	N/A	N/A	N/A	N/A	N/A	N/A
45A Air / Air	0.042	0.043	0.049	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A


Mild steel

O₂ Plasma / O₂ Shield

30 A

Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	46 / 97
Cutflow	22 / 46	0 / 0


Note: Air must be connected to use this process. It is used as the preflow gas.




220747



220194




220754




220193



220180



220192



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds	
O ₂	O ₂	80	15	92	15	0.5	114	1.3	5355	2.3	180	0.1	
						0.8	115		4225			0.2	
						1	116		3615			0.3	
						1.2	117		2865				
						1.5	119		2210				
			35		5	2	120	1.5	1490	2.7		0.4	
						2.5	122		1325				
						3*	123		1160				0.5
						4*	125		905				0.7
						6*	128		665				1.0

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds	
O ₂	O ₂	80	15	92	15	0.018	114	0.05	215	0.09	180	0.1	
						0.024			200				0.2
						0.030	115		170			0.3	
						0.036	116		155				
						0.048	117		110				
						0.060	119		85				
			35		5	0.075	120	0.06	60	0.11		0.4	
						0.105	122		50				
						0.135*	123		40				0.5
						3/16*	128		30				0.7
						1/4*			25				1.0

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	105
Ar	Air	90	10	90	10	9	2.5	0.10	2540	100	80


* Pierce complete is recommended for these thicknesses.

OPERATION

Mild steel O₂ Plasma / O₂ Shield 50 A

Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	43 / 90
Cutflow	25 / 52	0 / 0

Note: Air must be connected to use this process. It is used as the preflow gas.



Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds	
O ₂	O ₂	70	30	75	15	0.8	110	1.0	6500	2.0	200	0.0	
						1	111		5000				
						1.2	112		4150				
						1.5	114	1.3	3200	2.6		0.1	
						2	115		2700				
						2.5	117		2200				
						3	119	1.5	1800	3.0		0.2	
						4	121		1400				0.3
						5	122		1200				0.4
						6	126	2.0	950	4.0		0.5	
						7	128		780				
						8	130		630				

English


Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
O ₂	O ₂	70	30	75	15	0.030	110	0.04	270	0.08	200	0.0
						0.036			210			
						0.048			112			
						0.060	114	0.05	125	0.10		
						0.075	115		110			
						0.105	118		80			
						0.135	120	0.06	60	0.12		
						3/16	121		50			
						1/4	125	0.08	35	0.16		
						5/16	130		25			
											0.5	

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage	
						Amps						
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	118	
Ar	Air	90	10	90	10	9	2.5	0.10	2540	100	77	

Mild steel
O₂ Plasma / Air Shield
80 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	76 / 161
Cutflow	23 / 48	41 / 87




220747



220189




220756




220188



220179



220187



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
O ₂	Air	50	30	72	30	2	112	2.5	9810	3.8	150	0.1
						2.5	115		7980			
						3	117		6145			
						4	120	2.0	4300	4.0	200	0.2
						5	121		3670			
						6	123		3045			
						8	125		2430			0.3
						10	127		1810			0.4
						12	130		1410			0.5
					15	15	133		1030	5.0	250	0.7
						20	135		545			0.8
								2.5	545	6.3		0.9

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
O ₂	Air	50	30	72	30	0.075	112	0.10	400	0.15	150	0.1
						0.105	115		290			
						0.135	117		180			
						3/16	120	0.08	155	0.16	200	0.2
						1/4	123		110			
						5/16	125		96			
						3/8	127		75			0.3
						1/2	130		50			0.4
						5/8	133		37	0.20	250	0.5
					15	3/4	135		25			0.7
								0.10	25			0.8
										0.25		0.9

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	78


OPERATION

Mild steel bevel cutting

O₂ Plasma / Air Shield

80 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	47 / 100
Cutflow	23 / 48	47 / 100




220637



220742




220845




220806



220179



220802



220700

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time				
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds				
O ₂	Air	50	48	72	48	2.0	2	2.5 – 8.6	9810	3.8	150	0.1				
							2.5		7980							
							3		6145							
							4	2.0 – 8.6	4300	4.0	200	0.2				
							5		3670							
							6		3045			0.3				
							8		2430				0.4			
							10		1810			5.0		250	0.7	
							12		1410				0.8			
					15		1030		6.3						0.9	
					20		2.5 – 8.6	545								
					24											

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
O ₂	Air	50	48	72	48	0.08	0.075	0.1 – 0.34	400	0.15	150	0.1
							0.105		290			
							0.135		180			
							3/16	0.08 – 0.34	155	0.16	200	0.2
							1/4		110			
							5/16		96			0.3
							3/8		75			
							1/2		50	0.20	250	0.7
							5/8		37			
					3/4		0.1 – 0.34	25	0.25			0.9

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	78


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	76 / 161
Cutflow	23 / 48	41 / 87

Mild steel underwater cutting

No more than 75 mm (3 in) below the surface of the water

O₂ Plasma / Air Shield


80 A




220747



220189



220756



220188



220179



220187



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
O ₂	Air	50	30	72	30	4	116	2.0	3877	4.0	200	0.2
						5	118		3407			0.3
						6	122		2746			
						8	125		2162			0.4
						10	129		1639			0.5
					15	12	132		1271	5.0	250	0.7
						15	136		922			0.8


English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	inches	Volts	inches	ipm	inches	factor %	seconds
O ₂	Air	50	30	72	30	0.135	115	0.08	162	0.150	150	0.2
						3/16	117		140			
						1/4	123		99			0.3
						5/16	125		86			
						3/8	128		68			0.4
					15	1/2	133		45	0.20	250	0.5
						5/8	137		33			0.7
												0.8

OPERATION

Mild steel O₂ Plasma / Air Shield 130 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	102 / 215
Cutflow	33 / 70	45 / 96




220747



220183




220756




220182



220179



220181



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
O ₂	Air	35	40	80	35	3	124	2.5	6505	5.0	200	0.1
						4	126	2.8	5550	5.6		0.2
						5			4795			0.3
						6	127		4035			
			65	28	8	129	3.0	3360	6.0	7.6		0.3
					10	130		2680				
					12	132	3.3	2200	6.6			0.7
					15	135	3.8	1665	1.0			
					20	138		1050				
					25	141	4.0	550	190	1.8		
					32	160	4.5	375	Edge start			
					38	167		255				

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
O ₂	Air	35	40	80	35	0.135	124	0.100	240	0.200	200	0.1
						3/16	126	0.110	190	0.220		0.2
						1/4	127		150			0.3
					28	5/16	129	0.120	132	0.240		
			3/8			130	110		0.300			
			1/2			132	0.130	80		0.260		1.0
			5/8			135	0.150	60		190		
			3/4			138		45				
			1			141	0.160	20	Edge start			
			1-1/4			160	0.180	15				
			1-1/2		167	10						

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

Mild steel bevel cutting


O₂ Plasma / Air Shield

130 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	64 / 135
Cutflow	33 / 70	45 / 96



220637



220742




220740




220646



220179



220649



220700

Note: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds	
O ₂	Air	15	33	80	30	2.0	3	2.5 – 8.6	6505	5.0	200	0.1	
							4	2.8 – 8.6	5550	5.6		0.2	
							5		4795			0.3	
							6		4035				
							8	3.0 – 8.6	3360	6.0			
							10		2680				
			23	12	3.3 – 8.6		2200	6.6	200	0.5			
				15	3.8 – 8.6		1665	7.6		0.7			
				20			1050			1.0			
				25	4.0 – 8.6		550	10.2		1.8			
				32*	4.5 – 8.6		375			220		4.0	
				38			255	Edge start					

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds	
O ₂	Air	15	33	80	30	0.08	0.135	0.100 – 0.34	240	0.200	200	0.1	
							3/16	0.110 – 0.34	190	0.220		0.2	
					1/4		150		0.240			0.3	
					5/16		0.120 – 0.34	132		0.260			0.5
					3/8			110					
					1/2		0.130 – 0.34	80	0.300	1.0			
			5/8		0.150 – 0.34		60	190			1.8		
			3/4				45		220	4.0			
			1		0.160 – 0.34		20	Edge start					
			1-1/4*		0.180 – 0.34		15		Edge start				
			1-1/2				10						

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

* Suggestions for piercing 32 mm (1-1/4 in) mild steel: 1. Turn preflow on during IHS, 2. Use ohmic contact during IHS, 3. Use pierce complete when piercing.


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	102 / 215
Cutflow	33 / 70	45 / 96

Mild steel underwater cutting

No more than 75 mm (3 in) below the surface of the water

O₂ Plasma / Air Shield


130 A




220747



220183




220756




220182



220179



220181



220340

Metric


Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
O ₂	Air	32	32	84	28	5	127	2.8	4212	5.6	200	0.3
					22	8	129	3.0	2998	6.0		
						10	131		2412	6.6		0.5
						12	133	3.3	1980	7.6		0.7
						15	138	3.8	1497	7.6		

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	inches	Volts	inches	ipm	inches	factor %	seconds	
O ₂	Air	32	32	84	28	3/16	127	0.11	171	0.22	200	0.2	
						1/4	126		135			0.24	0.3
					22	5/16	129	0.12	119	0.26			
						3/8	130		99			0.30	0.7
						1/2	134	72	0.15	54			1.0
						5/8	140	41					
			52		3/4	144							

Mild steel
O₂ Plasma / Air Shield
200 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	128 / 270
Cutflow	39 / 82	48 / 101



220637



220761



220757




220354



220353



220352



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time		
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds		
O ₂	Air	24	65	69	28	5	123	3.3	5700	6.6	200	0.2		
						6	124		5250					
						8	125		4355					
						10	126		3460					
						12	128		3060					
						15	131	4.1	2275	8.2		10.2	0.3	
						20	133		1575					
						25	143	5.1	1165	10.2				0.5
						32	145		750					
						38	152		510					
						50	163		255					
											Edge start			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds	
O ₂	Air	24	65	69	28	3/16	124	0.13	230	0.26	200	0.2	
						1/4			200				
						5/16	125		171				0.3
						3/8	126		140				
						1/2	128		115				
						5/8	131	0.16	80	0.32		0.6	
						3/4	133		65				
						1	143	0.20	45	0.40			1.0
						1-1/4	145		30				
						1-1/2	152		20				
						2	163		10				
												Edge start	

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	130
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63


OPERATION

Mild steel bevel cutting

O₂ Plasma / Air Shield

200 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	114 / 240
Cutflow	43 / 90	49 / 102




220637



220658




220845




220659



220353



220662



220700

Note: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
O ₂	Air	25	62	90	49	2.0	5	3.3 – 8.4	5700	6.6	200	0.2
							6		5250			0.3
							8		4355			
							10		3460			
							12		3060			0.5
							15	4.1 – 8.4	2275	8.2	200	0.6
							20		1575			0.8
							25		1165			1.0
							32*	5.1 – 8.4	750	10.2	200	2.7
							38		510			Edge start
							50		255			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
O ₂	Air	25	62	90	49	0.08	3/16	0.13 – 0.33	230	0.26	200	0.2
							1/4		200			0.3
							5/16		171			
							3/8		140			
							1/2		115			0.5
							5/8	0.16 – 0.33	80	0.32	200	0.6
							3/4		65			0.8
							1		45			1.0
							1-1/4*	0.20 – 0.33	30	0.40	200	2.7
							1-1/2		20			Edge start
							2		10			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	124
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	61

* Suggestions for piercing 32 mm (1-1/4 in) mild steel: 1. Turn preflow on during IHS, 2. Use ohmic contact during IHS, 3. Use pierce complete when piercing.

Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	128 / 270
Cutflow	39 / 82	48 / 101


Mild steel underwater cutting

No more than 75 mm (3 in) below the surface of the water

O₂ Plasma / Air Shield

200 A


Preflow must be on during IHS.




220637



220761



220757




220354



220353



220352



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	Factor %	Seconds
O ₂	Air	24	65	69	28	8	126	3.3	3878	6.6	200	0.3
						10	127		3116			0.5
						12	129		2764			0.6
						15	133	4.1	2052	8.2		0.8


English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	inches	Volts	inches	ipm	inches	Factor %	Seconds
O ₂	Air	24	65	69	28	1/4	125	0.13	180	0.26	200	0.2
						5/16	126		154			0.3
						3/8	127		126			0.5
						1/2	129		104			0.6
						5/8	135	0.16	72	0.32		0.8
						3/4	137		59			


OPERATION

Mild steel O₂ Plasma / Air Shield 260 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	130 / 275
Cutflow	42 / 88	104 / 220




220637



220764




220760




220439



220436



220435



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
O ₂	Air	24	75	70	70	6	150	2.8	6500	8.5	300	0.3
						8			5470			
						10			4440			
						12			3850			0.4
				75	75	15	155	3.6	3130	9.0	250	0.5
						20	159		2170			0.6
						22	166		1930			0.7
						25	171		1685			0.8
				80	75	28	170	4.8	1445	9.5	200	0.9
						32	172		1135			1.0
						38	174		895			Edge start
						44	185		580			
						50	188		405			
						58	193		290			
						64	202		195			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
O ₂	Air	24	75	70	70	1/4	150	0.11	245	0.330	300	0.3
						5/16			215			
						3/8			180			
						1/2			145			0.4
				75	75	5/8	155	0.14	115	0.350	250	0.5
						3/4	159		90			0.6
						7/8	166		75			0.7
						1	171		65			0.8
				80	75	1-1/8	170	0.19	55	0.380	200	0.9
						1-1/4	172		45			1.0
						1-1/2	174		35			Edge start
						1-3/4	185		22			
						2	188		15			
						2-1/4	193		12			
						2-1/2	202		8			

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	135
Ar	Air	30	20	30	20	24	3.0	0.12	2540	100	68

Mild steel bevel cutting (standard)

O₂ Plasma / Air Shield

260 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	130 / 275
Cutflow	42 / 88	104 / 220



220637



220741



220740



220542



220436



220541



220571

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
O ₂	Air	24	75	70	70	2.0	6	2.8 – 7.6	6500	8.5	300	0.3
							8		5470			
							10		4440			
							12		3850			
				75	75		15	3.6 – 7.6	3130	9.0	250	0.5
							20		2170			0.6
							22		1930			0.7
							25		1685			0.8
				80	75		28	4.8 – 7.6	1445	9.5	200	0.9
							32		1135			1.0
							38*		895			2.0
							44		580			Edge start
							50		405			
							58		290			
							64		195			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
O ₂	Air	24	75	70	70	0.08	1/4	0.11 – 0.30	245	0.330	300	0.3
							5/16		215			
							3/8		180			
							1/2		145			0.4
				75	75		5/8	0.14 – 0.30	115	0.350	250	0.5
							3/4		90			0.6
							7/8		75			0.7
							1		65			0.8
				80	75		1-1/8	0.19 – 0.30	55	0.380	200	0.9
							1-1/4		45			1.0
							1-1/2*		35			2.0
							1-3/4		22			Edge start
							2		15			
							2-1/4		12			
							2-1/2		8			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	135
Ar	Air	30	20	30	20	24	3.0	0.12	2540	100	68


* See the alternate, thick metal piercing, cut chart if you have a problem with excessive slag on the shield or problems with the torch misfiring.

OPERATION

Mild steel bevel cutting (alternate) thick metal piercing

O₂ Plasma / Air Shield
260 A


Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	85 / 180
Cutflow	47 / 99	54 / 115




220637



220897




220896




220898



220436



220899



220571

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
O ₂	Air	24	32	64	31	2.0	25	3.6 – 7.6	1685	9.0	250	0.8
							28	4.8 – 7.6	1445	9.5	200	1.0
							32		1135			1.2
							38*		895			3.0
							44		580		Edge start	
							50		405			
							58		290			
							64		195			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
O ₂	Air	24	32	64	31	0.08	1	0.14 – 0.30	65	0.35	250	0.8
							1-1/8	0.19 – 0.30	55	0.38	200	1.0
							1-1/4		45			1.2
							1-1/2*		35			3.0
							1-3/4		22		Edge start	
							2		15			
							2-1/4		12			
							2-1/2		8			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	122
Ar	Air	30	20	30	20	24	3.0	0.12	2540	100	62

The consumables on this page are designed for thick metal piercing. They are only recommended for use if you have a problem with excessive slag on the shield, or problems with the torch misfiring, when using the standard bevel consumables.

Using the thick metal piercing process may result in a 20% decrease in the life of the consumables.

* Suggestions for piercing 38 mm (1-1/2 in) mild steel:

1. Turn preflow on during IHS
2. Use stall force during IHS
3. Use pierce complete when piercing

Flow rates – lpm/scfh		
	O ₂	Air
Preflow	0 / 0	130 / 275
Cutflow	42 / 88	104 / 220


Mild steel underwater cutting

No more than 75 mm (3 in) below the surface of the water

O₂ Plasma / Air Shield

260 A


Preflow must be on during IHS.



220637



220764



220760




220439



220436



220435



220340

Metric


Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	Factor %	Seconds
O ₂	Air	24	75	70	70	8	150	2.8	4889	8.4	300	0.3
						10			3997			
						12			3501			
				75	75	15	156	3.6	2830	9.0	250	0.5
						20	160		1958			0.6
						22	162		1750			0.7
						25	165		1527			0.8
				80	75	28	170	4.8	1311	9.6	200	0.9

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	inches	Volts	inches	ipm	inches	Factor %	Seconds
O ₂	Air	24	75	70	70	5/16	150	0.11	194	0.33	300	0.3
						3/8			162			
						1/2			131			
				75	75	5/8	157	0.14	104	0.35	250	0.5
						3/4	159		81			0.6
						7/8	162		68			0.7
						1	165		59			0.8
				80	75	1-1/8	171	0.19	50	0.38	200	0.9

Stainless steel N₂ Plasma / N₂ Shield 45 A


Flow rates – lpm/scfh	
	N ₂
Preflow	24 / 51
Cutflow	75 / 159



220747



220202




220755




220201



220180



220308



220340

Metric

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
N ₂	N ₂	35	5	55	60	0.8	94	2.5	6380	3.8	150	0.0
						1			5880			0.1
						1.2			5380			0.2
						1.5	95		4630			
						2	97		3935			
						2.5	101		3270			
						3	103		2550			
						4			1580			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
N ₂	N ₂	35	5	55	60	0.036	94	0.10	240	0.150	150	0.0
						0.048			210			0.1
						0.060	95		180			0.2
						0.075	97		160			
						0.105	101		120			
						0.135	103		75			0.3

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	85
Ar	Air	90	10	90	10	12	2.5	0.10	2540	100	65


Note: This process produces a darker cut edge than the 45 A, F5/N₂ stainless steel process.

Stainless steel

F5 Plasma / N₂ Shield

45 A


Flow rates – lpm/scfh		
	F5	N ₂
Preflow	0 / 0	43 / 91
Cutflow	8 / 17	65 / 138



220747



220202



220755




220201



220180



220308



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
F5	N ₂	35	25	55	60	0.8	99	2.5	6570	3.8	150	0.2
						1			5740			
						1.2			4905			
						1.5			3890			
						2	101		3175			
						2.5	102		2510			
						3	103		2010			
						4	104		1435			0.3
					15	6	110	2.0	845		190	0.5

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
F5	N ₂	35	25	55	60	0.036	99	0.10	240	0.150	150	0.2
						0.048			190			
						0.060			150			
						0.075	100		130			
						0.105	102		90			
						0.135	104		65			0.3
					15	3/16	108	0.08	45		190	0.4
						1/4	110		30			0.5

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	85
Ar	Air	90	10	90	10	12	2.5	0.10	2540	100	65


Note: This process produces a shinier cut edge than the 45 A, N₂/N₂ stainless steel process.

Stainless steel HDi

F5 Plasma / N₂ Shield

60 A


Flow rates – lpm/scfh		
	F5	N ₂
Preflow	0 / 0	76 / 160
Cutflow	20 / 42	58 / 122



220747



220815




220814



220847



220180



220339



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	Factor %	Seconds
F5	N ₂	70	48	84	41	3	114	2.0	2770	4.0	200	0.3
						4	117		2250			
						5	118		1955			
					51	6	120		1635			0.5

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	Factor %	Seconds
F5	N ₂	70	48	84	41	0.105	113	0.08	120	0.16	200	0.3
						0.135	116		95			
						3/16	118		80			
					51	1/4	120		60			0.5

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage	
						Amps						
N ₂	N ₂	10	10	10	10	15	2.5	0.1	6350	250	95	
Ar	N ₂	90	10	90	10	8	2.5	0.1	2540	100	82	

Stainless steel

F5 Plasma / N₂ Shield

80 A


Flow rates – lpm/scfh		
	F5	N ₂
Preflow	0 / 0	67 / 142
Cutflow	31 / 65	87 / 185



220747



220338



220755




220337



220179



220339



220340

Metric

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
F5	N ₂	35	30	60	75	4	108	3.0	2180	4.5	150	0.2
						5	110	2.7	1700	4.1		0.3
						6	112	2.5	1225	3.8		0.4
						8	116	3.0	895	4.5		0.5
						10	120		560			

English


Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
F5	N ₂	35	30	60	75	0.135	108	0.120	105	0.180	150	0.2
						3/16	110	0.110	60	0.170		0.3
						1/4	112	0.100	45	0.150		0.4
						5/16	116	0.120	35	0.180		0.5
						3/8	120		25			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	95
Ar	Air	50	10	50	10	12	3.0	0.12	2540	100	60

Stainless steel N₂ Plasma / N₂ Shield 130 A


Flow rates – lpm/scfh	
	N ₂
Preflow	97 / 205
Cutflow	79 / 168



220747



220198




220756



220197



220179



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
N ₂	N ₂	20	65	70	30	6	153	3.0	1960	6.0	200	0.3
						8	155		1630			0.4
						10	156		1300			0.5
						12	162	3.5	900	7.0	0.8	
						15	167	3.8	670	Edge start		
						20	176	4.3	305			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
N ₂	N ₂	20	65	70	30	1/4	153	0.120	75	0.240	200	0.3
						5/16	155		64			0.4
						3/8	156		55			0.5
						1/2	162	0.140	30	0.280	0.8	
						5/8	167	0.150	25	Edge start		
						3/4	176	0.170	15			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75


Note: This process produces a rougher, darker cut edge with more dross, and the cut edges are closer to perpendicular than the 130 A, H35/N₂ process.

Stainless steel

H35 Plasma / N₂ Shield

130 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	76 / 160
Cutflow	26 / 54	68 / 144



220747



220198




220755




220197



220179



220307



220340

Metric

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield	mm	Volts	mm	mm/m	mm	factor %	seconds
H35	N ₂	20	40	70	60	8	150	4.5	1140	7.7	170	0.3
						10	154		980			
					45	12	158		820			0.5
						30	15		162			
					20		165		360			1.3
					20		25		172			260

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time		
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds		
H35	N ₂	20	40	70	60	5/16	150	0.180	45	0.310	170	0.3		
						3/8	154		40					
					45	1/2	158		30				0.5	
					30	5/8	162		20					0.8
						3/4	165		15					
					20	1	172		10			Edge start		

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

Note: This process produces a smoother, shinier cut edge with less dross, and the cut edges are less perpendicular than the 130 A, N₂/N₂ process.

Stainless steel bevel cutting

N₂ Plasma / N₂ Shield

130 A

Flow rates – lpm/scfh	
N ₂	
Preflow	97 / 205
Cutflow	125 / 260



Note: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
N ₂	N ₂	20	65	70	80	2.0	6	3.0 – 10.0	1960	6.0	200	0.3
							8		1630			0.4
							10		1300			0.5
							12	3.5 – 10.0	900	7.0		0.8
							15	3.8 – 10.0	670	Edge start		
							20	4.3 – 10.0	305			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
N ₂	N ₂	20	65	70	80	0.08	1/4	0.12 – 0.40	75	0.240	200	0.3
							5/16		64			0.4
							3/8		55			0.5
							1/2	0.14 – 0.40	30	0.280	0.8	
							5/8	0.15 – 0.40	25	Edge start		
							3/4	0.17 – 0.40	15			

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

Stainless steel bevel cutting


H35 Plasma / N₂ Shield

130 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	90 / 190
Cutflow	26 / 54	114 / 240




220637



220738



220739




220656



220179



220606



220571

Note: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
H35	N ₂	20	40	70	80	2.0	8	4.5 – 10.0	1140	7.7	170	0.3
							10		980			0.5
							12		820			0.8
							15		580			1.3
							20		360			
							25		260		Edge start	

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
H35	N ₂	20	40	70	80	0.08	5/16	0.180 – 0.40	45	0.310	170	0.3
							3/8		40			0.5
							1/2		30			0.8
							5/8		20			1.3
							3/4		15			
							1		10		Edge start	


Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

Stainless steel

N₂ Plasma / N₂ Shield
200 A


Flow rates – lpm/scfh	
	N ₂
Preflow	111 / 235
Cutflow	137 / 290



220637



220762




220758



220343



220342



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
N ₂	N ₂	21	65	82	65	8	159	3.8	3000	7.6	200	0.4
						10	160		2700			0.5
						12	161		2400			0.6
						15	163		1800			0.8
						20	167		1000			1.0

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
N ₂	N ₂	21	65	82	65	5/16	159	0.15	118	0.300	200	0.4
						3/8	160		110			0.5
						1/2	161		90			0.6
						5/8	163		65			0.8
						3/4	167		45			1.0

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	66

Stainless steel

H35 Plasma / N₂ Shield

200 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	116 / 245
Cutflow	30 / 63	104 / 220



220637



220762




220758




220343



220342



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
H35	N ₂	21	65	82	75	8	175	9.0	1790	9.0	100	0.4
						10			1620			0.5
						12	170	7.5	1450	7.5		0.6
						15	173		1200			0.7
						20	177		820			0.8

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
H35	N ₂	21	65	82	75	5/16	175	0.350	70	0.350	100	0.4
						3/8			65			0.5
						1/2	170	0.300	55	0.300		0.6
						5/8	173		45			0.7
						3/4	177		35			0.8


Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	66

OPERATION

Stainless steel N₂ Plasma / Air Shield 260 A


Flow rates – lpm/scfh		
	N ₂	Air
Preflow	127 / 270	0 / 0
Cutflow	54 / 114	116 / 245



220637



220763




220758



220406



220405



220307



220340

Metric

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds	
N ₂	Air	11	75	75	82	6	160	3.8	6375	7.5	200	0.3	
						8	158		4910				
						10	157		3440				
						12	161		2960				0.4
						15	163		2520				0.5
						20	164		1590				0.6
						25	168		1300				0.8
						32	171		875				1.0
						38	179		515	Edge start			
						44	190		365				
						50	195		180				

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds	
N ₂	Air	11	75	75	82	1/4	160	0.15	240	0.30	200	0.3	
						5/16	158		193				
						3/8	157		140				0.4
						1/2	161		110				0.5
						5/8	163		95			0.6	
						3/4	164		70			0.8	
						1	168		50			1.0	
						1-1/4	171		35				
						1-1/2	179		20	Edge start			
						1-3/4	190		14				
						2	200		6				

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63

Stainless steel

H35 Plasma / N₂ Shield

260 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	127 / 270
Cutflow	40 / 84	122 / 260



220637



220763



220758




220406



220405



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
H35	N ₂	11	75	80	88	8	188	11.0	2030	11.0	100	0.3
						10	185		1870			
						12	173	9.0	1710	9.0	120	0.4
						15	171	7.5	1465			0.5
						20	175		1085			0.6
						25	180		785			0.7
						32	185		630			1.0
						38	186		510		Edge start	
						44	189		390			
						50	200		270			

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds	
H35	N ₂	11	75	80	88	5/16	188	0.45	80	0.45	100	0.3	
						3/8	185		75				
						1/2	173	0.35	65	0.35	120	0.4	
						5/8	171	0.30	55	0.36		0.5	
						3/4	175		45				0.6
						1	180		30				0.7
						1-1/4	185		25				1.0
						1-1/2	186		20	Edge start			
						1-3/4	189		15				
						2	200		10				

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63

Stainless steel bevel cutting

H35 Plasma / N₂ Shield

260 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	127 / 270
Cutflow	40 / 84	122 / 260




220637



220738




220739




220607



220405



220606



220571

Notes: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
H35	N ₂	11	75	80	88	2.0	8	11.0	2030	11.0	100	0.3
							10	9.0 – 10.0	1870	9.0	120	0.4
							12		1710			0.5
							15	7.5 – 10.0	1465		120	0.6
							20		1085			0.7
							25		785			1.0
							32		630			Edge start
							38		510			
							44		390			
							50		270			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
H35	N ₂	11	75	80	88	0.08	5/16	0.45 – 0.40	80	0.45	100	0.3
							3/8	0.35 – 0.40	75	0.35	120	0.4
							1/2		65			0.5
							5/8	0.30 – 0.40	55	0.36	120	0.6
							3/4		45			0.7
							1		30			1.0
							1-1/4		25			Edge start
							1-1/2		20			
							1-3/4		15			
							2		10			

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63

Stainless steel bevel cutting

N₂ Plasma / Air Shield

260 A


Flow rates – lpm/scfh		
	N ₂	Air
Preflow	127 / 270	0 / 0
Cutflow	54 / 114	116 / 245




220637



220738




220739




220607



220405



220606



220571

Note: Bevel angle range is 0° to 45°.

Metric

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	mm	Range (mm)	mm/m	mm	factor %	seconds
N ₂	Air	11	75	75	82	2.0	6	3.8 – 10.0	6375	7.5	200	0.3
							8		4910			
							10		3440			
							12		2960			0.4
							15		2520			0.5
							20		1590			0.6
							25		1300			0.8
							32		875			1.0
							38		515	Edge start		
							44		365			
							50		180			

English

Select Gases		Set Preflow		Set Cutflow		Minimum Clearance	Equivalent Material Thickness	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	in	Range (in)	ipm	in	factor %	seconds
N ₂	Air	11	75	75	82	0.08	1/4	0.15 – 0.40	240	0.30	200	0.3
							5/16		193			
							3/8		140			
							1/2		110			0.4
							5/8		95			0.5
							3/4		70			0.6
							1		50			0.8
							1-1/4		35			1.0
							1-1/2		20	Edge start		
							1-3/4		14			
							2		6			

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63

Aluminum

Air Plasma / Air Shield

45 A


Flow rates – lpm/scfh	
	Air
Preflow	45 / 95
Cutflow	78 / 165



220747



220202




220756




220201



220180



220308



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
Air	Air	35	25	55	60	1.2	130	2.5	4750	3.8	150	0.2
						1.5	115		4160			
						2	113		3865			
						2.5	110		3675			
						3	107		2850			
					40	4	102	1.8	2660	2.7		0.3
						6	117	3.0	1695	4.5		0.6

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds	
Air	Air	35	25	55	60	0.040	130	0.100	220	0.150	150	0.2	
						0.051	115		170				
						0.064	113		160				
						0.102	110		140				
					40	0.125	102	0.070	110	0.110		0.3	
						3/16	114	0.120	90	0.180			0.4
						1/4	117		60				0.6

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	15	2.5	0.10	6350	250	85
Ar	Ar	90	10	90	10	12	2.5	0.10	2540	100	75

Aluminum

Air Plasma / Air Shield

130 A


Flow rates – lpm/scfh	
	Air
Preflow	73 / 154
Cutflow	78 / 165



220747



220198




220756




220197



220179



220181



220340

Metric

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
Air	Air	20	40	70	30	6	153	2.8	2370	5.6	200	0.2
						8	154	3.0	1920	6.0		0.3
						10	154		1465			0.5
						12	156		1225			0.8
						15	158	3.3	1050	6.6		1.3
						20	162	3.5	725	7.0		
						25	172	4.0	525	N/A		

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
Air	Air	20	40	70	30	1/4	153	0.110	90	0.220	200	0.2
						5/16	154	0.120	76	0.240		0.3
						3/8	154		60			0.5
						1/2	156		45			0.8
						5/8	158	0.130	40	0.260		1.3
						3/4	162	0.140	30	0.280		
						1	172	0.160	20	N/A		

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps					
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Ar	50	10	50	10	15	3.0	0.12	2540	100	82

Note: This process produces a rougher cut edge that is less perpendicular than the 130 A, H35/N₂ process.

Aluminum

H35 Plasma / N₂ Shield
130 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	76 / 160
Cutflow	26 / 54	68 / 144



220747



220198




220755



220197



220179



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
H35	N ₂	20	40	70	60	8	158	5.0	1775	6.5	130	0.3
						10			1615			
					45	12	156	4.5	1455	7.7	170	0.5
					30	15			1305			0.8
						20			940			1.3
					20	25			540			Edge start

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
H35	N ₂	20	40	70	60	5/16	158	0.200	70	0.260	130	0.3
						3/8			65			
					45	1/2	156	0.180	55	0.310	170	0.5
					30	5/8			50			0.8
						3/4			40			1.3
					20	1			20			Edge start

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	130
Ar	Air	50	10	50	10	15	3.0	0.12	2540	100	75

Note: This process produces a smoother cut edge that is more perpendicular than the 130 A, Air/Air process.

Aluminum

N₂ Plasma / N₂ Shield
200 A


Flow rates – lpm/scfh	
	N ₂
Preflow	113 / 240
Cutflow	135 / 287



220637



220762




220759




220346



220342



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
N ₂	N ₂	21	65	70	65	8	158	6.4	6000	9.0	140	0.3
						10			4750			0.4
						12			3500			0.5
						15	166		2350			0.6
						20	165		1000			0.8

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
N ₂	N ₂	21	65	70	65	5/16	158	0.250	236	0.350	140	0.3
						3/8			200			0.4
						1/2			120			0.5
						5/8	166		80			0.6
						3/4	165		50			0.8


Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	66


Aluminum

H35 Plasma / N₂ Shield
200 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	113 / 240
Cutflow	34 / 72	90 / 190



220637



220762



220759




220346



220342



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time	
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds	
H35	N ₂	21	65	70	65	8	152	6.4	5000	9.0	140	0.3	
						10			4400				
						12	150		3800				0.4
						15			3000				0.5
						20	159		1450				0.6

English

Select Gases		Set Preflow		Set Outflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
H35	N ₂	21	65	70	65	5/16	152	0.250	197	0.350	140	0.3
						3/8			180			
						1/2	150		140			0.4
						5/8			110			0.5
						3/4	159		70			0.6

Marking


Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	140
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	66

Aluminum


N₂ Plasma / Air Shield

260 A


Flow rates – lpm/scfh		
	N ₂	Air
Preflow	125 / 265	0 / 0
Cutflow	50 / 105	113 / 240



220637



220763



220758



220406



220405



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
N ₂	Air	11	75	70	82	6	172	6.4	7900	9.0	140	0.2
						8			6415			0.3
						10	171		4930			0.4
						12	164	4.0	4290	8.0	200	0.5
						15	165		3330			0.6
						20	171		1940			
						25	177		1440	11.0	260	0.8
						32	191		940			Edge start
						38	195		520			
						44	202		320			
						50	205		215			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
N ₂	Air	11	75	70	82	1/4	172	0.250	300	0.350	140	0.2
						5/16			253			0.3
						3/8	171		200			0.4
						1/2	164	0.160	160	0.320	200	0.5
						5/8	165		120			0.6
						3/4	171		80			
						1	177		55	0.420	260	0.8
						1-1/4	191		40			Edge start
						1-1/2	195		20			
						1-3/4	202		12			
						2	205		8			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63


OPERATION

Aluminum


H35 Plasma / N₂ Shield

260 A


Flow rates – lpm/scfh		
	H35	N ₂
Preflow	0 / 0	127 / 270
Cutflow	33 / 70	118 / 250



220637



220763



220758




220406



220405



220307



220340

Metric

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	mm	Volts	mm	mm/m	mm	factor %	seconds
H35	N ₂	11	75	70	85	6	170	11.0	7200	11.0	100	0.2
						8			6660			0.3
						10			6120			0.4
						12	162	7.6	5160	8.5	110	0.5
						15	163		3720			0.6
						20	166		2230			
						25	174		1930	11.0	150	0.8
						32	175		1510			Edge start
						38	176		1150			
						44	183		670			
						50	190		390			

English

Select Gases		Set Preflow		Set Cutflow		Material Thickness	Arc Voltage	Torch-to-Work Distance	Cutting Speed	Initial Pierce Height		Pierce Delay Time
Plasma gas	Shield gas	Plasma gas	Shield gas	Plasma gas	Shield gas	in	Volts	in	ipm	in	factor %	seconds
H35	N ₂	11	75	70	85	1/4	170	0.45	280	0.45	100	0.2
						5/16			262			0.3
						3/8			250			0.4
						1/2	162	0.30	190	0.33	110	0.5
						5/8	163		130			0.6
						3/4	166		90			
						1	174		75	0.45	150	0.8
						1-1/4	175		60			Edge start
						1-1/2	176		45			
						1-3/4	183		25			
						2	190		14			

Marking

Select Gases		Set Preflow		Set Cutflow		Amperage	Torch-to-Work Distance		Marking Speed		Arc Voltage
						Amps	mm	in	mm/m	ipm	Volts
N ₂	N ₂	10	10	10	10	18	2.5	0.10	6350	250	120
Ar	Air	30	10	30	10	20	3.0	0.12	2540	100	63

Section 5

MAINTENANCE

In this section:



Introduction	5-3
Routine maintenance.....	5-3
System description.....	5-4
Power and signal cables.....	5-4
Sequence of operation	5-5
Gas system purge cycle.....	5-6
Gas system valve usage.....	5-6
Marking process	5-8
PCB block diagram	5-9
Error codes.....	5-10
HyPerformance plasma system error codes.....	5-10
Error code troubleshooting – error codes 000 to 018	5-11
Error code troubleshooting – error codes 020 to 028, 224 to 228.....	5-12
Error code troubleshooting – error codes 030 to 042, 231 to 234.....	5-13
Error code troubleshooting – error codes 044 to 046	5-14
Error code troubleshooting – error codes 047 to 053, 248 to 250.....	5-15
Error code troubleshooting – error codes 054 to 061	5-16
Error code troubleshooting – error codes 062 to 067, 265 to 267	5-17
Error code troubleshooting – error codes 071 to 075, 273 to 275.....	5-18
Error code troubleshooting – error codes 076 to 101, 276 to 301	5-19
Error code troubleshooting – error codes 102 to 111, 302 to 308.....	5-20
Error code troubleshooting – error codes 116 to 133, 316.....	5-21
Error code troubleshooting – error codes 134 to 140, 334 and 338.....	5-22
Error code troubleshooting – error codes 141 to 152, 346 to 351	5-23
Error code troubleshooting – error codes 153 to 156, 354 to 356.....	5-24
Error code troubleshooting – error codes 157 to 159, 357 to 359.....	5-25
Error code troubleshooting – error codes 160 to 180	5-26
Error code troubleshooting – error code 181, 182, 298, and 383.....	5-27
Power supply states.....	5-28
Plasma system operation with pump timeout.....	5-29
CNC operation with pump timeout.....	5-30
Initial checks.....	5-31
Power measurement	5-32

Air filter element replacement	5-33
Power supply coolant system servicing.....	5-34
Draining the coolant system.....	5-34
Coolant system filter.....	5-35
Filter replacement.....	5-35
Coolant flow troubleshooting chart	5-36
Coolant flow tests.....	5-37
Before testing.....	5-37
Using the Hypertherm flow meter (128933).....	5-37
Manual pump operation	5-38
Test 1 – return line.....	5-39
Test 2 – supply line at ignition console.....	5-39
Test 3 – change the torch.....	5-40
Test 4 – supply line to the torch receptacle	5-40
Test 5 – return line from the torch receptacle (remove at the ignition console).....	5-40
Test 6 – bucket test at the pump	5-41
Test 7 – bypass the check valve	5-41
Pump and motor troubleshooting	5-42
Testing the flow sensor.....	5-43
Gas leak tests.....	5-44
Leak test 1	5-44
Leak test 2	5-44
Power supply control board PCB3.....	5-45
Power supply power distribution board PCB2	5-46
Start-circuit PCB1	5-47
Operation	5-47
Start circuit functional schematic	5-47
Start circuit troubleshooting	5-47
Pilot arc current levels.....	5-49
Gas console control board PCB2	5-50
Gas console power distribution board PCB1.....	5-51
Gas console, AC valve-driver board PCB3.....	5-52
Chopper tests.....	5-53
Phase-loss detection test	5-55
Torch lead test.....	5-56
Preventive maintenance.....	5-57

Introduction

Hypertherm assumes that the service personnel performing the troubleshooting testing are high-level electronic service technicians who have worked with high-voltage electro-mechanical systems. Knowledge of final isolation troubleshooting techniques is also assumed.

In addition to being technically qualified, maintenance personnel must perform all testing with safety in mind. Refer to the **Safety** section for operating precautions and warning formats.


		WARNING SHOCK HAZARD
<p>Use extreme care when working near the chopper modules. Each large electrolytic capacitor (blue-cased cylinder) stores large amounts of energy in the form of electric voltage. Even if the power is off, dangerous voltages exist at the capacitor terminals, on the chopper, and the diode heatsinks. Never discharge any capacitor with a screwdriver or other implement... explosion, property damage and/or personal injury will result.</p>		

Routine maintenance

See *Preventive Maintenance*, located at the end of this section, for maintenance information. Contact the Technical Services department listed at the front of this manual with any questions regarding maintenance procedures.

System description

Power and signal cables



Sequence of operation

1. Power-up – The system verifies that all of these signals are off at power-up
 - Coolant flow off
 - Chopper current off
 - Transfer off
 - Phase Loss off
 - Chopper 1 over-temp off
 - Magnetics over-temp off
 - Coolant over-temp off
 - Plasma start off
2. Purge – Air or N₂ gas flows through torch for 20 seconds
 - Coolant flow on
 - Contactors closes and the chopper performs a chopper test and a current sensor test
 - Plasma start off
 - Contactors remains closed when the purge cycle ends
3. Idle
 - Gas pressure ok
 - Coolant flow on
 - Chopper current off
 - Line voltage ok
4. Preflow – 2 second flow of gas
5. Pilot Arc – Current flow between electrode and nozzle
 - Chopper, main contactor and pilot arc relay are on
 - High frequency present
 - Chopper current sensor = pilot arc current
6. Transfer – Pilot arc current sensed on the worklead
7. Ramp-up – Chopper current increases to set point and gas switches to cutflow
 - Coolant flow on
 - Gas pressure ok
 - Phase loss on
 - Line voltage ok
8. Steady State – normal operating parameters
 - Coolant flow on
 - Gas pressure ok
 - Phase loss on
 - Chopper 1 over-temp off
 - Magnetics over-temp off
 - Coolant over-temp off
9. Ramp-down – Current and gas flow decreases after plasma start has been removed
 - Cutflow gas off
10. Auto Off – 10 second postflow
 - Main contactors off
 - Choppers off

Gas system purge cycle

When the system is turned on, or the operator changes from one process to another, the system automatically goes through a purge process. The purge process has 2 stages; a preflow purge and a cutflow purge.

The preflow purge gas is turned on for 8 seconds with an auto gas console, or 12 seconds with a manual gas console.

The cutflow purge gas is turned on for 8 seconds with an auto gas console, or 12 seconds with a manual gas console.

There are 2 exceptions to the process described above.

Exception 1 – if the operator changes from a non-fuel gas process (O₂/Air, Air/Air, or N₂/Air) to a fuel gas process (H35/N₂, or F5/N₂) or the reverse, there will be 3 stages to the purge process. Nitrogen will purge the gas system first, for 12 seconds. The preflow and cutflow purges will follow the nitrogen purge.

Note: Error code 42 (low nitrogen gas pressure) will be displayed, if nitrogen is not connected to the gas system. If error code 42 is not resolved in 3 minutes, it will be replaced by error code 139 (purge time-out error).

Exception 2 – no purge process will occur if the operator changes from any process to a nitrogen marking process.

Gas system valve usage

The following tables show which valves are active for each cutting process.

O ₂ /O ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1	SV2		SV4			SV7			SV10							SV17	SV18		
Cutflow	SV1	SV2		SV4			SV7			SV10				SV14		SV16			SV19	

O ₂ /Air process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1	SV2			SV5		SV7			SV10							SV17	SV18		
Cutflow	SV1	SV2			SV5		SV7			SV10				SV14		SV16			SV19	

N ₂ /N ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow						SV6		SV8			SV11						SV17	SV18		
Cutflow						SV6		SV8			SV11			SV14		SV16			SV19	

F5/N ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow			SV3			SV6		SV8				SV12					SV17	SV18		
Cutflow			SV3			SV6		SV8				SV12		SV14		SV16			SV19	

H35/N ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow			SV3			SV6		SV8				SV12					SV17	SV18		
Cutflow			SV3			SV6		SV8				SV12		SV14		SV16			SV19	

N ₂ /Air process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1				SV5			SV8			SV11						SV17	SV18		
Cutflow	SV1				SV5			SV8			SV11			SV14		SV16			SV19	

Air/Air process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1				SV5		SV7		SV9								SV17	SV18		
Cutflow	SV1				SV5		SV7		SV9					SV14		SV16			SV19	

MAINTENANCE

Marking process

The valves that are active when marking are represented by the tables below. The active valves in the gas console will differ, depending on what process was used before marking.

Valves active when changing from a process that **does not** use a fuel gas

N ₂ /N ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow						SV6		SV8			SV11						SV17	SV18		
Cutflow						SV6		SV8			SV11			SV14		SV16			SV19	

Valves active when changing from a process that **does** use a fuel gas


N ₂ /N ₂ process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow						SV6		SV8			SV11						SV17	SV18		
Cutflow						SV6		SV8			SV11			SV14		SV16			SV19	

Ar/Ar process	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow						SV6		SV8			SV11						SV17	SV18		
Cutflow						SV6		SV8			SV11			SV14		SV16			SV19	

Ar/Air 25 to 35 amps	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1				SV5		SV7				SV11						SV17	SV18		
Cutflow	SV1				SV5		SV7				SV11			SV14		SV16			SV19	

Ar/Air < 25 or > 35 amps	Gas console AC valve driver board – LEDs																			
Valve location	Gas console															Off-valve				
LED number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Preflow	SV1				SV5			SV8			SV11						SV17	SV18		
Cutflow	SV1				SV5			SV8			SV11			SV14		SV16			SV19	


PCB block diagram



Error codes

HyPerformance plasma system error codes

Error codes are displayed in the 3-digit LED display on the gas console.



Error code troubleshooting – error codes 000 to 018

Error code number	Name	Description	Corrective action
000	No error	System is ready to run.	None needed.
009	Flow switch test	The flow switch is tested when the pump restarts after a pump timeout (30 minutes without a start signal). The test ensures that the coolant flow is correct before firing the torch.	Wait 10 seconds for the flow rate to stabilize.
011	No active process HPR400XD HPR800XD Only	The current setting is greater than the capability of the selected process. When this error code occurs, the power supply will ignore the start signal until a correct process is chosen.	Note: To protect against unintended operation after a system reset, the current will be set to 5 amps. If a correct process is sent, the system will operate normally. 1. Verify that the secondary power supply is turned ON. 2. Verify that the current for the selected process is within the range of the power supply capability (up to 400A for 400XD, and up to 800A for 800XD).
012	Test in progress	One of the gas test modes is running.	Wait for the test to finish.
013	Test passed	The test was successful.	No action required.
014	Cut gas channel 1 fail	The gas pressure in channel 1 is decreasing, which indicates a leak.	Look for leaks and loose connections between the selection console and the metering console.
015	Cut gas channel 2 fail	The gas pressure in channel 2 is decreasing, which indicates a leak.	Look for leaks and loose connections between the selection console and the metering console.
016	Plasma rampdown fail	Plasma pressure did not decrease in the time allowed.	Verify that there is no obstruction in the plasma vent hose.
017	Shield rampdown fail	Shield pressure did not decrease in the time allowed.	Inspect the holes in the shield for obstructions. Replace the shield if the holes are blocked.

Error code troubleshooting – error codes 020 to 028, 224 to 228

Error code number	Name	Description	Corrective action
020	No pilot arc	No current detected from chopper at ignition and before 1-second timeout.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper preflow and cut-flow settings. 3. Perform gas leak tests (see <i>Maintenance</i> section). 4. Verify spark across spark gap. 5. Inspect CON1 and pilot arc relay for excessive wear. 6. Perform gas flow test (see <i>Maintenance</i> section). 7. Perform torch lead test (see <i>Maintenance</i> section). 8. Perform start circuit test (see <i>Maintenance</i> section).
021	No arc transfer	No current detected on work lead 500 milliseconds after pilot arc current was established.	<ol style="list-style-type: none"> 1. Verify proper pierce height. 2. Verify proper preflow and cut-flow settings. 3. Inspect work lead for damage or loose connections.
024 Primary 224 Secondary	Lost current Chopper 1	Lost the current signal from Chopper 1 after transfer.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper cut-flow gas settings. 3. Verify pierce delay time. 4. Verify arc did not lose contact with plate while cutting (hole cutting, scrap cutting, etc).
025 Primary 225 Secondary	Lost current Chopper 2 HPR260XD HPR400XD Only	Lost the current signal from Chopper 2 after transfer.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper cut-flow gas settings. 3. Verify pierce delay time. 4. Verify arc did not lose contact with plate while cutting (hole cutting, scrap cutting, etc).
026 Primary 226 Secondary	Lost transfer	Lost the transfer signal after transfer completed.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper cut-flow gas settings. 3. Verify pierce delay time. 4. Verify arc did not lose contact with plate while cutting (hole cutting, scrap cutting, etc). 5. Inspect work lead for damage or loose connections. 6. Try connecting work lead directly to the plate.
027 Primary 227 Secondary	Lost phase	Phase imbalance to chopper after contactor engaged or while cutting.	<ol style="list-style-type: none"> 1. Verify phase-to-phase voltage to power supply. 2. Disconnect power to power supply, remove cover on contactor and inspect contacts for excessive wear. 3. Inspect power cord, contactor, and input to chopper for loose connections. 4. Inspect phase loss fuses on Power Distribution board. Replace board if fuses are blown. 5. Perform phase loss test (see <i>Maintenance</i> section).
028 Primary 228 Secondary	Lost current Chopper 3 HPR400XD Only	Lost the current signal from Chopper 3 after transfer.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper cut-flow gas settings. 3. Verify pierce delay time. 4. Verify arc did not lose contact with plate while cutting (hole cutting, scrap cutting, etc).

Error code troubleshooting – error codes 030 to 042, 231 to 234

Error code number	Name	Description	Corrective action
030	Gas system error Auto Gas Only	A failure has occurred in the gas system.	<ol style="list-style-type: none"> 1. Verify that cable number 5 (power supply-to-gas console control cable) is not damaged and is properly connected to PCB3 and to the rear of the gas console. 2. Verify that cable number 6 (power supply-to-gas console power cable) is not damaged and is properly connected inside the power supply and to the rear of the gas console. 3. Verify that D1 (+5 VDC) and D2 (+3.3 VDC) are illuminated on PCB2 inside the gas console. These LEDs indicate power to PCB2. 4. If power is present at PCB2 and PCB3 and both gas console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced.
031 Primary 231 Secondary	Start lost	Start signal was received and then lost before an arc was established.	<ol style="list-style-type: none"> 1. If a mechanical relay is being used to provide the HPR with a start signal, this relay is either bouncing when activated or the contacts are faulty. Replace the relay. 2. Inspect interface cable for damage; faulty crimps, or poor electrical connections. 3. If interface cable is good and a relay is not driving the start input, the CNC is dropping the start signal before a steady state arc has been established.
032	Hold timeout	Hold signal was active for longer than 60 seconds.	<ol style="list-style-type: none"> 1. Check the interface cable for damage. The hold wires may be short-circuiting inside. 2. The CNC is maintaining this input, it could be waiting for an IHS complete input from another torch. 3. If CNC interface cable is good and it is a 1-torch system, change PCB3.
033	Precharge time-out Auto Gas Only	Selection console was not able to charge the lines to the correct value.	This is a warning for a possible gas restriction in the leads. Verify that there are no restrictions in the plasma and shield hoses, or low inlet-gas pressure.
034 Primary 234 Secondary	Lost current Chopper 4 HPR400XD Only	Lost the current signal from Chopper 4 after transfer.	<ol style="list-style-type: none"> 1. Verify that the consumable parts are in good condition. 2. Verify proper cut-flow gas settings. 3. Verify pierce delay time. 4. Verify arc did not lose contact with plate while cutting (hole cutting, scrap cutting, etc).
042	Low nitrogen (N ₂) gas pressure	Nitrogen gas pressure under lower limit of: 2.07 bar (30 psi) – cutting 0.34 bar (5 psi) – marking During N ₂ purge, when changing between a fuel gas process and an oxidizer process.	<ol style="list-style-type: none"> 1. Verify that the nitrogen supply is turned on and inspect gas supply pressure and volume of gas remaining in supply tanks. 2. Verify that the gas regulator is set to 8.27 bar (120 psi). See <i>Setting the supply regulators (Installation section)</i>.

Error code troubleshooting – error codes 044 to 046

Error code number	Name	Description	Corrective action
044	Low plasma gas pressure	Plasma gas pressure under lower limit of 0.34 bar (5 psi) – preflow 3.45 bar (50 psi) – cutflow (cutting) 0.34 bar (5 psi) – cutflow (marking)	<ol style="list-style-type: none"> 1. Inspect gas supply pressure and volume of gas remaining in supply tanks. 2. Verify the gas regulator settings on gas console with the parameters in the cut charts. 3. See <i>Setting the supply regulators</i> (Installation section). 4. Perform gas leak tests (Maintenance section).
045	High plasma gas pressure	Plasma gas pressure over upper limit of: 7.58 bar (110 psi) – manual 9.65 bar (140 psi) – auto	<ol style="list-style-type: none"> 1. Verify gas supply pressure settings. 2. Verify gas regulator settings on gas console with cut chart. 3. See <i>Setting the supply regulators</i> (Installation section). 4. Solenoid at off-valve is not opening. Verify power to valves, disconnect plasma and shield hoses exiting off-valve. If pressures decrease a valve is not functioning or no power to the valve.
046	Low line voltage	Line voltage is close to or less than the lower limit of 102 VAC (120 VAC -15%). The normal lower limit for operation is 108 VAC (120 VAC -10%).	<ol style="list-style-type: none"> 1. Verify input-line voltage at PCB2 in the power supply (also PCB1 in the cooler for HPR400XD systems). Voltage needs to be within 10% of nominal (120 VAC). 2. Verify fuses on PCB2 in the power supply. 3. Verify 120 VAC voltage on plug J2.4, pins 3 and 4 on PCB2 in the power supply. 4. For HPR400XD systems, verify the voltage on PCB1 in the cooler with a DC volt meter. It should be about 0.415 VDC between TP23 and TP2 on PCB1. 5. If AC voltage on PCB2, J2.4, pins 3 and 4, is greater than 108 VAC and DC voltage between TP23 and TP2 on PCB1 is less than 0.38 VDC, verify minimum 108 VAC voltage on plug J4, pins 1 and 2 on PCB1. Verify the wiring between PCB2 in the power supply and J4 on PCB1. If the voltage on plug J4 is greater than 108 VAC, but the DC voltage on TP23 and TP2 is less than 0.38, replace PCB1. 6. If the AC voltage on PCB2 in the power supply at J2.4, pins 3 and 4, is greater than 108 VAC and the DC voltage between TP23 and TP2 on PCB1 in the cooler (HPR400XD only) is also greater than 0.38 VDC, verify the CAN link between PCB3 in the power supply and PCB1 in the cooler.

Error code troubleshooting – error codes 047 to 053, 248 to 250

Error code number	Name	Description	Corrective action
047	High line voltage	Line voltage is close to or greater than the upper limit of 138 VAC (120 VAC +15%). The normal upper limit for operation is 132 VAC (120 VAC +10%).	<ol style="list-style-type: none"> 1. Verify input–line voltage at PCB2 in the power supply and PCB1 in the cooler (HPR400XD only). Voltage needs to be within 10% of nominal (120 VAC). 2. Verify fuses on PCB2 in the power supply. 3. Verify 120 VAC voltage on plug J2.4, pins 3 and 4 on PCB2 in the power supply. 4. Verify the voltage on PCB1 in the cooler (HPR400XD only) with a DC volt meter. It should be about 0.415 VDC between TP23 and TP2 on PCB1. 5. If AC voltage on PCB2, J2.4, pins 3 and 4, is less than 132 VAC and DC voltage between TP23 and TP2 on PCB1 is greater than 0.44 VDC, verify maximum 132 VAC voltage on plug J4, pins 1 and 2 on PCB1. Verify wiring between PCB2 in the power supply and J4 on PCB1. If the voltage on plug J4 is less than 132 VAC, but the DC voltage on TP23 and TP2 is greater than 0.44, replace PCB1. 6. If the AC voltage on PCB2 in the power supply on plug J2.4, pins 3 and 4, is less than 132 VAC and the DC voltage between TP23 and TP2 on PCB1 in the cooler (HPR400XD only) is also less than 0.44 VDC, verify the CAN link between PCB3 in the power supply and PCB1 in the cooler.
048 Primary 248 Secondary	CAN error	An error occurred with the CAN communications between the power supply and the gas console.	<ol style="list-style-type: none"> 1. Verify that cable number 5 (power supply-to-gas console control cable) is not damaged and is properly connected to PCB3 and to the rear of the gas console. 2. Verify that cable number 6 (power supply-to-gas console power cable) is not damaged and is properly connected inside the power supply and to the rear of the gas console. 3. Verify that D1 (+5 VDC) and D2 (+3.3 VDC) are illuminated on PCB2 inside the gas console. These LEDs indicate power to PCB2. 4. If power is present at PCB2 and PCB3 and both gas console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced.
050 Primary 250 Secondary	Start signal is on at power-up	Plasma start signal input is active during power-up of power supply.	<ol style="list-style-type: none"> 1. Stop or clear the cutting program. The plasma start signal to the plasma was not dropped after the last cut. 2. Verify that the CNC interface cable is not damaged. 3. Remove CNC interface cable from PCB3 and look for an open circuit between pins 15 and 34. 4. If the circuit is closed either the CNC is issuing a plasma start or the CNC interface cable is damaged. 5. If circuit is open, and LEDN300J is illuminated with CNC Interface cable removed from PCB3, replace PCB3.
053	Low shield gas pressure	Shield pressure is below lower limit of 0.14 bar (2 psi).	<ol style="list-style-type: none"> 1. Verify gas supply pressure and that a sufficient volume of gas remains in your supply. 2. Verify gas regulator settings on gas console with cut chart. 3. See <i>Setting the supply regulators</i> (Installation section). 4. Perform gas leak tests (Maintenance section).

Error code troubleshooting – error codes 054 to 061

Error code number	Name	Description	Corrective action
054	High shield gas pressure	Shield gas pressure is over upper limit of: 7.58 bar (110 psi) – manual 9.65 bar (140 psi) – auto	<ol style="list-style-type: none"> 1. Verify gas supply regulator settings. See <i>Setting the supply regulators</i> (Installation section). 2. Verify pressure settings on gas console with cut chart. 3. Solenoid at off-valve is not opening. Verify power to valves, disconnect plasma and shield hoses exiting off-valve. If pressures decrease, a valve is not functioning or no power to the valve.
055	MV1 inlet pressure Auto Gas Only	Motor valve 1 inlet pressure is less than 3.45 bar (50 psi) or greater than 9.65 bar (140 psi).	<ol style="list-style-type: none"> 1. Verify that gas pressure transducer P1 is between 3.45 bar (50 psi) and 9.65 bar (140 psi). Increase or decrease the inlet gas pressure to correct the problem.
056	MV2 inlet pressure Auto Gas Only	Motor valve 2 inlet pressure is less than 3.45 bar (50 psi) or greater than 9.65 bar (140 psi).	<ol style="list-style-type: none"> 1. Verify that gas pressure transducer P2 is between 3.45 bar (50 psi) and 9.65 bar (140 psi). Increase or decrease the inlet gas pressure to correct the problem.
057	Cut gas 1 pressure Auto Gas Only	Cut gas 1 outlet pressure is less than 3.45 bar (50 psi) or greater than 9.65 bar (140 psi) in the selection console.	<ol style="list-style-type: none"> 1. Verify that gas pressure transducer P3 is between 3.45 bar (50 psi) and 9.65 bar (140 psi). Increase or decrease the inlet gas pressure to correct the problem.
058	Cut gas 2 pressure Auto Gas Only	Cut gas 2 outlet pressure is less than 3.45 bar (50 psi) for non-mixing, or less than 1.38 bar (20 psi) when mixing or greater than 9.65 bar (140 psi) for non-mixing and mixing.	<ol style="list-style-type: none"> 1. Verify that gas pressure transducer P4 is between 3.45 bar (50 psi) and 9.65 bar (140 psi). Increase or decrease the inlet gas pressure to correct the problem.
060	Low coolant flow	Coolant flow is less than the required 2.3 lpm (0.6 gpm).	<ol style="list-style-type: none"> 1. Verify that the correct consumables are properly installed. 2. Perform the coolant flow test procedure in the Maintenance section of the manual.
061	No plasma gas type	<p>Manual gas - The gas console control board is not receiving signals from the gas selector knob.</p> <p>Auto gas - The selection console is not receiving the plasma gas type signal.</p>	<ol style="list-style-type: none"> 1. Auto gas - the process parameters may not have been downloaded. Verify that the process information can be viewed on the CNC screen. 2. Manual gas - the selector knob (2) may be set between positions. Reset the knob. 3. Verify that there is power to the console by looking to see if any LED on any board in the selection console (auto) or gas console (manual) is illuminated. If no LED is illuminated, verify that the fuse on the power distribution PCB is in proper working condition. 4. If the problem still exists, replace the control board.

Error code troubleshooting – error codes 062 to 067, 265 to 267

Error code number	Name	Description	Corrective action
062	No shield gas type	Manual gas – The gas console control board is not receiving signals from the gas selector knob. Auto gas – The selection console is not receiving the shield gas type signal.	<ol style="list-style-type: none"> 1. Auto gas – The process parameters may not have been downloaded. Verify that the process information can be viewed on the CNC screen. 2. Manual gas – The selector knob (2) may be set between positions. Reset the knob. 3. Verify that there is power to the console by looking to see if any LED on any board in the selection console (auto) or gas console (manual) is illuminated. If no LEDs are illuminated, verify that the fuse on the power distribution PCB is in proper working condition. 4. If the problem still exists, replace the control board.
065 Primary 265 Secondary	Chopper 1 overtemp	Chopper 1 has overheated.	<ol style="list-style-type: none"> 1. Verify that all chopper fans are operating properly. Spinning fan blades should be difficult to see. 2. Blow dust out of system, especially from fans and heat sink of chopper. 3. Verify that the voltage on rear side of J3.202, pins 2 and 3 on PCB3, is less than or equal to 2.9 VDC. 4. If the voltage is low, verify correct wiring between chopper temperature sensor and J3.202 pins 1 and 2. 5. If wiring is good and overtemp error does not clear after 30 minutes of the power supply idling with the fans running, replace the chopper.
066 Primary 266 Secondary	Chopper 2 overtemp HPR260XD HPR400XD Only	Chopper 2 has overheated.	<ol style="list-style-type: none"> 1. Verify that all chopper fans are operating properly. Spinning fan blades should be difficult to see. 2. Blow dust out of system, especially from fans and heat sink of chopper. 3. Verify that the voltage on rear side of J3.202, pins 5 and 6 on PCB3, is less than or equal to 2.9 VDC. 4. If the voltage is low, verify correct wiring between chopper temperature sensor and J3.202 pins 4 and 5. 5. If wiring is good and overtemp error does not clear after 30 minutes of the power supply idling with the fans running, replace the chopper.
067 Primary 267 Secondary	Magnetics overtemp	Power transformer has overheated.	<ol style="list-style-type: none"> 1. Verify that all the large fans are operating properly. Spinning fan blades should be difficult to see. 2. Blow dust out of system especially from fans and large power transformer. 3. Verify that the voltage on the rear side of J3.202 pins 14 and 15, is equal to or less than 3.2 VDC. 4. If voltage is low or near 0 VDC, inspect wiring between the transformer's temperature sensor and J3.202 pins 13 and 14. Look for shorts between wires or to ground. 5. If wiring is good, the transformer has overheated. Allow the power supply to idle with the fans running for a minimum of 30 minutes to cool the large power transformer. 6. Replace the transformer's temperature sensor if it is open or shorted. Replacement kit part number is 228309.

Error code troubleshooting – error codes 071 to 075, 273 to 275

Error code number	Name	Description	Corrective action
071	Coolant overtemp	Torch coolant has overheated.	<ol style="list-style-type: none"> 1. Verify that the large fan in the cooler (HPR400XD only) is running. 2. Blow dust out of the cooler (HPR400XD only), especially from the heat exchanger. 3. Verify that the voltage on the rear side of J1.5 pins 6 and 8, is equal to or lower than 2.8 VDC. 4. If voltage is low, inspect wiring between coolant temperature sensor and J1.5, pins 5 and 6, for shorts to wires or ground. 5. If wiring is good, the coolant has overheated; let system idle with the fans running for 30 minutes to cool. 6. Replace the coolant temperature sensor if it is open or shorted. Sensor part number is 229224.
072	Auto gas, control board overtemp Auto Gas Only	Control board has exceeded 90° C (194° F).	Verify that the airflow to the gas console is not restricted.
073 Primary 273 Secondary	Chopper 3 overtemp HPR400XD Only	Chopper 3 has overheated.	<ol style="list-style-type: none"> 1. Verify that all chopper fans are operating properly. Spinning fan blades should be difficult to see. 2. Blow dust out of system, especially from fans and heat sink of chopper. 3. Verify that the voltage on rear side of J3.202, pins 8 and 9 on PCB3, is less than or equal to 2.9 VDC. 4. If the voltage is low, verify correct wiring between chopper temperature sensor and J3.202 pins 7 and 8. 5. If wiring is good and overtemp error does not clear after 30 minutes of the power supply idling with the fans running, replace the chopper.
074 Primary 274 Secondary	Chopper 4 overtemp HPR400XD Only	Chopper 4 has overheated.	<ol style="list-style-type: none"> 1. Verify that all chopper fans are operating properly. Spinning fan blades should be difficult to see. 2. Blow dust out of system, especially from fans and heat sink of chopper. 3. Verify that the voltage on rear side of J3.202, pins 11 and 12 on PCB3, is less than or equal to 2.9 VDC. 4. If the voltage is low, verify correct wiring between chopper temperature sensor and J3.202 pins 10 and 11. 5. If wiring is good and overtemp error does not clear after 30 minutes of the power supply idling with the fans running, replace the chopper.
075 Primary 275 Secondary	Low current on CS3 HPR400XD Only	A current less than 10 amps has been detected by current sensor 3.	See the chopper test later in this section.

Error code troubleshooting – error codes 076 to 101, 276 to 301

Error code number	Name	Description	Corrective action
076 Primary 276 Secondary	Low current on CS4 HPR400XD Only	A current less than 10 amps has been detected by current sensor 4.	See the chopper test later in this section.
093	No coolant flow	Coolant flow signal was lost or never was satisfied.	<ol style="list-style-type: none"> 1. If this is a new system, follow start procedure. 2. Verify that the coolant filter is in good condition. 3. Perform coolant flow tests (<i>Maintenance</i> section). 4. Verify that the CNC drives the plasma start signal for at least 10 seconds to allow the timed-out pump to turn on again.
095 Primary 295 Secondary	High current on CS4 HPR400XD Only	A current greater than 35 amps has been detected by current sensor 4.	See the chopper test later in this section.
098	Phase loss at initialization HPR400XD HPR800XD Only	The system detected incoming line voltage during power-up, before the contactor was energized.	<ol style="list-style-type: none"> 1. Verify phase-to-phase voltage to power supply. 2. Disconnect power to power supply, remove cover on contactor and inspect contacts for excessive wear. 3. Inspect power cord, contactor, and input to chopper for loose connections. 4. Inspect phase loss fuses on Power Distribution board. Replace board if fuses are blown. 5. Perform phase loss test (see <i>Maintenance</i> section).
099 Primary 299 Secondary	Chopper 1 overtemp at power-up	Chopper 1 is indicating an overtemp at power-up.	<ol style="list-style-type: none"> 1. Verify that the temperature sensor for the chopper has not been bypassed or that the wires to the temperature switch are shorted out in the harness, or that the sensor is open. 2. If no jumper is present, the chopper is overheated and needs time to cool to 83° C (181.4° F).
100 Primary 300 Secondary	Chopper 2 overtemp at power-up HPR260XD HPR400XD Only	Chopper 2 is indicating an overtemp at power-up.	<ol style="list-style-type: none"> 1. Verify that the temperature sensor for the chopper has not been bypassed or that the wires to the temperature switch are shorted out in the harness, or that the sensor is open. 2. If no jumper is present, the chopper is overheated and needs time to cool to 83° C (181.4° F).
101 Primary 301 Secondary	Magnetics overtemp at power-up	Main transformer is indicating an overtemp at power-up.	<ol style="list-style-type: none"> 1. Verify that the transformer temperature sensor has not been bypassed or the wires to the temperature sensor are not shorted out in the harness. 2. Verify that the sensor is not open or shorted, if it is not open or shorted, the main transformer is overheated and needs time to cool to 150° C (302° F).

Error code troubleshooting – error codes 102 to 111, 302 to 308

Error code number	Name	Description	Corrective action
102 Primary 302 Secondary	Chopper 1 current at power-up	Chopper 1 current signal is active at power-up.	See wiring diagrams in section 7 1. Verify that the voltage at CS1 is correct. 2. Verify that the wiring between CS1 and PCB3 is correct and not damaged. 3. Swap CS1 with CS2. If the error code changes to 156, replace the original CS1.
103 Primary 303 Secondary	High current on CS1	A current greater than 35 Amps has been detected by current sensor 1.	See the chopper test later in this section.
104 Primary 304 Secondary	High current on CS2 HPR260XD HPR400XD Only	A current greater than 35 amps has been detected by current sensor 2.	See the chopper test later in this section.
105 Primary 305 Secondary	Low current on CS1	A current less than 10 amps has been detected by current sensor 1.	See the chopper test later in this section.
106 Primary 306 Secondary	Low current on CS2 HPR260XD HPR400XD Only	A current less than 10 amps has been detected by current sensor 2.	See the chopper test later in this section.
107 Primary 307 Secondary	High current on CS3 HPR400XD Only	A current greater than 35 amps has been detected by current sensor 3.	See the chopper test later in this section.
108 Primary 308 Secondary	Transfer at power-up	The system has detected current on the work lead during power-up.	1. Verify that the electrical connections to current sensors CS1 and CS3 are correct and not damaged. 2. Replace PCB3 if connections are correct and not damaged. 3. Verify that the main contactor (CON1) is not welded closed, or closing at power-up.
109	Coolant flow at power-up	“Coolant flow OK” signal is active during power-up and before pump motor is activated.	Either the coolant flow sensor was bypassed or it is faulty. 1. Verify that there is power at the sensor. 2. Verify that all the connectors have good connections.
111	Coolant overtemp at power-up	Coolant is indicating an overtemp at power-up.	1. Verify that the coolant temperature sensor has not been bypassed or the wires to the sensor are not shorted out in the harness. 2. If not, the coolant temperature is over the set point and needs time to cool to 70° C (158° F).

Error code troubleshooting – error codes 116 to 133, 316

Error code number	Name	Description	Corrective action
116 Primary 316 Secondary	Watchdog interlock	An error occurred with the CAN communication system.	<ol style="list-style-type: none"> 1. Verify that cable number 5 (power supply-to-gas console control cable) is not damaged and is properly connected to PCB3 and the rear of the gas console. 2. Verify that cable number 6 (power supply-to-gas console power cable) is not damaged and is properly connected inside the power supply and to the rear of the gas console. 3a. (Manual gas console) Verify that D1 (+5 VDC) and D2 (+3.3 VDC) are illuminated on PCB2 inside the gas console. These LEDs indicate power to PCB2. 3b. (Auto gas console) Verify that D17 (+5 VDC) and D18 (+3.3 VDC) are illuminated on PCB2 inside the gas console. These LEDs indicate power to PCB2. 4. If power is present at PCB2 and PCB3 and both gas console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced. 5. Verify that the gas console control PCB and power distribution PCBs are securely mounted to the chassis at all four corners.
123	MV1 error Auto Gas Only	Motor valve 1 did not move into position within 60 seconds.	Verify that LED D17 or D18 illuminates on the AC valve driver PCB in the selection console. If either illuminates, replace the motor valve. If they do not illuminate, replace PCB3.
124	MV2 error Auto Gas Only	Motor valve 2 did not move into position within 60 seconds.	Verify that LED D19 or D20 is illuminating on the AC valve driver PCB in the selection console. If either illuminates, replace the motor valve. If they do not illuminate, replace PCB3.
133	Unknown gas console type	The power supply control board does not recognize the gas console that is installed or has not received a CAN message.	<ol style="list-style-type: none"> 1. Verify that the part numbers of PCB2 and PCB3 are correct. 2. Verify that the power supply-to-gas console control cable is not damaged and is properly connected to PCB3 and the rear of the gas console. 3. Verify that the power supply-to-gas console power cable is not damaged and is properly connected inside the power supply and to the rear of the gas console. 4. Verify that D1 (+5 VDC) and D2 (+3.3 VDC) are illuminated on PCB2 inside the gas console. These LEDs indicate power to PCB2. 5. If power is present at PCB2 and PCB3 and both gas console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced.

Error code troubleshooting – error codes 134 to 140, 334 and 338

Error code number	Name	Description	Corrective action
134 Primary 334 Secondary	Chopper 1 overcurrent	Chopper 1 current feedback has exceeded 160 amps.	<ol style="list-style-type: none"> 1. Verify that the wiring between CS1 and PCB3 is correct and not damaged. 2. Measure voltage across current sensor. <ol style="list-style-type: none"> a) Red to black = +15 VDC, Green to black = -15 VDC, white to black = 0 VDC at idle and varies with current output (4 VDC = 100 amps). b) If possible, take a voltage reading on current sensor while trying to cut. Ratio is 4 VDC = 100 amps. c) If the current sensor voltage is approximately 6.4 VDC or greater at idle, replace the current sensor. 3. Remove connector JA.1 from the chopper and verify that LED1 is extinguished. <ol style="list-style-type: none"> a) If LED1 is extinguished with the connector removed, then reconnect JA.1 and try to fire the torch. If the chopper still goes into overcurrent, replace the chopper. b) If the chopper does not go into overcurrent, replace PCB3.
138 Primary 338 Secondary	Chopper 2 overcurrent HPR260XD HPR400XD Only	Chopper 2 current feedback has exceeded 160 amps.	<ol style="list-style-type: none"> 1. Verify that the wiring between CS2 and PCB3 is correct and not damaged. 2. Measure voltage across current sensor. <ol style="list-style-type: none"> a) Red to black = +15 VDC, Green to black = -15 VDC, white to black = 0 VDC at idle and varies with current output (4 VDC = 100 amps). b) If possible, take a voltage reading on current sensor while trying to cut. Ratio is 4 VDC = 100 amps. c) If the current sensor voltage is approximately 6.4 VDC or greater at idle, replace the current sensor. 3. Remove connector JB.1 from the chopper and verify that LED1 is extinguished. <ol style="list-style-type: none"> a) If LED1 is extinguished with the connector removed, then reconnect JB.1 and try to fire the torch. If the chopper still goes into overcurrent, replace the chopper. b) If the chopper does not go into overcurrent, replace PCB3.
139	Purge time-out error	The purge cycle did not complete within 3 minutes.	<p>This is a warning for a possible gas restriction in the leads.</p> <ol style="list-style-type: none"> 1. Verify that there are no restrictions in the plasma and shield hoses. 2. Verify that the inlet gas pressures are set to the proper levels.
140	Pressure transducer 1 or 8 error Auto Gas Only	Faulty transducer or control board in the metering console or the selection console.	<ol style="list-style-type: none"> 1. Verify that transducer P1 in the selection console is working properly. Replace if necessary. 2. Verify that transducer P8 in the metering console is working properly. Replace if necessary. 3. Verify that the control boards in the metering and selection consoles are working properly. Replace if necessary.

Error code troubleshooting – error codes 141 to 152, 346 to 351

Error code number	Name	Description	Corrective action
141	Pressure transducer 2 or 7 error Auto Gas Only	Faulty transducer or control board in the metering console or the selection console.	<ol style="list-style-type: none"> 1. Verify that transducer P2 in the selection console is working properly. Replace if necessary. 2. Verify that transducer P7 in the metering console is working properly. Replace if necessary. 3. Verify that the control boards in the metering and selection consoles are working properly. Replace if necessary.
142	Pressure transducer 3 or 5 error Auto Gas Only	Faulty transducer or control board in the metering console or the selection console.	<ol style="list-style-type: none"> 1. Verify that transducer P3 in the selection console is working properly. Replace if necessary. 2. Verify that transducer P5 in the metering console is working properly. Replace if necessary. 3. Verify that the control boards in the metering and selection consoles are working properly. Replace if necessary.
143	Pressure transducer 4 or 6 error Auto Gas Only	Faulty transducer or control board in the metering console or the selection console.	<ol style="list-style-type: none"> 1. Verify that transducer P4 in the selection console is working properly. Replace if necessary. 2. Verify that transducer P6 in the metering console is working properly. Replace if necessary. 3. Verify that the control boards in the metering and selection consoles are working properly. Replace if necessary.
144	Internal flash error Manual Gas Only	Communication problem to the flash chip on the gas console control board.	Replace the control board.
145	Internal flash error Auto Gas Only	Communication problem to the flash chip on the selection console control board.	Replace the control board.
146 Primary 346 Secondary	Chopper 3 overtemp at power-up HPR400XD Only	Chopper 3 is indicating an overtemp at power-up.	<ol style="list-style-type: none"> 1. Verify that the temperature sensor for the chopper has not been bypassed or that the wires to the temperature switch are shorted out in the harness, or that the sensor is open. 2. If no jumper is present, the chopper is overheated and needs time to cool to 83° C (181.4° F).
147 Primary 347 Secondary	Chopper 4 overtemp at power-up HPR400XD Only	Chopper 4 is indicating an overtemp at power-up.	<ol style="list-style-type: none"> 1. Verify that the temperature sensor for the chopper has not been bypassed or that the wires to the temperature switch are shorted out in the harness, or that the sensor is open. 2. If no jumper is present, the chopper is overheated and needs time to cool to 83° C (181.4° F).
151 Primary 351 Secondary	Software fail	Software has detected an incorrect state or condition.	Replace power supply control board.
152	Internal flash error	Communication problem to the flash chip on the power supply control board.	Replace the control board.

Error code troubleshooting – error codes 153 to 156, 354 to 356

Error code number	Name	Description	Corrective action
153	PS EEPROM error	EEPROM memory on power supply control board not working.	Replace the control board.
154 Primary 354 Secondary	Chopper 3 overcurrent HPR400XD Only	Chopper 3 current feedback has exceeded 160 amps.	<ol style="list-style-type: none"> 1. Verify that the wiring between CS3 and PCB3 is correct and not damaged. 2. Measure voltage across current sensor. <ol style="list-style-type: none"> a) Red to black = +15 VDC, Green to black = -15 VDC, white to black = 0 VDC at idle and varies with current output (4 VDC = 100 amps). b) If possible, take a voltage reading on current sensor while trying to cut. Ratio is 4 VDC = 100 amps. c) If the current sensor voltage is approximately 6.4 VDC or greater at idle, replace the current sensor. 3. Remove connector JC.1 from the chopper and verify that LED1 is extinguished. <ol style="list-style-type: none"> a) If LED1 is extinguished with the connector removed, then reconnect JC.1 and try to fire the torch. If the chopper still goes into overcurrent, replace the chopper. b) If the chopper does not go into overcurrent, replace PCB3..
155 Primary 355 Secondary	Chopper 4 overcurrent HPR400XD Only	Chopper 4 current feedback has exceeded 160 amps.	<ol style="list-style-type: none"> 1. Verify that the wiring between CS4 and PCB3 is correct and not damaged. 2. Measure voltage across current sensor. <ol style="list-style-type: none"> a) Red to black = +15 VDC, Green to black = -15 VDC, white to black = 0 VDC at idle and varies with current output (4 VDC = 100 amps). b) If possible, take a voltage reading on current sensor while trying to cut. Ratio is 4 VDC = 100 amps. c) If the current sensor voltage is approximately 6.4 VDC or greater at idle, replace the current sensor. 3. Remove connector JD.1 from the chopper and verify that LED1 is extinguished. <ol style="list-style-type: none"> a) If LED1 is extinguished with the connector removed, then reconnect JD.1 and try to fire the torch. If the chopper still goes into overcurrent, replace the chopper. b) If the chopper does not go into overcurrent, replace PCB3.
156 Primary 356 Secondary	Chopper 2 current at power-up HPR260XD HPR400XD Only	Chopper 2 current signal is active at power-up.	<p>See wiring diagrams in section 7</p> <ol style="list-style-type: none"> 1. Verify that the voltage at CS2 is correct. 2. Verify that the wiring between CS2 and PCB3 is correct and not damaged. 3. Swap CS2 with CS3. If the error code changes to 157, replace the original CS2.

Error code number	Name	Description	Corrective action
157 Primary 357 Secondary	Chopper 3 current at power-up HPR400XD Only	Chopper 3 current signal is active at power-up.	See wiring diagrams in section 7 1. Verify that the voltage at CS3 is correct. 2. Verify that the wiring between CS3 and PCB3 is correct and not damaged. 3. Swap CS3 with CS2. If the error code changes to 156, replace the original CS3.
158 Primary 358 Secondary	Chopper 4 current at power-up HPR400XD Only	Chopper 4 current signal is active at power-up.	See wiring diagrams in section 7 1. Verify that the voltage at CS4 is correct. 2. Verify that the wiring between CS4 and PCB3 is correct and not damaged. 3. Swap CS4 with CS2. If the error code changes to 156, replace the original CS4.
159 Primary 359 Secondary	Motor-drive fault HPR400XD and HPR800XD	<p>The pump-motor-drive board (PCB7) is indicating a drive fault.</p> <p>Note: The secondary error code (359) may display if the secondary power supply is turned off individually, or when the entire system is turned off. Customers with a manual gas console will not see this error code when the entire system is turned off.</p>	<p>1. Verify that the circuit breaker on PCB7 has not tripped. If it has tripped, reset the breaker by pressing the button until it is even with the top of the circuit breaker. If the circuit breaker is not tripped and there is no power to PCB7, verify that the fuse on PCB2 in the power supply is good.</p> <p>2. If D32 on PCB7 illuminates, the solenoid valve and motor are drawing too much current. D32 will only illuminate for a short time, and extinguishes after the outputs from the pump-motor-drive turn-off in response to the fault condition. Verify the wiring to the solenoid valve and the motor. Verify that the pump spins freely and is properly mounted to the motor. Look for obstructions in the torch, consumables, coolant lines, and in-line filter. Verify that the solenoid valve is operating. Any of these can cause the motor or solenoid valve to draw excessive current. Test for low coolant flow by using the coolant flow test in this section.</p> <p>3. If D32 on PCB7 illuminates immediately at power-up, and all the items above have been verified, replace PCB7.</p> <p>4. If D30 on PCB7 illuminates, the IGBT drive has encountered an over current condition. D30 will only illuminate for a short time, and extinguishes after the outputs from the pump motor-drive turn off. Follow the same steps for D32 above.</p> <p>5. If D31 on PCB7 illuminates, the heatsink thermistor is indicating that the heatsink is too hot. Wait 10 minutes for it to cool. If the error remains, verify that the wires from heatsink on PCB7 are properly connected to the J6 connector on PCB7. If the error still remains, turn OFF all power to the system and measure the resistance on the J6 connector between pins 1 and 2. At 25° C (77° F) the resistance should be 10k.</p>

Error code troubleshooting – error codes 160 to 180

Error code number	Name	Description	Corrective action
160	HPR cooler's CAN fault HPR400XD Only	Communication between the control board (PCB3 in the power supply) and the cooler sensor board (PCB1 in the cooler) was interrupted for more than 1 second.	<ol style="list-style-type: none"> 1. Verify that the cable connections from the power supply to the cooler are good. 2. Verify that D1 (+ 5 VDC) and D2 (+3.3 VDC) are illuminated on PCB1 inside the cooler. 3. Verify that the CAN bus LEDs, D7 and D8 are blinking.
161	Maximum coolant flow has been exceeded	Coolant flow has exceeded 6.8 lpm (1.8 gpm) for a cooler, 8.52 lpm (2.25 gpm) for a chiller.	<ol style="list-style-type: none"> 1. Verify proper coolant flow. 2. Look for air bubbles in the coolant. 3. Verify that the coolant is mixed in the proper proportions.
180	Selection console CAN time-out Auto Gas Only	The power supply did not receive a CAN message from the selection console within 1 second.	<ol style="list-style-type: none"> 1. Verify that the power supply-to-selection console CONTROL and POWER cables are not damaged and are properly connected to PCB3, and the rear of the selection console. 2. Verify that D17 (+5 VDC) and D18 (+3.3 VDC) are illuminated on PCB2 inside the selection console. These LEDs indicate power to PCB2. Also verify that D26 (CAN – RX) and D27 (CAN – TX) are illuminated on PCB2 inside the selection console. These LEDs indicate communication between the selection console and the power supply. 3. If power is present at PCB2 and PCB3 and both selection console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced. 4. Verify that the gas console control PCB and power distribution PCBs are securely mounted to the chassis at all four corners.


Error code troubleshooting – error code 181, 182, 298, and 383

Error code number	Name	Description	Corrective action
181	Metering console CAN time-out Auto Gas Only	The power supply did not receive a CAN message from the metering console within 1 second.	<ol style="list-style-type: none"> 1. Verify that the power supply-to-metering console CONTROL and POWER cables are not damaged and are properly connected to PCB3, and the rear of the metering console. 2. Verify that D17 (+5 VDC) and D18 (+3.3 VDC) are illuminated on PCB2 inside the metering console. These LEDs indicate power to PCB2. Also verify that D26 (CAN – RX) and D27 (CAN – TX) are illuminated on PCB2 inside the metering console. These LEDs indicate communication between the metering console and the power supply. 3. If power is present at PCB2 and PCB3 and both metering console cables are good, then PCB2 or PCB3 has failed. Use the CAN tester to verify which board needs to be replaced. 4. Verify that the gas console control PCB and power distribution PCBs are securely mounted to the chassis at all four corners.
182	Secondary power supply time-out HPR800XD Only	The secondary power supply fails before transmitting the error to the primary power supply.	<ol style="list-style-type: none"> 1. The primary power supply to secondary power supply CAN communication cable was disconnected after power-up. 2. The cable has electrical interference (noise) or the cable shielding has been compromised.
298	Secondary power supply phase loss at initialization HPR800XD Only	The system detected incoming line voltage during power-up, before the contactor was energized.	<ol style="list-style-type: none"> 1. Verify phase-to-phase voltage to power supply. 2. Disconnect power to power supply, remove cover on contactor and inspect contacts for excessive wear. 3. Inspect power cord, contactor, and input to chopper for loose connections. 4. Inspect phase loss fuses on Power Distribution board. Replace board if fuses are blown. 5. Perform phase loss test (see <i>Maintenance</i> section).
383	No ramp-up message HPR800XD Only	The secondary power supply is ready to provide current output but does not receive the control signal from the primary power supply.	<ol style="list-style-type: none"> 1 Turn off the power to the system and then turn on the power again. 2. The cable has electrical interference (noise) or the cable shielding has been compromised.


Power supply states


Set switch 8 on the gas console to the status position to view ID numbers.

State code	Name
00	Power -up (idle)
02	Purge
03	Ready for start (Idle 2)
04	Preflow
05	Pilot arc
06	Transfer
07	Ramp-up
08	Steady state
09	Ramp-down
10	Final ramp-down
11	Cycle complete (Auto off)
12	Test cutflow
14	Shutdown
15	Reset
16	Maintenance
20	Test preflow
22	Manual pump control
23	Inlet leak check
24	System leak check





Plasma system operation with pump timeout



CNC operation with pump timeout

Initial checks

Before troubleshooting, do a visual check and verify that proper voltages are present at the power source, transformers and power distribution board.

		DANGER SHOCK HAZARD
<p>Always use caution when servicing a power supply when plugged in and the covers are removed. Dangerous voltages exist within the power supply which could cause injury or death.</p>		


1. Disconnect line power by turning OFF the main disconnect switch.
2. Remove the power supply's top panel and two side panels.
3. Inspect interior of power supply for discoloration on PC boards, or other apparent damage. If a component or module is obviously defective, remove and replace it before doing any testing. Refer to the *Parts List* section to identify parts and part numbers.
4. If no damage is apparent, connect power to the power supply, and turn the main disconnect switch ON.
5. Measure the voltage between the W, V and U terminals of TB1 located on the right side of the power supply. See figure on next page. Also refer to the wiring diagram in Section 7, if required. The voltage between any 2 of the 3 terminals should be equal to the supply voltage. If there is a problem at this point, disconnect main power and check connections, power cable, and fuses at line disconnect switch. Repair or replace any defective component.

Power measurement



DANGER
SHOCK HAZARD


There is line voltage at the contactor and the power distribution board (PCB2) when the line disconnect switch is on. Use extreme care when measuring primary power in these areas. Voltages present at the terminal block and contactors can cause injury or death.



Note: Check lines in the following order:
U to V
U to W
V to W
Check each line to ground. If one line is 10% greater, or more, than the other two, put that leg on U.


Air filter element replacement

1. Turn OFF all electrical power and disconnect the air hose from the filter.
2. Remove the filter bowl by turning it counter clockwise until it releases.
3. Pull the clear filter housing down firmly to remove it. The filter housing has an o-ring around the top. Apply a thin film of silicone lubricant on the o-ring to extend it's life. The o-ring should look shiny, but there should not be any excess or built-up grease.



4. Use a screwdriver to remove the filter element from the filter housing. Then install the new filter element.

Note: Do not allow the filter element to turn when loosening the screw.




5. Reinstall the clear filter housing and the filter bowl.


Power supply coolant system servicing

Draining the coolant system

1. Turn OFF the power, and remove the return coolant hose (red tape) from the pump and put it in a 20 liter (5 gallon) container.



2. Press and hold the current selection knob (8) and turn ON the power switch. The pump will run continuously while (8) is pressed.



3. Run the pump until the coolant stops flowing and immediately release the current selection knob (8).


Caution: Coolant will flow from the filter when its housing is removed. Drain coolant before servicing the filter.




Coolant system filter

Filter replacement

1. Turn OFF all power to the system.
2. Remove housing.
3. Remove and discard filter element.
4. Install new filter element 027664.
5. Re-install housing.
6. Refill with new coolant.





Coolant flow tests


If the LED display on the gas console shows a coolant flow error (093 or 060), turn OFF the system and then ON again to clear the error. Then perform the following tests to find the cause of the problem.

An in-line flow meter is the most accurate way to measure the flow rate, but can not be used with all the tests described. An in-line flow meter (part number 128933) is available from Hypertherm. The following “bucket” tests give a good idea of the flow rate.

Before testing

Note: Coolant must be drained from the system before the in-line filter is cleaned (step 1 below). The coolant in the system will drain out as soon as the in-line filter is removed.


1. Clean the in-line filter.
2. Replace the filter on the rear of the power supply.
3. Verify that the system has the correct level of coolant, when refilling the system after completing steps 1 and 2.



Using the Hypertherm flow meter (128933)

Use the steps below to get an accurate reading from the flow meter.


1. Hold the flow meter upright. Square in both axis.
2. Take your reading from the edge shown below.



Manual pump operation

If the LED display on the gas console shows coolant flow error 093, the pump must be turned on manually within 12 seconds of turning on the power supply, or the power will have to be turned off and then on again.

1. Turn ON the power. Press and hold the current selection knob (8) to turn on the pump manually, and allow the coolant to flow for 60 seconds.



2. Write down the coolant flow rate shown on the gas console's LED display. The recorded flow rate will be used for comparison during some of the tests. Coolant flow must be greater than 2.3 lpm (0.6 gpm) for the system to operate.
3. Release the current selection knob (8) and then turn OFF the power.

Note: A flow diagram can be found on schematic 013377, sheet 15 of 19

Test 1 – return line


Note: An in-line flow meter is required to complete this test.

1. Turn OFF the power. Remove the return coolant line (blue hose with red tape), and connect the flow meter to measure the flow rate.
2. Measure the flow rate on the flow meter. Turn ON the power. Turn ON the pump manually (see step 1 under “Manual pump operation”). Write down the flow rate from the flow meter.
3. Reconnect the return coolant line (blue hose with red tape).

If the flow rate is 0.8 gpm or more, go to test 7.

If the flow rate is less than 0.8 gpm, go to test 2.

If there is no flow, go to pump and motor troubleshooting.





Test 2 – supply line at ignition console

Note: Remove the torch-lead coolant hoses to access the supply line.

1. Turn OFF the power. Remove the supply coolant line (blue hose with green tape) from the RHF/LHF console, and place it in a 3.8 liter (1 gallon) container. A Hypertherm coolant container works well.
2. Measure how long it takes to fill the container. Turn ON the power. Turn ON the pump manually (see step 1 under “Manual pump operation”). Write down how long it takes to fill the container.
3. Reconnect the coolant lines.

If the container is full in 65 seconds or less, go to test 3.

If it takes more than 65 seconds to fill the container, go to test 6.



Test 3 – change the torch

1. Replace the torch and consumables with a new torch and new consumables.
2. Turn ON the pump manually (see step 1 under “Manual pump operation”), let it run for 60 seconds, and look at the flow rate on the LED display on the gas console.

If the flow rate shown on the LED display is 0.9 gpm or more, replace the torch.

If the flow rate is still less than 0.9 gpm, go to test 4.

Test 4 – supply line to the torch receptacle

1. Turn OFF the power. Remove the coolant supply line from the torch receptacle, and place it in a 3.8 liter (1 gallon) container. A Hypertherm coolant container works well.

Caution: Coolant will flow from the hose very quickly.



2. Measure how long it takes to fill the container. Turn ON the power. Turn ON the pump manually (see step 1 under “Manual pump operation”). Write down how long it takes to fill the container.
3. Reconnect the coolant supply line to the torch receptacle.

If it takes more than 65 seconds to fill the container, look for an obstruction or kink in the coolant hose between the torch and the LHF/RHF console. If there is no obstruction or kink, replace the torch leads.


If the container is full in 65 seconds or less, go to test 5.

Test 5 – return line from the torch receptacle (remove at the ignition console)

1. Turn OFF the power. Remove the return coolant line (blue hose with red tape) from the RHF/LHF console, and place it in a 3.8 liter (1 gallon) container. A Hypertherm coolant container works well.
2. Measure how long it takes to fill the container. Turn ON the power. Turn ON the pump manually (see step 1 under “Manual pump operation”). Write down how long it takes to fill the container.
3. Reconnect the return coolant line.

If it takes more than 65 seconds to fill the container, there is an obstruction in the torch receptacle. Replace the torch receptacle.

If the container is full in 65 seconds or less, there is an obstruction in the return coolant line (from the RHF/LHF console to the power supply). Replace the return coolant line.




Test 6 – bucket test at the pump

1. Turn OFF the power. Remove the pump outlet, coolant line, and place it in a 3.8 liter (1 gallon) container.
A Hypertherm coolant container works well.
2. Measure how long it takes to fill the container. Turn ON the power. Turn ON the pump manually (see step 1 under “Manual pump operation”). Write down how long it takes to fill the container.


If it takes more than 65 seconds to fill the container, replace the pump and check the motor shaft for damage.

If it takes less than 65 seconds to fill the container, check the coolant supply line (from the power supply to the RHF/ LHF console) for kinks. If no kinks are found, replace the by-pass valve and the hoses between the power supply and RHF/ LHF console.




Test 7 – bypass the check valve


1. Turn OFF the power. Remove the hose from the relief valve.




2. Remove the push-to-connect fitting from the relief valve.



3. Remove the relief valve.



4. Install the push-to-connect fitting and connect the hose.




Test 7 – continued

5. Turn ON the power supply, and note the coolant flow rate shown on the LED display on the gas console.

If the flow shown on the LED display is more than 0.8 gpm, replace the check valve. Coolant will drain out of the torch during every consumable change if the check valve is bypassed.

If the flow shown on the LED display is less than 0.8 gpm, replace the flow switch.

Note: The check valve must be oriented correctly. The arrow points up, as shown.



Check valve orientation

Pump and motor troubleshooting

Is the motor LED illuminated on the control board?

Is the motor on?

If the LED is illuminated, but the pump is not running, turn the pump on manually.

If the motor will not turn on, verify that the fuse is OK, and make sure there is power to the motor.

If you are still not getting flow from the pump, verify that the solenoid valve and check valve are working correctly.

Gas leak tests

The system has two automatic leak test modes. The leak test mode is activated by switching the shield gas selector switch (2) to the TEST position and then switching the RUN/SET switch (7) to either SET PREFLOW or SET CUTFLOW to begin the leak test.

Leak test mode 1 – With switch 7 in the SET PREFLOW position.

The inlet valves within the gas console will close and the off-valves will open to allow any trapped gas to escape. After 20 seconds all the off-valves will close. At this point there should be no pressure between the gas console and off-valve, and the pressure displays should read zero.

This test is intended to identify a problem with any inlet supply valve that does not close properly in the gas console, in which case pressure will build at the off-valve and be displayed on the gas console. This test also checks for leaks in the supply lines.

Leak Check Mode 2 – Switch 7 in the SET CUTFLOW position.

The inlet valves will open and pressurize the gas lines between the off-valve and the gas console. After 20 seconds all inlet valves are turned off. The pressures displayed should remain constant.

This test is intended to identify a leak between the gas console and the off-valve.


Leak test 1

1. Turn ON power to the HPR260.
2. After initial gas purge switch shield selector switch (2) to TEST.
3. Select SET PREFLOW on switch 7. The off-valve opens and exhausts gas between the gas console and torch. The inlet valves in gas console will remain closed.
4. The off-valve will close after 20 seconds.
5. Close gas supply valves.
6. Monitor the pressure displays and the gas supply pressure gauges for 20 minutes. The pressure displays should remain at or close to zero while inlet pressures remain constant.
7. If any pressure display increases, then one or more inlet valves in the gas console are not closing properly.
8. If a gas supply pressure gauge decreases but no pressure is displayed on gas console, then there is a leak in the supply hoses between the shut-off and the gas console.

Leak test 2


1. After performing leak test 1, turn on gas supply valves again and move switch 7 to SET CUTFLOW. The inlet valves in the gas console will open for 20 seconds and then close, while the off-valve remains closed. This traps pressure between the gas console and the off-valve.
2. Close the gas supply valves.
3. Monitor the pressure displays on the gas console and the gas supply pressure gauges for 20 minutes. Pressure displays and gas supply gauges should remain constant.
4. If any pressure displays decrease, then there is a leak in a gas line between the gas console and the off-valve.
5. If a gas supply pressure gauge decreases then there is a leak in the supply hoses between the shut-off and the gas console.

Power supply control board PCB3



Control PCB LED list		
LED	Signal name	Notes
D100	+5 VDC	
D101	+3.3 VDC	
D113	CAN TX	Constant blinking
D114	CAN RX	Constant blinking
D117	RS-422 TX	
D118	RS-422 RX	



Control PCB3 firmware list	
Item	Part number
U104	081169 EVEN
U105	081169 ODD



Control PCB LED list			
LED	Output	Input	Notes
D321	Machine motion		
D322	Error		
D323	Rampdown error		
D324	Not ready		
D325	Spare		Not used
D326	Pilot arc enable		
D327		Hold	
D328		Pierce	
D329		Corner current	
D330		Plasma start	

Control PCB LED list			
LED	Output	Input	Notes
D331	HV transformer		
D332	Pump motor enable		
D333	Contactor		
D334	Pilot arc relay		
D335	Spare		
D336	Surge select		
D337		Phase loss	

Power supply power distribution board PCB2



Power distribution PC board LED list		
LED	Output	Color
D1	Contactor	Red
D2	Pilot arc relay	Red
D3	120 VAC (switched)	Green
D5	HF ignition	Red
D7	Surge select	Red
D12	24 VAC (switched)	Green
D23	240 VAC (switched)	Green
D25	+ 24 VDC	Red
D26	Pump motor	Green
D31	+ 5 VDC	Red
D32	- 15 VDC	Red
D33	+ 15 VDC	Red
D35	24 VAC	Green


Start-circuit PCB1

Operation

The start circuit is a high-speed switch that quickly transfers the pilot arc current from the pilot arc lead to the work lead. The start circuit performs 2 functions:

1. It allows the initial pilot arc current to flow through the pilot arc lead quickly, with little impedance.
2. After initial pilot arc current is established, the start circuit introduces impedance to the pilot arc lead to aid in transferring the arc to the workpiece. See schematic below.

Start circuit functional schematic



Start circuit troubleshooting



		DANGER SHOCK HAZARD
<p>Always use caution when servicing a power supply when plugged in and the covers are removed. Dangerous voltages exist within the power supply which could cause injury or death.</p>		

D2 should always be illuminated.

D1 illuminates as soon as the torch fires and will extinguish as soon as the arc transfers to the workpiece. If arc transfer is immediate, the LED will not illuminate.

If there is no arc at the torch or if the arc will not transfer:

1. Turn OFF all power to the system.
2. Remove wires from H8 (WORK) and H9 (NOZZLE) studs on the board.
3. Verify a resistance of about (\approx) 5.5 k Ω between H8 and D50 (-). If the resistance value is not correct, replace the board.
Note: Resistance value may slowly increase to the correct value due to the capacitance in the circuit.
4. Verify a resistance of about (\approx) 15 k Ω between snubber and H8.
 - The work lead should not have any cuts or breaks. Verify a resistance of 1 Ω or less. The work lead connection to the cutting table should be clean and have good contact to the table.
 - Verify that LED-D2 is illuminated. If it is not illuminated, the board may need to be replaced or the board may not be receiving power.
 - Fire the torch in the air and verify that D1 is illuminated. If it is not illuminated, but a pilot arc is established, the board may need to be replaced.
 - Verify a resistance of about (\approx) 1 Ω across the R1 resistor.




Pilot arc current levels

The pilot arc current level will change depending on the chosen process and arc current level. See table below.

Pilot arc current							
Plasma gas	30-amps	45-amps	50-amps	80-amps	130-amps	200-amps	260-amps
O ₂	25	30	30	30	30	40	40
N ₂	25	30	30	30	35	40	40
H35	25	30	30	30	35	40	40
F5	25	30	30	30	35	40	40
Air	25	30	30	30	35	40	40

Transfer current							
Plasma gas	30-amps	45-amps	50-amps	80-amps	130-amps	200-amps	260-amps
O ₂	10	10	10	10	15	20	20
N ₂	10	10	10	10	15	20	20
H35	10	10	10	10	15	20	20
F5	10	10	10	10	15	20	20
Air	10	10	10	10	15	20	20

Gas console control board PCB2





Control PCB2 firmware list	
Item	Part number
U17	081109 EVEN
U18	081109 ODD

Gas console control board LEDN list		
LEDN	Signal name	Color
LEDN1	Plasma preflow, left digit	Red
LEDN2	Plasma preflow, right digit	Red
LEDN3	Plasma cutflow, left digit	Red
LEDN4	Plasma cutflow, right digit	Red
LEDN5	Shield preflow, left digit	Red
LEDN6	Shield preflow, right digit	Red
LEDN7	Shield cutflow, left digit	Red
LEDN8	Shield cutflow, right digit	Red
LEDN9	Current, left digit	Red
LEDN10	Current, center digit	Red
LEDN11	Current, right digit	Red

Gas console control board LED list		
LED	Signal name	Color
D1	+ 5 VDC	Green
D2	+ 3.3 VDC	Green
D4	Coolant error	Yellow
D6	Pressure error	Yellow
D8	CAN- TX	Green
D9	CAN- RX	Green
D10	Voltage error	Yellow
D11	Temperature error	Yellow


Gas console power distribution board PCB1




Gas console control board LED list

LED	Signal name	Color
D1	120 VAC (switched)	Green
D7	+ 5 VDC	Red
D9	+ 24 VDC	Red



Gas console, AC valve-driver board PCB3



LED	Signal name	Color	LED	Signal name	Color
D1	SV1	Red	D11	SV11	Red
D2	SV2	Red	D12	SV12	Red
D3	SV3	Red	D13	SV13	Red
D4	SV4	Red	D14	SV14	Red
D5	SV5	Red	D15	SV15	Red
D6	SV6	Red	D16	SV16	Red
D7	SV7	Red	D17	SV17	Red
D8	SV8	Red	D18	SV18	Red
D9	SV9	Red	D19	SV19	Red
D10	SV10	Red	D20	SV20	Red



Chopper tests

		<p style="text-align: center;">WARNING SHOCK HAZARD</p>
<p>Use extreme care when working near the chopper modules. Each large electrolytic capacitor (blue-cased cylinder) stores large amounts of energy in the form of electric voltage. Even if the power is off, dangerous voltages exist at the capacitor terminals, on the chopper, and the diode heatsinks. Never discharge any capacitor with a screwdriver or other implement... explosion, property damage and/or personal injury will result.</p>		


Automatic chopper and current sensor tests during power-up

Turn ON the system. When the preflow starts, the contactor will close and the system will automatically test the choppers and current sensors. The system closes the contactor and turns on chopper 1 at 90% duty cycle. The chopper will charge the surge capacitor on the I/O board (PCB 6). The current that charges the capacitor should be between 10 amps and 35 amps. Error code 105 will appear in the LED display if the current is < 10 amps or there is no feedback on current sensor 1 (CS1). Error code 103 will appear in the LED display if the current is > 35 amps.

If chopper 1 passes the test, the system will repeat the test for chopper 2, and current sensor 2 (CS2). Error code 106 will appear in the LED display if the current is < 10 amps. Error code 104 will appear in the LED display if the current is > 35 amps.


Place the toggle switch in the ERROR position if the system completes the power up sequence. If the system shows error code 003 the test passed. The choppers and current sensors are OK.

If error code number 103, 104, 105, or 106 are displayed, continue with the tests below.



Troubleshooting low-current error codes 105 and 106

1. Verify that the current sensors (CS1 and CS2) and cables are not damaged.
2. Exchange CS1 and CS2. Replace the faulty sensor if the error code is not displayed again.
3. Measure the resistance between wire 38 and wire 39 on PCB6 with a meter. The value should be increasing as the capacitor charges. Replace PCB6 if a constant value is seen.
4. Check for loose wires or shorts from the chopper to PCB6.
5. Check for 220 VAC to 1A, 1B, and 1C on the chopper when the contactor closes.




Troubleshooting high-current error codes 103 and 104


1. Verify that the current sensors (CS1 and CS2) and cables are not damaged.
2. Exchange CS1 and CS2. Replace the faulty sensor if the error the code is not displayed again.
3. Look at the surge capacitor to ensure that it is not short-circuited. Replace PCB6 if the surge capacitor is shorted.
4. Check for short circuits from the work terminal to the negative terminal on PCB6. Resistance should be about 100K ohm from the work terminal to the negative terminal. Resistance will vary if you have a voltage divider for a height control system.

Phase-loss detection test


1. Turn OFF all power to the system and remove the cover from CON1.



2. Inspect the condition of the 3 contacts for excessive wear. If one of more of the contacts are worn excessively, replace CON1 and restart the system. If the error remains, perform the following steps.




OK



Excessive wear

3. Test the fuses F5, F6, and F7 on the power distribution board (PCB2). If any of the fuses are blown, replace PCB2.



4. Remove J2.8 from PCB2 and place a jumper between pins 1 and 2 on the cable connector.
 - a. Make a test cut. If the phase-loss error continues, verify wiring between J2.8 on PCB2 and J3.302 on PCB3 by verifying the continuity between
 - J2.8 pin1 to J3.302 pin14
 - J2.8 pin2 to J3.302 pin15.
 - b. If the wiring is ok replace PCB3. If any wiring is damaged repair or replace damaged wires.
 - c. If the phase-loss error goes away while the jumper is on J2.8, make another cut and measure the phase-to-phase voltage across the fuses, F5, F6, and F7. The voltage should be 220 VAC +/-15%. If one of the 3 voltage readings is less than 187 VAC, check the contacts to the contactor, and check for loose connections between the power cord – contactor – power transformer – and the chopper.




WARNING SHOCK HAZARD



Always use caution when servicing a power supply when plugged in and the covers are removed. Dangerous voltages exist within the power supply which could cause injury or death.

Torch lead test


1. Turn OFF all power to the system.
2. Locate the start circuit assembly.



3. Install a temporary jumper wire between H8 (work) and H9 (nozzle) on the start circuit PCB1.



4. Locate the pilot arc relay (CR1) and remove the dust cover. Have a second person close the contact.



5. Measure the ohm value between the nozzle and the plate. The reading should be less than 3 ohms. A measurement of greater than 3 ohms indicates a faulty connection between the torch and ignition console or between the ignition console and the power supply.
6. Verify that the pilot arc wire on the torch lead is not damaged. If it is damaged replace the lead. If it is not damaged replace the torch head.

Preventive maintenance

Hypertherm created a Preventive Maintenance Program (PMP) specifically for your plasma system. The PMP has two parts: a cleaning and inspection schedule and a component replacement schedule.

See the *HPR800XD Auto Gas Preventive Maintenance Program Instruction Manual (808640)* for part numbers.

If you have questions about how to maintain your plasma system, contact your OEM or regional Hypertherm Technical Service team. You can find contact information for each regional office at www.hypertherm.com/global on the “Contact us” page after choosing your language.

This document refers to your system’s instruction manual. If you do not have your instruction manual, you can find it in the Hypertherm downloads library:

1. Go to www.hypertherm.com/global
2. Choose your language.
3. Click Downloads library.
4. Enter your instruction manual’s part number in the Part number field.
 - HPR260XD Manual Gas Instruction Manual: 806340

Section 6

PARTS LIST


In this section

Power supply	6-2
Ignition console	6-7
Torch lead junction box (Optional).....	6-8
Ignition console to junction box leads	6-9
Gas console	6-10
Off-valve.....	6-11
HyPerformance torch	6-12
Torch assembly	6-12
Torch leads	6-13
Ohmic contact wire.....	6-13
Consumable parts kits	6-14
Consumables for mirror-image cutting	6-16
Straight cutting	6-16
Bevel cutting.....	6-18
Recommended spare parts	6-19
Warning Label – 110647.....	6-20

Power supply


Power supplies		
Without Hypernet	With Hypernet	Voltage (AC)
078554	078562	200/208
078555	078563	220
078556	078564	240
078557	078565	380
078558	078566	400
078605	078606	415
078559	078567	440
078560	078568	480
078561	078569	600

Note: The Hypernet option is currently used with the ArcGlide® torch height control. See the ArcGlide instruction manual (806450) for more information.



Item	Part Number	Description	Designator	Qty.
1	See table above	Power supply		
2	228332	Panel: Top, with label		1
3	075241	Sheet metal screws		1
4	228535	Panel: Right or left side, with label		1
5	228534	Panel: Front, with label		1
6	129633	Green power lamp assembly		1
8	228611	Kit: Hypernet upgrade (not shown)		1


Power supply



Item	Part Number	Description	Designator	Qty.
1	027634	Filter housing		1
	027664	Filter element		1
2	127014	Cap: Coolant reservoir		1
3	229034*	EMI filter: 80 amp, 50-60 HZ		1
4	129792	Chopper assembly	CH1, CH2	2
5	127039	6" fan: 230 CFM, 115 VAC 50-60 HZ		4
6	027079	10" fan: 450-550 CFM, 120 VAC 50-60 HZ		3
7	014295	200 volt main transformer: 45.5 KW, 3 ph, 50 HZ	T2	1
	014296	220 volt main transformer: 45.5 KW, 3 ph, 50-60HZ		1
	014297	240 volt main transformer: 45.5 KW, 3 ph, 60 HZ		1
	014302	380 volt main transformer: 45.5 KW, 3 ph, 50 HZ		1
	014295	400 volt main transformer: 45.5 KW, 3 ph, 50 HZ		1
	014295	415 volt main transformer: 45.5 KW, 3 ph, 50 HZ		1
	014296	440 volt main transformer: 45.5 KW, 3 ph, 50-60 HZ		1
	014297	480 volt main transformer: 45.5 KW, 3 ph, 60 HZ		1
	014298	600 volt main transformer: 45.5 KW, 3 ph, 60 HZ		1
	228309	Kit: Thermistor replacement for main transformer		1


* 400/415 volt power supply only

Power supply



<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
1	003149	Relay: Pilot arc, 120 VAC	CR1	1
2	041837	PCB: I/O	PCB6	1
3	003217	Contactor (200 VAC - 240 VAC)	CON1	1
	003233	Contactor (380 VAC - 600 VAC)	CON1	1
4	229238	Start circuit assembly	PCB1	1
5	109483	Current sensor: Hall 200 amp, 4 volt	CS3	1
6a	109004	Current sensor: Hall 100 amp, 4 volt	CS2	1
6b	109004	Current sensor: Hall 100 amp, 4 volt	CS1	1
7	014280	Inductor: 4 MH		2

Power supply




Item	Part Number	Description	Designator	Qty.
1	008551*	Fuse: 7.5 amp, 600 volt	F1, F2	2
	008709**	Fuse: 20 amp, 500 volt	F1, F2	2
2	228548	Control PCB	PCB3	1
3	041802	Power distribution PCB	PCB2	1
	108028	Fuse: 3 amp		1
	108075	Fuse: 6.3 amp		1
	108709	Fuse: 10 amp		1
4	027926	Filter assembly: 1/2" NPT low profile		1
5	229206	Flow switch assembly	FLS	1
6	229066	Heat exchanger assembly		1
7	127039***	Fan (for pump motor): 230 cfm, 115 VAC, 50-60 Hz		1
8	129786	Control transformer: 200/208 volt, 50-60 HZ	T2	1
	229117	Control transformer: 220 volt, 50-60 HZ		1
	129966	Control transformer: 240 volt, 60 HZ		1
	229094	Control transformer: 380 volt, 50 HZ		1
	129787	Control transformer: 400 volt, 50-60 HZ		1
	229451	Control transformer: 415 volt, 50-60 HZ		1
	229013	Control transformer: 440 volt, 50-60 HZ		1
	129967	Control transformer: 480 volt, 50-60 HZ		1
	129989	Control transformer: 600 volt, 50-60 HZ		1

*380, 400, 415, 440, 480, and 600 volt power supplies

**200/208 and 240 volt power supplies


***415 volt power supply only

Power supply



<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
1	109393	Temperature sensor	T2	1
2	006132	Check valve (relief valve): 1/4" NPT, 200 psi		1
3	006075	Check valve: 1/4" FPT		1
4	229229	Solenoid valve assembly: 3/8", 240 volt	CLT SOL	1
5	228171	Kit: Pump with clamp		1
6	228230	Kit: Motor with clamp		1
	031122	Pump to motor shaft coupler (not shown)		1

Ignition console




<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
1	078172	Ignition Console		
2	129831	Coil assembly	T2	1
3	041817	HFHV Ignition PCB	PCB IGN	1
4	129854	Transformer	T1	1

Ignition console to junction box leads




Caution: **Total lead length from the ignition console to the torch must be less than or equal to:**
20 m (65 feet) for HPR130XD / HPR260XD
15 m (50 feet) for HPR400XD / HPR800XD

Part no.	Description	Part no.	Description
428420	3 m (10 ft)	428425	10 m (35 ft)
428421	4.5 m (15 ft)	428426	12.2 m (40 ft)
428339	5.5 m (18 ft)	428427	13.7 m (45 ft)
428422	6 m (20 ft)	428428	15 m (50 ft)
428423	7.5 m (25 ft)	428429	16.8 m (55 ft)
428424	9.1 m (30 ft)		

Torch lead junction box (Optional)


<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Qty.</u>
	078619	HPRXD junction box	1
1	015007	Coolant fitting	4
2	104763	Pilot arc fitting	1
3	104762	Coolant block	1

Gas console



Item	Part Number	Description	Designator	Qty.
1	078532	Gas Console		
2	041805	Power distribution PCB	PCB1	1
	008756	Fuse: 5 amp, 250 volt		1
3	041822	Valve driver PCB	PCB3	1
	008756	Fuse: 5 amp, 250 volt		1
4	005263	Pressure sensor	PT1-PT4	4
5	006109	Solenoid valve	SV2, SV3, SV4, SV6, SV8-SV14	11
	006112	Replacement solenoid coil		
6	228984	Solenoid valve	SV1, SV5, SV7	3
7	005262	Illuminated power switch	SW1	1


Gas console



<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
1	041912	Control PCB	PCB2	1
2	229128	Regulator assembly with elbow fitting	PR1, PR3, PR4	3
3	229129	Regulator assembly with elbow and tee fitting	PR2	1
	228147	Kit: Regulator upgrade (replaces all 4 regulators)		
4	011109	Filter assembly		1
	011110	Filter element		1


Off-valve

<u>Item</u>	<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
	078534	Off valve assembly		1
1	006109	Solenoid valve	V16-V20	5
	006112	Replacement solenoid coil		5
2	123748	Off-valve cable		1



HyPerformance torch


Torch assembly



<u>Item</u>	<u>Part Number</u>	<u>Description</u>
1	228521	HPR260 machine torch assembly
2	220706	Quick-disconnect torch
3	220571	Water tube
4	220705	Quick-disconnect receptacle
5	220789	Torch mounting sleeve assembly: Standard, 181 mm (7 in)
	220788	Torch mounting sleeve assembly: Short, 114 mm (4.5 in)
	220790	Torch mounting sleeve assembly: Long, 248 mm (9.75 in)
6	104269	2" spanner wrench
	128879	Torch kit: o-rings, water tube and seal
	128880	Quick disconnect kit: o-ring and connector

Torch leads

Part no.	Description
228291	2 m (6 ft)
228292	3 m (10 ft)
228293	4.5 m (15 ft)
228294	6 m (20 ft)
228295	7.5 m (25 ft)
228296	10 m (35 ft)
228297	15 m (50 ft)
228547	20 m (65 ft)

Ohmic contact wire (Not part of the HPR260XD system. Shown for reference only.)

Part no.	Length
123983	3 m (10 ft)
123984	6 m (20 ft)
123985	7.5 m (25 ft)
123986	9 m (30 ft)
123987	12 m (40 ft)
123988	15 m (50 ft)
123989	23 m (75 ft)
123990	30 m (100 ft)
123991	45 m (150 ft)

Consumable parts kits

Note: See *Consumable selection* or *Cut charts* for specific applications

Mild steel consumable starter kit – 228422

Part Number	Description	Qty.
026009	O-ring: 0.208" X 0.070"	5
027055	Lubricant: Silicone 1/4-oz tube	1
044028	O-ring: 1.364" X 0.070"	2
104119	Tool: Consumable removal / replacement	1
104269	Wrench: Spanner	1
220179	Swirl ring: 80 A/130	1
220180	Swirl ring: 30 A	1
220181	Electrode: 130 A	2
220182	Nozzle: 130 A	3
220183	Shield: 130 A	2
220187	Electrode: 80 A	2
220188	Nozzle: 80 A	2
220189	Shield: 80 A	1
220192	Electrode: 30 A	2
220193	Nozzle: 30 A	2
220194	Shield: 30 A	1
220340	Water tube with o-ring	1
220352	Electrode: 200 A	2
220353	Swirl ring: 200 A	1
220354	Nozzle: 200 A	3
220435	Electrode: 260 A	2
220436	Swirl ring: 260 A	1
220439	Nozzle: 260 A	3
220552	Electrode: 50 A	2
220553	Swirl ring: 50 A	1
220554	Nozzle: 50 A	2
220555	Shield: 50 A	1
220637	Shield cap	1
220665	SilverPlus Electrode: 130 A	1
220666	SilverPlus Electrode: 200 A	1
220668	SilverPlus Electrode: 260 A	1
220747	Shield cap: 130 A	1
220754	Nozzle retaining cap: 30 A	1
220756	Nozzle retaining cap: 130 A	1
220757	Nozzle retaining cap: 200 A	1
220760	Nozzle retaining cap: 260 A	1
220761	Shield: 200 A	2
220764	Shield: 260 A	2

Stainless steel and Aluminum consumable starter kit – 228423

Part Number	Description	Qty.
026009	O-ring: 0.208" X 0.070"	5
027055	Lubricant: Silicone 1/4-oz tube	1
044028	O-ring: 1.364" X 0.070"	2
104119	Tool: Consumable removal / replacement	1
104269	Wrench: Spanner	1
220179	Swirl ring: 80 A/130 A	1
220180	Swirl ring: 30 A	2
220197	Nozzle:130 A	2
220198	Shield:130 A	1
220307	Electrode:130 A	4
220337	Nozzle:80 A	2
220338	Shield:80 A	1
220339	Electrode:80 A	4
220340	Water tube	1
220342	Swirl ring:200 A	1
220343	Nozzle:200 A	2
220405	Swirl ring:260 A	1
220406	Nozzle:260 A	2
220637	Shield cap	1
220747	Shield cap:130 A	1
220755	Nozzle retaining cap:130 A (CCW)	1
220758	Nozzle retaining cap:260 A	1
220762	Shield:200 A	1
220763	Shield:260 A	1
220814	Nozzle retaining cap: 60 A HDi	1
220815	Shield: 60 A HDi	1
220847	Nozzle: 60 A HDi	2


Consumables for mirror-image cutting

Straight cutting

Mild steel

	Shield cap	Shield	Nozzle retaining cap	Nozzle	Swirl ring	Electrode	Water tube
30 A		220194	220810	220193	220306	220192	
50 A		220555	220810	220554	220549	220552	
80 A	220747	220189	220755	220188	220305	220187	
130 A		220183	220755	220182	220305	220181	220340
200 A		220761	220811	220354	220350	220352	
260 A	220637	220764	220812	220439	220442	220435	


Stainless steel




PARTS LIST

Bevel cutting

Mild steel



Stainless steel



Recommended spare parts

Power supply

<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
129633	Green power lamp assembly		1
027634	Filter housing		1
027664	Filter element		1
129792	Chopper assembly	CH1	1
127039	6" fan: 230 CFM, 115 VAC 50-60 HZ		1
027079	10" fan: 450-550 CFM, 120 VAC 50-60 HZ		1
003149	Relay: Pilot arc, 120 VAC	CR1	1
041837	PCB: I/O		1
003217	Contactora (200 VAC-240 VAC)	CON1	1
003233	Contactora (380 VAC-600 VAC)	CON1	1
109004	Current sensor: Hall 100 amp, 4 volt		1
229238	Start circuit assembly	PCB1	1
008551*	Fuse: 7.5 amp, 600 volt	F1, F2	2
228548	Control PCB	PCB3	1
041802	Power distribution PCB	PCB2	1
229206	Flow switch assembly	FLS	1
006075	Check valve: 1/4" FPT		1
229229	Solenoid valve assembly	CLT SOL	1
228171	Pump assembly with clamp: 80 gpm, 200 psi		1
228230	Motor with clamp: 1/3 HP, 240 volt, 50-60 HZ		1

* 400, 415, 480, and 600 volt power supplies

Ignition console

<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
041817	HFHV Ignition PCB		1
129854	Transformer	T1	1

Gas console

<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
041805	Power distribution PCB	PCB1	1
041822	Valve driver PCB	PCB3	1
005263	Pressure sensor	PT1-PT3	1
006109	Solenoid valve	SV1-SV14	2
005262	Illuminated power switch	SW1	1

Off-valve

<u>Part Number</u>	<u>Description</u>	<u>Designator</u>	<u>Qty.</u>
006109	Solenoid valve	V16-V19	1

Warning Label – 110647

This warning label is affixed to some power supplies. It is important that the operator and maintenance technician understand the intent of these warning symbols as described. The numbered text corresponds to the numbered boxes on the label.




1. Cutting sparks can cause explosion or fire.
 - 1.1 Do not cut near flammables.
 - 1.2 Have a fire extinguisher nearby and ready to use.
 - 1.3 Do not use a drum or other closed container as a cutting table.
2. Plasma arc can injure and burn; point the nozzle away from yourself. Arc starts instantly when triggered.
 - 2.1 Turn off power before disassembling torch.
 - 2.2 Do not grip the workpiece near the cutting path.
 - 2.3 Wear complete body protection.
3. Hazardous voltage. Risk of electric shock or burn.
 - 3.1 Wear insulating gloves. Replace gloves when wet or damaged.
 - 3.2 Protect from shock by insulating yourself from work and ground.
 - 3.3 Disconnect power before servicing. Do not touch live parts.
4. Plasma fumes can be hazardous.
 - 4.1 Do not inhale fumes.
 - 4.2 Use forced ventilation or local exhaust to remove the fumes.
 - 4.3 Do not operate in closed spaces. Remove fumes with ventilation.
5. Arc rays can burn eyes and injure skin.
 - 5.1 Wear correct and appropriate protective equipment to protect head, eyes, ears, hands, and body. Button shirt collar. Protect ears from noise. Use welding helmet with the correct shade of filter.
6. Become trained. Only qualified personnel should operate this equipment. Use torches specified in the manual. Keep non-qualified personnel and children away.
7. Do not remove, destroy, or cover this label. Replace if it is missing, damaged, or worn.

WIRING DIAGRAMS

Introduction

This section contains the wiring diagrams for the system. When tracing a signal path or referencing with the *Parts List* or **Troubleshooting** sections, please be aware of the following format to assist you in understanding the wiring diagrams' organization:











































- Sheet numbers are located in the lower right-hand corner.
- Page-to-page referencing is done in the following manner:






























Destination and **Source Coordinates** refer to letters A-D on the Y-axis of each sheet and numbers 1-4 on the X-axis of each sheet. Lining up the coordinates will bring you to the source or destination blocks (similar to a road map).


Wiring Diagram Symbols


Wiring diagram symbols and their identification precede the system wiring diagrams in this section.

	Battery		Fuse		Push Button, Normally Closed
	Cap, polarized		Ground Clamp		Push Button, Normally Open
	Cap, non-polarized		Ground, Chassis		Receptacle
	Cap, feed-thru		Ground, Earth		Relay, Coil
	Circuit breaker		IGBT		Relay, Normally Closed
	Coax shield		Inductor		Relay, Normally Open
	Current Sensor		LED		Relay, Solid State, AC
	Current sensor		Lamp		Relay, Solid State, DC
	DC supply		MOV		Relay, Solid State, Dry
	Diode		Pin		Resistor
	Door interlock		Socket		SCR
	Fan		Plug		Shield
	Feedthru LC		PNP Transistor		Shunt
	Filter, AC		Potentiometer		Spark Gap

	Switch, Flow		Switch, Level, Normally Closed		Switch, Pressure, Normally Closed		Switch, Pressure, Normally Open		Switch, 1 Pole, 1 Throw		Switch, 1 Pole, 2 Throw		Switch, 1 Pole, 1 Throw, Center Off		Switch, Temperature, Normally Closed		Switch, Temperature, Normally Open		Terminal Block		Time Delay Closed, NC/Off		Time Delay Open, NO/Off
	Time Delay Open, NC/On		Time Delay Closed, NO/Off		Transformer		Transformer, Air Core		Transformer Coil		Triac		VAC Source		Valve, Solenoid		Voltage Source		Zener Diode				
<hr/>																							
												Torch Symbols											
																							
																							
																							
																							
																							

Discrete output functionality







ELEC SCH: HPR260XD POWER SUPPLY


013377

SHEET 1 OF 19










ELEC SCH:HPR260XD POWER SUPPLY

013377

SHEET 4 OF 19










ELEC SCH:HPR260XD POWER SUPPLY

013377

SHEET 5 OF 19









ELEC SCH:HPR260XD POWER SUPPLY

013377

SHEET 6 OF 19






ELEC SCH:HPR260XD POWER SUPPLY

013377

SHEET 7 OF 19







ELEC SCH:HPR260XD POWER SUPPLY


013377


SHEET 8 OF 19















ELEC SCH:HPR260XD POWER SUPPLY


013377

SHEET 14 OF 19







Optional Multi-System Interface



- Notes:
- 1) For single system installations set Serial ID (S100), and Machine Motion (J303) as shown in Unit 1, jumpers J106 and J107 must be closed.
 - 2) On multi-system installations refer to the illustration. Jumpers J106 and J107 are left open on all systems except for the very last system where they are in the closed position. Termination resistors (120-ohm) or termination jumpers must be installed/set at the CNC for each of the RS-422 RX and TX signal pairs.
 - 3) If a Hypertherm Automation Controller is being used, and there are intermittent communication failures (PS Link Failure), try removing the jumpers on J106 and J107 on the control board, and the termination jumper (J6 or J8) on the serial isolation board in the controller. Only remove the termination jumper on the serial isolation board that is connected to the HPR power supply. See sheet 17 for more details.



ELEC SCH:HPR260XD POWER SUPPLY

013377

SHEET 16 OF 19



Optional Remote On/Off

Notes:


- 1) For single system installation set Serial ID (S100), Machine Motion (J303), J106 & J107 as shown.

Relocate the white wire on TB2 from position #3 to position #2. Connect customer supplied Remote On/Off cable in series with the power supply and the gas console power switch. Connect one terminal of the Remote On/Off cable to position #2 on TB2 and the other terminal to position #3.

Refer to page 3 of the wiring diagram

Depress the Gas Console Power switch to the closed position (on position).
- 2) For a multi-system installation set up as described above, set jumpers as shown on the multi-system interface page
- 3) The CNC will need a dedicated I/O for each system using the Remote On/Off feature (contact should be rated for min. 24Vac, 0.5 Amp)


* If a Hypertherm Automation controller is being used, and there are intermittent communication failures (PS Link Failure), try removing the jumpers on J104 and J105 on the control board, and the termination jumper (J6 or J8) on the serial isolation board in the controller. Only remove the termination jumper on the serial isolation board that is connected to the HPR power supply. See figure below for details.






ELEC SCH: HPR260XD POWER SUPPLY

013377

SHEET 17 OF 19



Optional Command THC Interface



Notes:


- 1) For a single system installation set Serial ID (S100), Machine Motion (J303), J106 & J107 as shown above.
- 2) For a two system installation duplicate a second power supply and Command THC as illustrated for a single system, set Serial ID as shown for the second system.
- 3) For a three system installation set up as described above, set Serial ID as shown for the third system.
- 4) For a four system installation set up as described above, set Serial ID as shown for the fourth system.
- 5) All machine interface cables (Pwr. supply-CNC) used for serial communication between Pwr. supply-CNC will have a common connection node with the CNC.
- 6) The CNC will need a dedicated I/O port for each Command THC.
- 7) If a Hypertherm Automation controller is being used, and there are intermittent communication failures (PS Link Failure), try removing the jumpers on J106 and J107 on the control board, and the termination jumper (J6 or J8) on the serial isolation board in the controller. Only remove the termination jumper on the serial isolation board that is connected to the HPR power supply. See figure on Sheet 19 for details.



S100
Serial ID
Dipswitch
for second system



S100
Serial ID
Dipswitch
for third system




S100
Serial ID
Dipswitch
for fourth system

Dipswitch setting example:

S100



Switch 1 is in the On position
Switches 2-8 are in the Off position




ELEC SCH: HPR260XD POWER SUPPLY

013377

SHEET 18 OF 19



Optional ArcGlide/EdgePro Multi-System Interface



- Notes:
- 1) For the 041993 control board, set Serial ID (S100), and Machine Motion (J303) as shown. Jumpers J106 and J107 should be installed. All 041993 DIPSWITCH and jumper settings are the same; serial IDs are determined by the 141131 board setting.
 - 2) For a single system installation, set SW1 on the 141131 board as shown in Unit 1.
 - 3) For a two system installation, set SW1 on the 141131 boards as shown in Units 1 through 2.
 - 4) For a three system installation, set SW1 on the 141131 boards as shown in Units 1 through 3.
 - 5) For a four system installation, set SW1 on the 141131 boards as shown in Units 1 through 4.

HYPERTHERM TORCH COOLANT SAFETY DATA

In this section:

1 – Identification of the substance/mixture and of the company undertaking.....	a-2
2 – Hazards identification	a-2
3 – Composition/information on ingredients.....	a-3
4 – First aid measures	a-3
5 – Fire-fighting measures.....	a-3
6 – Accidental release measures.....	a-3
7 – Handling and storage	a-4
8 – Exposure controls/personal protection	a-4
9 – Physical and chemical properties	a-4
10 – Stability and reactivity	a-5
11 – Toxicological information.....	a-5
12 – Ecological information.....	a-5
13 – Disposal considerations.....	a-6
14 – Transport information.....	a-6
15 – Regulatory information.....	a-6
16 – Other information	a-7
Freezing Point of Propylene Glycol Solution	a-8

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

1 – IDENTIFICATION OF THE SUBSTANCE/MIXTURE AND OF THE COMPANY UNDERTAKING

Product identifier – Torch Coolant 30% PG Mixture

GHS Product Identifier – **Not applicable.**

Chemical Name – **Not applicable.**

Trade name – **Torch Coolant 30% PG Mixture**

CAS No. – **Not applicable.**

EINECS No. – **Not applicable.**

REACH Registration No. – **Not available.**

Relevant identified uses of the substance or mixture and uses advised against

Identified use(s) – **Industrial use only.**

Uses advised against – **Not available.**

Details of the supplier of the safety data sheet

Company Identification – **Hypertherm**

Telephone – **+1 (603) 643-5638 (USA), +31 (0) 165 596 907 (Europe)**

E-Mail (competent person) – **technical.service@Hypertherm.com**

Address – **P.O. Box 5010, Hanover, NH 03755 USA (USA),
Vaartveld 9, 4704 SE Roosendaal, Nederlands (Europe)**

Emergency telephone number – **(800) 255-3924 (USA), +1 (813) 248-0585 (International)**

Hypertherm®



2 – HAZARDS IDENTIFICATION

EC Classification	NONE	GHS Classification Signal word(s)	NONE
NONE	NONE	NONE	NONE

According to Regulation (EC) No. 1272/2008 (CLP) – NONE

According to Directive 67/548/EEC & Directive 1999/45/EC – NONE

Preparation is not classified as hazardous in the sense of directive 1999/45/EC and 2006/121/EC.

Risk Phrases – NONE



Safety Phrases – NONE

Hazard statement(s) – NONE

Precautionary statement(s) – NONE

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

3 – COMPOSITION/INFORMATION ON INGREDIENTS

HAZARDOUS INGREDIENT 1	% W/W	CAS No.	EC No.	EC Classification
Propylene Glycol	30-50	57-55-6	200-338-0	NONE
GHS Classification				
Not classified				NONE
HAZARDOUS INGREDIENT 2	% W/W	CAS No.	EC No.	EC Classification
Benzotriazole	<1.0	95-14-7	202-394-1	Xn, F
GHS Classification				
WARNING  	Acute Tox. 4 (Oral, Dermal, Inhalation) Eye Irrit. 2, Aquatic Chronic 3			H302, 312, 319, 332, 412

For full text of R phrases see section 16. For full text of H/P phrases see section 16. Non-hazardous components are not listed.

4 – FIRST AID MEASURES

Inhalation	Unlikely to be hazardous by inhalation unless present as an aerosol. Remove patient from exposure.
Skin Contact	Wash skin with water.
Eye Contact	If substance has gotten into the eyes, immediately wash out with plenty of water for several minutes.
Ingestion	Laxative. Do not induce vomiting. If swallowed, seek medical advice immediately and show this container or label.
Further Medical Treatment	Unlikely to be required but if necessary treat symptomatically.

5 – FIRE-FIGHTING MEASURES

Combustible but not readily ignited.

Extinguishing media	Extinguish preferably with dry chemical, foam or water spray
Unsuitable Extinguishing Media	None known
Fire Fighting Protective Equipment	A self contained breathing apparatus and suitable protective clothing should be worn in fire conditions

6 – ACCIDENTAL RELEASE MEASURES


Personal Precautions	Put on protective clothing
Environmental Exposure Controls	Absorb spillages onto sand, earth or any suitable adsorbent material
Other	None

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

7 – HANDLING AND STORAGE

Handling	Unlikely to cause harmful effects under normal conditions of handling and use.
Storage	Keep container tightly closed and dry. Keep away from heat. Keep out of the reach of children. Keep away from oxidizing agents.
Storage Temperature:	Ambient.
Storage Life:	Stable at ambient temperatures.
Specific Use:	Industrial use only.

8 – EXPOSURE CONTROLS/PERSONAL PROTECTION

	Respirators	Normally no personal respiratory protection is necessary. Wear suitable respiratory protective equipment if exposure to levels above the occupational exposure limit is likely. A suitable dust mask or dust respirator with filter type A/P may be appropriate.
	Eye Protection	Safety spectacles.
	Gloves	Wearing of chemical protective gloves is not necessary.
	Body protection	None.
	Engineering Controls	Ensure adequate ventilation to remove vapors, fumes, dust etc.
	Other	None.

OCCUPATIONAL EXPOSURE LIMITS

SUBSTANCE	CAS No.	LTEL (8 hr TWA ppm)	LTEL (8 hr TWA mg/m ³)	STEL (ppm)	STEL (mg/m ³)	Note:
Propylene Glycol	57-55-6	NE	10*	NE	NE	AIHA WEEL in the USA
Benzotriazole	95-14-7	NE	NE	NE	NE	None

9 – PHYSICAL AND CHEMICAL PROPERTIES

Information on basic physical and chemical properties

Appearance – Liquid	Vapor Pressure (mm Hg) – Not available
Color – Pinkish – Reddish	Vapor Density (Air=1) – Not available
Odor – Slight	Density (g/ml) – 1.0 ± 0.1 g/ml
Odor Threshold (ppm) – Not available	Solubility (Water) – Soluble
pH (Value) – 5.5-7.0 (Concentrated)	Solubility (Other) – Not established
Melting Point (°C) / Freezing Point (°C) – < -0°C / (< 32°F)	Partition Coefficient (n-Octanol/water) – Not available
Boiling point/boiling range (°C): >100°C (>212°F)	Auto Ignition Temperature (°C) – Not available
Flash Point (°C) – >95°C (>203°F)	Decomposition Temperature (°C) – Not available
Evaporation rate – Not available	Viscosity (mPa.s) – Not available
Flammability (solid, gas) – Non-flammable	Explosive properties – Not explosive
Explosive limit ranges – Not available	Oxidizing properties – Not oxidizing
Other information – None	

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

10 – STABILITY AND REACTIVITY

Reactivity	None
Chemical stability	Stable under normal conditions
Possibility of hazardous reactions	None
Conditions to avoid	None anticipated
Incompatible materials	Keep away from oxidizing agents
Hazardous Decomposition Product(s)	Carbon monoxide, Carbon dioxide, Nitrogen oxides

11 – TOXICOLOGICAL INFORMATION

11.1.1 – Substances

Acute toxicity	
Ingestion	Low oral toxicity, but ingestion may cause irritation of the gastrointestinal tract
Inhalation	Unlikely to be hazardous by inhalation
Skin Contact	Mild irritant to rabbit skin
Eye Contact	Mild irritant to the eye
Hazard label(s)	None
Serious eye damage/irritation	Mild irritant to the eye
Respiratory or skin sensitization	Mild irritant to rabbit skin
Mutagenicity	Not known
Carcinogenicity	IARC, NTP, OSHA, ACGIH do not list this product or any components thereof as known or suspected carcinogen
Reproductive toxicity	Not known
STOT-single exposure	Not known
STOT-repeated exposure	Not known
Aspiration hazard	Not known

12 – ECOLOGICAL INFORMATION

Toxicity	Do not let this chemical/product enter the environment.
Persistence and degradability	Biodegradable
Bioaccumulative potential	None anticipated
Mobility in soil	The product is predicted to have moderate mobility in soil
Results of PBT and vPvB assessment	None assigned
Other adverse effects	None anticipated

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

13 – DISPOSAL CONSIDERATIONS

Waste treatment methods – Disposal should be in accordance with local, state or national legislation. No special measures are required. No specific waste water pretreatment required.

Additional Information – None

14 – TRANSPORT INFORMATION

Not classified as dangerous for transport.

Transport in bulk according to Annex II of MARPOL73/78 and the IBC Code.

15 – REGULATORY INFORMATION

USA

TSCA (Toxic Substance Control Act) – **Listed.**

SARA 302 – Extremely Hazardous Substances – **Not applicable.**

SARA 313 – Toxic Chemicals – **Not applicable.**

SARA 311/312 – Hazard Categories – **None.**

CERCLA (Comprehensive Environmental Response Compensation and Liability Act) – **Not applicable.**

CWA (Clean Water Act) – CWA 307 – Priority Pollutants – **None.**

CAA (Clean Air Act 1990) CAA 112 – Hazardous Air Pollutants (HAP) – **None.**

Proposition 65 (California) – **Not applicable.**

State Right to Know Lists – **CAS No. 95-14-7 Listed in MA, NJ, PA.**

Canada

WHMIS Classification (Canada) – **Not classified.**

CANADA INGREDIENT DISCLOSURE LIST – **Not applicable.**

Canada (DSL/NDL) – **Listed.**

EU

EINECS (Europe) – **Listed.**

Wassergefährdungsklasse (Germany) – **None.**

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP

16 – OTHER INFORMATION

The following sections contain revisions or new statements: 1–16.


Legend

LTEL	Long Term Exposure Limit
STEL	Short Term Exposure Limit
STOT	Specific Target Organ Toxicity
DNEL	Derived No Effect Level
PNEL	Predicted No Effect Concentration

References:

Risk Phrases and Safety Phrases None. Preparation is not classified as hazardous in the sense of directive 1999/45/EC and 2006/121/EC.
Hazard statement(s) and Precautionary statement(s). None. Preparation is not classified as hazardous in the sense of directive 1999/45/EC and 2006/121/EC.
Training advice – None.
Additional Information USA – NFPA (National Fire Protection Association) – NFPA Rating: Flammability – 1, Health – 0, Instability/Reactivity – 0.
<p>Information contained in this publication or as otherwise supplied to Users is believed to be accurate and is given in good faith, but it is for the Users to satisfy themselves of the suitability of the product for their own particular purpose. Hypertherm gives no warranty as to the fitness of the product for any particular purpose and any implied warranty or condition (statutory or otherwise) is excluded except to the extent that exclusion is prevented by law. Hypertherm accepts no liability for loss or damage (other than that arising from death or personal injury caused by defective product, if proved), resulting from reliance on this information. Freedom under Patents, Copyright and Designs cannot be assumed.</p> <p>Note: Original safety data sheet authored in English</p>

Date	SAFETY DATA SHEET	Revision
6 Dec 2010	Torch Coolant 30% PG Mixture	2.01CLP



Freezing Point of Propylene Glycol Solution

FUNCTIONAL DESCRIPTION OF SOFTWARE

I. Power-up

- a. Processor boots in microprocessor mode and begins to execute code in external flash memory.
- b. Limited initialization of digital-signal processing (DSP) hardware.
- c. Calculate checksum on external flash and on DSP internal flash.
 - If checksums don't match, copy code in external flash to internal flash.
- d. Jump to internal flash and start execution.

II. Initialization

- a. Full initialization of DSP hardware.
- b. Read EEPROM for previous current setpoint.

III. Main loop

- a. Check for serial messages from the internal UART.
 - If valid message is received, parse the message and take action.
- b. Check for serial messages from the external UART.
 - If valid message is received, parse the message and take action.
- c. Check for CAN message.
 - If CAN message has arrived, parse the message and take action.
- d. Check for error conditions every 10 milliseconds.
- e. Refresh data from gas console (i.e. pressures) every 250 milliseconds.
- f. Update the chopper control loop every 26 microseconds.
- g. If an error has occurred, take action.
- h. Update analog inputs.
- i. If current setpoint has changed, update the data in the EEPROM.
- j. If inlet gases change, perform a purge cycle.
- k. Descriptions of machine states
(Numbers listed below do not correspond to actual state numbers.)

1. Idle

- Outputs are off.
- Chopper setpoints = 0.
- 6-second delay for other processors to initialize.
- After delay, wait for CAN watchdog message from the gas console.
- After CAN watchdog messages have been received, send a CAN reset message to the gas console and go to the Purge state.

Error checking

- Verify that Start signal is off (050).
- Check for coolant flow at power-up (109).
- Check for no chopper current (102).
- If no CAN watchdog message after 6-second delay, report error "UNKNOWN GAS CONSOLE" (133).

2. Purge

- Turn on coolant pump or motor.
- Gas console runs preflow gases for 12 seconds.
- After preflow cycle is done, verify coolant flow.
- Gas console runs cutflow gases for 12 seconds.
- Verify that the Plasma Start signal is off before going to Idle2 state.

Error checking

- If coolant flow rate is less than 1.1 lpm (0.3 gpm) (093), shut down the system.
- If coolant flow rate is less than 2.2 lpm (0.6 gpm) (060), continue pumping coolant until flow is above 2.2 lpm (0.6 gpm), with no start allowed at this time.

3. Idle2

- If Start signal is active, the gas console goes into Preflow state, the contactor and the soft-start controller turn on, and system goes into Preflow state.
- If the gas console or serial interface requests a state change, take action.
- After more than 10 seconds since the last Start signal, turn off the contactor and soft-start controller.

Error checking

- Check for coolant flow at power-up (093).
- Check for no chopper current (102).
- Verify that all temperatures are below the specified temperature limits.

4. Preflow_IHS

- Chopper setpoint = pilot arc current.
- Wait for preflow to finish (2 seconds if contactor timeout, otherwise 0.5 seconds) and for the Hold signal to be removed.

Error checking

- Check for coolant flow at power-up (093).
- Check for over/under line voltage (047/046).
- Check for coolant over temperature (071).
- Check for chopper over temperature (065).
- Check for transformer over temperature (067).

5. Pilot Arc

- Turn on pilot arc controller and pilot arc relay.
- Pulse HF after 50-millisecond delay to allow pilot arc relay to close.
- If chopper current = $1/2$ of pilot arc current, turn off HF and go to Transfer state.
- If no chopper current after 10 HF pulses, go to Auto Off state with error code (020), "No pilot arc."

Error checking

- No error checking due to HF noise.

6. Transfer

- If work lead current is $>$ transfer reference current, go to Ramp-up state and turn off pilot arc controller and pilot arc relay.
- If no transfer after 500 milliseconds, go to Auto Off state with error code (021), "No arc transfer."
- If chopper current is $<$ $1/2$ of setpoint, turn on HF.

Error checking

- No error checking due to HF noise.

7. Ramp-up

- If Pierce-complete input is off, then switch to cutflow gases.
- Ramp-up current is based on tables.
- Once chopper current is $=$ or $>$ setpoint, go to Steady state.

Error checking

- Check for coolant flow at power-up (093).
- Check for over/under line voltage (047/046).
- Check for coolant over temperature (071).
- Check for chopper over temperature (065).
- Check for transformer over temperature (067).

8. Steady state

- If Pierce-complete input is off, then switch to cutflow gases.
- If corner-current input is on, then switch to corner-current setpoint.
- If start-signal input is off, then go to Ramp-down state.

Error checking

- Check for loss of phase (027).
- Check for coolant flow at power-up (093).
- Check for over/under line voltage (047/046).
- Check for coolant over temperature (071).
- Check for chopper over temperature (065).
- Check for transformer over temperature (067).
- If chopper current is $<$ $1/2$ of current setpoint, show current lost error (024).
- If work lead current $<$ $1/2$ of setpoint, show transfer lost error (026).

9. Ramp-down

- Do current ramp-down according to tables.
- Put gas console into Idle state or Ramp-down state according to tables.

- Once current reaches end current, go to final Ramp-down state.

Error checking

- Check for coolant flow at power-up (093)

10. Final ramp-down

- Chopper setpoints = 0

Error checking

- Check for coolant flow at power-up (093).

11. Auto-off

- Turn off pilot arc relay, pilot arc controller, HF, and machine motion outputs.
- Preflow gases run for a 10-second postflow period.
- If error has occurred, turn on CNC error output.
- If Ramp-down error has occurred, turn on CNC Ramp-down error output.
- Postflow timer and contactor timer run for 10 seconds.
- If no Start signal, go to Idle2 state.

Error checking

- Check for coolant flow at power-up (093).

12. Shut-down

- Gas console goes to Shut-down state.
- All outputs off.
- CNC error output on.
- Chopper setpoints = 0.
- Wait for reset request.

13. Reset

- Reset CAN controller.
- Initialize timers.
- Go to Idle state.

14. Test cutflow

- Gas console runs cutflow gases.
- Wait for request to go to Idle state or Test Preflow state.

Error checking

- Check for coolant flow at power-up (093).
- Check for no Start signal.

15. Test preflow

- Gas console runs preflow gases.
- Wait for request to go to Idle state or Test Cutflow state.

Error checking

- Check for coolant flow at power-up (093).
- Check for no Start signal

Appendix C

ROBOTIC APPLICATIONS

In this section:

Components for robotic applications.....	c-2
Torch leads	c-2
Ohmic contact extension.....	c-2
Rotational mounting sleeve (optional) – 220864	c-3
Leather overwrap – 024866.....	c-3
Robotic teaching torch (laser pointer) – 228394.....	c-3
Torch and rotational mounting sleeve dimensions.....	c-3
Rotational mounting sleeve clamp dimensions.....	c-4

Components for robotic applications

Torch leads


The torch leads listed below have been designed to withstand the added stresses found in robotic, or bevel, applications. They are available with 2 m (6 ft), or 2.5 m (8 ft) gas leads.

Note: Consumable life will be reduced if the 2.5 m (8 ft) gas leads are used.

Overall length	1.8 M (6 feet) gas lead	2.4 M (8 feet) gas lead
2 m (6 ft)	228514	228516
2.5 m (8 ft)	228515	228517
3 m (10 ft)	228475	228482
3.5 m (12 ft)	228476	228483
4.5 m (15 ft)	228477	228484
6 m (20 ft)	228478	228485
7.5 m (25 ft)	228479	228486
10 m (35 ft)	228480	228487
15 m (50 ft)	228481	228488

Ohmic contact extension


A 2.5 m (8 ft) Ohmic contact wire is part of the lead set. Extensions can be found in the table below.



Part number	Length	Part number	Length
223059	1.5 m (5 ft)	223064	12 m (40 ft)
223060	3 m (10 ft)	223065	15 m (50 ft)
223061	4.5 m (15 ft)	223066	22.5 m (75 ft)
223062	6 m (20 ft)	223067	30 m (100 ft)
223063	9 m (30 ft)	223068	45 m (150 ft)


Rotational mounting sleeve (optional) – 220864

The rotational sleeve is designed for use in applications where the torch leads are twisted repeatedly. It is an optional component, and does not need to be used to use the torch leads listed above. The length of the rotational sleeve is 114.3 mm (4.5 in).



Rotational mounting sleeve clamp – 220900

The rotational sleeve has a larger diameter than standard sleeves (57 mm/2.25 in).




Leather overwrap – 024866


The leather overwrap is 3 m (10 ft) long, and is designed to be installed over the leads from where they attach to the torch. This adds protection in applications where molten metal will splash back on the leads.

Robotic teaching torch (laser pointer) – 228394


- Mount the laser pointer in the torch sleeve to provide accurate positioning and alignment of the torch.
- Use for online programming/teaching and robotic alignment systems.



Torch and rotational mounting sleeve dimensions



Rotational mounting sleeve clamp dimensions



HPR260XD manual gas revision changes (806340)

Changed Page	Description of changes for revision 2 (date of revision - 9/2011)
Global	Inch marks (") have been replaced by the abbreviation (in).
EMC-1 through W-2	Updated the format and information for both the Electromagnetic compatibility and Warranty sections. Added Certification test marks, Differences in national standards, Higher-level systems, laser and Automation products, and Proper disposal of Hypertherm products information to the Warranty section.
Safety sections	Updated the format and content of the safety information. Added Dry dust collection and Laser radiation information.
2-4	Removed the note under the gas quality and pressure requirements table that said "Oxygen, nitrogen, and air are required for all systems. Nitrogen is used as a purge gas." The statement was inaccurate.
2-5	Added power supply part numbers with Hypernet and the 415 volt power supply information to the table. Changed kW to kVA in the last column, "power".
2-11	Added IEC symbol graphics and descriptions.
3-3	Updated information about noise levels. A generic statement pointing customers to information on the Hypertherm web site will be added to all Mechanized manuals over time.
3-15	Added mounting hole call out.
3-19, 23, 31, 47 and 49	Added caution box about not using PTFE tape.
3-21	Changed the power cable connection point at the power supply from 1x5 to 1x1.
3-25	Added asterisk after note 4 that refers to the note that was added under the caution box.
3-36 and 3-37	Removed <i>changing consumables</i> note under torch alignment. Added a page and moved Torch lifter requirement to next page and added Hypernet information.
3-38	Added 415 VAC info to the table.
3-45	Added "See <i>Supply gas hoses</i> at the end of this section for recommendations" to the first paragraph. Removed the note "Oxygen, nitrogen, and air are required for all systems. Nitrogen is used as a purge gas." from under the first paragraph. The statement was inaccurate. Changed regulator pressure from 8.3 bar (120 psi) to 8 bar (115 psi). Removed the reference to methane because it is not used.
3-47	Added reference to supply gas hoses that are listed at the end of the section. Removed the reference to methane because it is not used.
4-6	Added "When using the argon marking processes, mark and cut individual parts. Marking the entire nest prior to cutting may lead to reduced consumable life. For better results intersperse cuts and marks." under Marking..
4-9	Added graphics and part numbers for mild steel, thick percing, bevel consumables.
4-11	Expanded "Inspect consumables" from one page to 2. Increased size of graphics for clarity.
4-19	Added "(for example: 30 amp O ₂ /O ₂ and 50 amp O ₂ /O ₂ processes). The pierce complete signal must be turned off for processes with shield gas preflow pressures that are lower than the cutflow pressures (for example: 600 amp and 800 amp processes)." to the second paragraph. Added third bullet point. Added "moving pierce", (800 amp SST piercing can be extended to 100 mm (4 in), and "an edge start is recommended unless the operator is experienced with this technique." to the last bullet point.

Changed Page	Description of change for revision 2 (date of revision - 9/2011)
4-22	Updated kerf width compensation data. Added 5, 8, 15, and 50 mm thicknesses. Populated empty boxes with N/A for not available.
4-23	Updated kerf width compensation table data. Added mixed gas processes to the table. Added 5/16, 5/8, 1-1/4, and 1-1/2 in thicknesses. Populated empty boxes with N/A for not available.
4-26, 27, 28, 29, 30 and 33	Added 5 mm, 8 mm, and 5/16 in thicknesses to the cut charts.
4-32 and 4-33	Added "on the shield" to the note - They are only recommended for use if you have a problem with excessive slag on the shield, or problems with the torch misfiring, when using the standard bevel consumables.
4-36	Corrected the N ₂ cutflow, flow rate.
4-31, 32, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 48 through 53	Added 8 mm, and 5/16 in thicknesses to the cut charts.
5-4	Changed heading from Control and signal cables to Power and signal cables.
5-5	Corrected the last line under number 2 to read "contactor remains closed" instead of contactor opens.
5-11	Added error code number 11. Added XD after HPR130, 260, and 400 in the Name column (all instances). Added error code numbers for HPR800XD secondary power supply. Removed error code number 18. It is for the original HPR260 not the HPR260XD.
5-12, 5-13	Removed the "Perform chopper test" step from error code numbers 020, 024/224, 025/225, 026/226, 028/228, 034/234
5-14, 15, and 18	Added HPR400XD references to error code numbers 46, 47 steps 1, 4, and 6. Added HPR400XD references to code number 071 steps 1 and 2..
5-19	Added error code number 98 (Phase loss at initialization).
5-25	Added a note to the description of error code number 159/359. Added "on PCB7" after D30, D31, and D32 in the corrective action steps.
5-26	Added error code number 161
5-27	Added error code numbers 182 and 383
5-32	Added "Main power in" with an arrow. Rewrote the note about checking line to ground, for clarity.
5-62 and 5-63	Updated the Service Parts Replacement Schedule table. Corrected the part number for the annual preventive maintenance kit (it was 228016 and was changed to 228606 and 228623). Corrected the part number for the torch main body (it was 220162 and was changed to 220706). Corrected the quantities for the 6 inch fan (127039 from 3 to 4) and the 10 inch fan (027079 from 1 to 3).
6-2	Added part numbers for power supplies with Hypernet and a note about Hypernet. Added the 415 volt power supply. Added Hypernet upgrade kit.
6-3	Added 415 V main transformer.
6-5 and 6-16	Added 415 V to the note.

Changed Page	Description of change for revision 2 (date of revision - 9/2011)
6-5	Added "127039*** Fan (for pump motor): 230 cfm, 115 VAC, 50-60 Hz" and the note *** 415 volt power supply only" at the bottom of the page. Added the part numbers for the fuses on the power distribution board. Added the part number for the 415 volt control transformer.
6-13	Corrected the quantity for electrode part number 220307 from 6 to 4.
6-15	Added part numbers to Consumables for mirror image cutting for 80 amp, 130 amp and 260 amp mild steel bevel cutting.
Schematics	All sheets updated from revision A to revision B.
Appendix A	Updated to the latest information and formatting for the Hypertherm torch coolant data (MSDS)
Appendix C	Updated TOC to include new items.
C-2	Added metric conversions for gas lead lengths. Added graphic of the ohmic contact extension.
C-3	Added graphics for the rotational mounting sleeve, the rotational mounting sleeve clamp, the leather over wrap, and the robotic teaching torch. Also added a dimensional drawing for the torch and rotational mounting sleeve.

