Contactor Upgrade HT4001/HT4400


Field Service Bulletin

804610 - Revision 0 - August, 2003

Hypertherm[®]

The world leader in plasma cutting technology™

Hypertherm, Inc. Etna Road, P.O. Box 5010 Hanover, NH 03755 USA 603-643-3441 Tel 603-643-5352 Fax www.hypertherm.com



Introduction


Purpose

This field service bulletin will enable a qualified electronics technician to upgrade the main contactor in HT4001 and HT4400 power supply's. The contactor has changed from a 003116 to 003217. The mounting plate included in this kit allows the new contactor to be mounted on the exosting sheet metal.

Note: This contactor can not be used on 200V HT4001 or HT4400 power supplies.

129971 Kit Contents


Part Number	Description	Qty
003217	Contactor	1
001868	Mounting plate	1
075161	Keep nut	1



REMOVING THE ACCESS PANELS

To replace the contactor first remove the side and rear panel(s) of the power supply to locate the contactor.


ര




Power Supplies


REPLACING THE CONTACTOR

- 1. Remove old contactor. Save hardware for installing new contactor
- 2. Align mounting plate with 3 threaded posts facing power supply. Threaded post on power supply sheet metal fits through hole in upper right corner of mounting plate.
- 3. Attach plate from back side with 3 of the bolts removed in step 1.










- 4. Install new contactor to mounting plate using the remaining nut from step 1 and the nut supplied in this kit.
- 5. Connect wiring.



© Copyright 2003 Hypertherm, Inc. All Rights Reserved

Hypertherm, HT4400 and HT4001 are trademarks of Hypertherm, Inc. and may be registered in the United States and/or other countries.