

Recommended spare parts

Power supply

Part Number	Description	Designator	Qty.
129633	Green power lamp assembly		1
027634	Filter housing		1
027664	Filter element		1
129792	Chopper assembly	CH1	1
127039	6" fan :230 CFM, 115 VAC 50-60 HZ		1
027079	10" fan :450-550 CFM, 120 VAC 50-60 HZ		1
003149	Relay: pilot arc, 120 VAC	CR1	1
041837	PCB: I/O		1
003139	Contactora	CON1	1
109004	Current sensor: hall 100 amp, 4 volt		1
129791	Start circuit assembly	PCB1	1
108263	Fuse: 175 amp, 250 volt	F3	1
008551*	Fuse: 7.5 amp, 600 volt	F1, F2	2
041909	Control PCB	PCB3	1
041802	Power distribution PCB	PCB2	1
129793	Flow switch assembly	FLS	1
027185	Heat exchanger fan: 4"		1
006075	Check valve: 1/4" FPT		1
129995	Solenoid valve assembly	CLT SOL	1
129994	Pump assembly: 70 gpm, 200 psi		1
128385	Kit: motor with clamp		1

* 400, 480 and 600 volt power supplies

This change also applies to the HPR130 Auto Gas, HPR260 manual gas, and HPR260 Auto gas manuals.

Ignition console

Part Number	Description	Designator	Qty.
041817	HFHV Ignition PCB		1
129854	Transformer	T1	1

Gas console

Part Number	Description	Designator	Qty.
041805	Power distribution PCB	PCB1	1
041822	Valve driver PCB	PCB3	1
005263	Pressure sensor	PT1-PT3	1
006109	Solenoid valve	SV1-SV14	2
005262	Illuminated power switch	SW1	1

Off-valve

Part Number	Description	Designator	Qty.
006109	Solenoid valve	V16-V19	1