









































65 A – 105 A						
		420539	220842	420536	420533	420540
85 A – 125 A						
		420553	420484	420490	420489	420485

English		CAP MOVES FREELY		CHANGE CAP IF STUCK	
ON		OFF			
					
					
					
					
					
					
Français / French		L'EMBOUIT BOUGE LIBREMENT		CHANGER L'EMBOUIT S'IL EST BLOQUÉ	
MARCHE (ON)		ARRÊT (OFF)			
					
					
					
					
					
					
Deutsch / German		KAPPE IST FREI BEWEGLICH		KLEMMENDE KAPPE AUSTAUSCHEN	
EIN (ON)		AUS (OFF)			
					
					
					
					
					
					
Español / Spanish		LA TAPA SE MUEVE LIBREMENTE		CAMBIE LA TAPA SI SE TRABA	
ENCENDIDO (ON)		APAGADO (OFF)			
					
					
					
					
					
					

Português / Portuguese LIGADO (ON)   	DESLIGADO (OFF)   	A CAPA SE MOVIMENTA LIVREMENTE  	TROCAR A CAPA SE EMPERRAR   
简体中文 / Simplified Chinese 开启   	关闭   	保护帽可自由移动  	如若卡住，则更换保护帽   
한국어 / Korean 켜기(ON)   	끄기(OFF)   	캡은 자유롭게 움직입니다.  	고정되면 캡을 조정하십시오.   
日本語 / Japanese ON (オン)   	OFF (オフ)   	キャップは自由に動きます  	動かない場合はキャップを変えてください  