

***Heat Shield Kits for T Series,  
Duramax™, Duramax Lock, and  
Duramax Hyamp Torches***

***Écran de chaleur des torches  
manuelles séries T, Duramax,  
Duramax Lock et Duramax Hyamp***

**Field Service Bulletin**

**Bulletin de service sur le terrain**

**804230      Revision 6      December 2016**  
**Révision 6      Decembre 2016**

***Hypertherm***<sup>®</sup>

**Hypertherm Inc.**

Etna Road, P.O. Box 5010  
Hanover, NH 03755 USA  
603-643-3441 Tel (Main Office)  
603-643-5352 Fax (All Departments)  
info@hypertherm.com (Main Office Email)

**800-643-9878 Tel (Technical Service)**

technical.service@hypertherm.com (Technical Service Email)

**800-737-2978 Tel (Customer Service)**

customer.service@hypertherm.com (Customer Service Email)

**866-643-7711 Tel (Return Materials Authorization)****877-371-2876 Fax (Return Materials Authorization)**

return.materials@hypertherm.com (RMA email)

**Hypertherm México, S.A. de C.V.**

Avenida Toluca No. 444, Anexo 1,  
Colonia Olivar de los Padres  
Delegación Álvaro Obregón  
México, D.F. C.P. 01780  
52 55 5681 8109 Tel  
52 55 5683 2127 Fax  
Soporte.Tecnico@hypertherm.com (Technical Service Email)

**Hypertherm Plasmatechnik GmbH**

Sophie-Scholl-Platz 5  
63452 Hanau  
Germany

00 800 33 24 97 37 Tel

00 800 49 73 73 29 Fax

**31 (0) 165 596900 Tel (Technical Service)****00 800 4973 7843 Tel (Technical Service)**

technicalservice.emea@hypertherm.com (Technical Service Email)

**Hypertherm (Singapore) Pte Ltd.**

82 Genting Lane  
Media Centre  
Annexe Block #A01-01  
Singapore 349567, Republic of Singapore  
65 6841 2489 Tel  
65 6841 2490 Fax  
Marketing.asia@hypertherm.com (Marketing Email)  
TechSupportAPAC@hypertherm.com (Technical Service Email)

**Hypertherm Japan Ltd.**

Level 9, Edobori Center Building  
2-1-1 Edobori, Nishi-ku  
Osaka 550-0002 Japan  
81 6 6225 1183 Tel  
81 6 6225 1184 Fax  
HTJapan.info@hypertherm.com (Main Office Email)  
TechSupportAPAC@hypertherm.com (Technical Service Email)

**Hypertherm Europe B.V.**

Vaartveld 9, 4704 SE  
Roosendaal, Nederland  
31 165 596907 Tel  
31 165 596901 Fax  
31 165 596908 Tel (Marketing)

**31 (0) 165 596900 Tel (Technical Service)****00 800 4973 7843 Tel (Technical Service)**

technicalservice.emea@hypertherm.com  
(Technical Service Email)

**Hypertherm (Shanghai) Trading Co., Ltd.**

B301, 495 ShangZhong Road  
Shanghai, 200231  
PR China  
86-21-80231122 Tel  
86-21-80231120 Fax  
**86-21-80231128 Tel (Technical Service)**  
techsupport.china@hypertherm.com  
(Technical Service Email)

**South America & Central America: Hypertherm Brasil Ltda.**

Rua Bras Cubas, 231 – Jardim Maia  
Guarulhos, SP – Brasil  
CEP 07115-030  
55 11 2409 2636 Tel  
tecnico.sa@hypertherm.com (Technical Service Email)

**Hypertherm Korea Branch**

#3904. APEC-ro 17. Heaundae-gu. Busan.  
Korea 48060  
82 (0)51 747 0358 Tel  
82 (0)51 701 0358 Fax  
Marketing.korea@hypertherm.com (Marketing Email)  
TechSupportAPAC@hypertherm.com  
(Technical Service Email)

**Hypertherm Pty Limited**

GPO Box 4836  
Sydney NSW 2001, Australia  
61 (0) 437 606 995 Tel  
61 7 3219 9010 Fax  
au.sales@Hypertherm.com (Main Office Email)  
TechSupportAPAC@hypertherm.com  
(Technical Service Email)




**Hypertherm (India) Thermal Cutting Pvt. Ltd**

A-18 / B-1 Extension,  
Mohan Co-Operative Industrial Estate,  
Mathura Road, New Delhi 110044, India  
91-11-40521201/ 2/ 3 Tel  
91-11 40521204 Fax  
HTIndia.info@hypertherm.com (Main Office Email)  
TechSupportAPAC@hypertherm.com  
(Technical Service Email)

© 2016 Hypertherm Inc. All rights reserved.

Duramax and Hypertherm are trademarks of Hypertherm Inc. and may be registered in the United States and/or other countries. All other trademarks are the property of their respective holders.

## Introduction

|   |   |   |
|---|---|---|
|  |  | <p><b>WARNING!</b><br/><b>ELECTRIC SHOCK CAN KILL</b></p>   |
|  |   | <p><b>Disconnect electrical power before performing any maintenance.</b><br/><b>See the <i>Safety and Compliance Manual (80669C)</i> for more safety precautions.</b></p> |

## Purpose

The heat shield provides increased thermal protection to the operator and torch handle when cutting and gouging.

## Tools and materials needed

- None

### Kit 128658 contents

| Part number | Description                            | Quantity |
|-------------|--|----------|
| 220049      | Heat shield assembly, T series torches | 1        |

### Kit 428347 contents


| Part number | Description  | Quantity |
|-------------|--|----------|
| 420369      | Heat shield assembly, Duramax and Duramax Lock torches | 1        |

### Kit 428348 contents


| Part number | Description                                 | Quantity |
|-------------|---|----------|
| 420392      | Heat shield assembly, Duramax Hyamp torches | 1        |

### Install the heat shield

Heat shield for T Series torches






Heat shield for Duramax, Duramax Lock, and Duramax Hyamp torches



1. Disconnect the power.
2. Remove the top (2) wing nuts and bolts.
3. Position the heat shield on the torch as shown in the diagram on the left.
4. Reinstall the wing nuts and bolts.
5. Tighten the nuts.

## Introduction

|   |   |  |
|---|---|--|
|  |  | <b>AVERTISSEMENT !</b><br><b>UN CHOC ÉLECTRIQUE PEUT ÊTRE MORTEL</b>   |
|  |   | <p>Avant tout entretien, débrancher l'alimentation électrique.</p> <p>Se reporter au <i>Manuel de sécurité et de conformité (80669C)</i> pour des mesures de sécurité supplémentaires.</p> |

## Objet

L'écran de chaleur fournit une meilleure protection thermique pour l'opérateur et la poignée de la torche lors de la coupe et du gougeage.

## Outils et matériel requis

- Aucun

### Contenu du kit 128658

| Numéro de référence | Description                                 | Quantité |
|---------------------|---|----------|
| 220049              | Ensemble écran de chaleur, torches séries T | 1        |

### Contenu du kit 428347


| Numéro de référence | Description  | Quantité |
|---------------------|--|----------|
| 420369              | Ensemble écran de chaleur, torches Duramax et Duramax Lock | 1        |

### Contenu du kit 428348


| Numéro de référence | Description                                      | Quantité |
|---------------------|--|----------|
| 420392              | Ensemble écran de chaleur, torches Duramax Hyamp | 1        |

### Installation de l'écran de chaleur

Écran de chaleur pour torches séries T



Écran de chaleur pour torches Duramax, Duramax Lock et Duramax Hyamp



1. Débrancher l'alimentation électrique.
2. Retirer les boulons et écrous à oreilles supérieurs (2).
3. Placer l'écran de chaleur sur la torche comme illustré sur le schéma de gauche.
4. Remettre les boulons et écrous à oreilles en place.
5. Serrer les écrous.